




Product manual

Wireless speaker



Model: GLY-059B

Please read the instructions carefully before use




FCC ID:2BVYP-GLY059B

MANUFACTURER:

HENZHEN GAOST HARDWARE CO.,LTD

Installation Guide



Note:

①: Wireless host

④: Power adapter

②: Subwoofer

⑤: Connect cable

③: Tweeter


⑥: G6F-AC charger

The Wireless name is "Wireless Connection." Upon powering on the speaker, the voice prompt announces, "Wireless connection is ready to pair"; a "ding-dong" sound indicates that the Wireless connection has been successfully established.


Specifications



Product name: Wireless speaker
Model No.:GLY-059B
Input:12Vdc~29Vdc 3A
Subwoofer power:25W Max
Tweeter power:10W Max



Product name: AC/DC ADAPTER
Model No.:GRP-90W2900-A
INPUT:AC100~240V~,50/60Hz,2.5A
OUTPUT:29V 3.0A,87.0W







Product name: USB charger
Model No.: G6F-AC
Input: 12~29Vdc 3A
Output: USB-A: 5Vdc,3A/9Vdc,2A/12Vdc,1.5A
Type-C:5Vdc,3A/9Vdc,2.22A/12Vdc,1.67A
USB-A+Type-C: 5Vdc,3A 15W Max



Specifications

Product name	Wireless Connection
Power Input	DC29V/3A
Frequency Response	20HZ-20KHX
Signal-to-Noise Ratio	≥80db
Maximum Output Power	20W
Wireless connection range	≤10 meters
Wireless transmission frequency	2.4G

Accessories list

Wireless host:1PC	
Subwoofer:1PC	
Tweeter:2PCS	
Connect cable 29V/3A:1PC	
Power adapter:1PC	
G6F-AC charger:2PCS	

Speaker location



FAQs

Issue	Solution
General Issues	First,check the power connection. Make sure the plug is securely inserted into the outlet.
The device won't turn on	If the power supply is working properly, then replace the Wireless host
No sound	Check if the volume is set too low or if the speakers are not connected properly.If there is still no sound,the speaker needs to be replaced.
Wireless cannot pair	Please disconnect all other paired Wireless devices, restart the Wireless host device,and search again. Ensure the speaker is within range of your phone and there are no obstacles in the way.



· 6 ·

Issue	Solution
iPhone/iPad cannot play	Check if the iPhone or iPad is in sleep mode;please play the audio manually.
Android device cannot play	Please confirm that your Android version is 4.3 or higher.

If the above steps do not resolve the issue,record the issue (we recommend taking a video or photo)and contact us. Non-professionals should not disassemble the device to avoid voiding the warranty.

· 7 ·

Safety notice

1.Installation Safety
This product must be installed and secured by a professional or someone with installation expertise. Ensure that the is securely attached to t h e surrounding wooden or upholstered surfaces to prevent personal injury caused by loosening or falling.

2. Electrical Safety
Do not use in damp environments (such as bathrooms, near water sources) or in locations where it may be exposed to water droplets or mist.Use only the power adapter specified on the product nameplate to void overloading caused by prevent overheating or damage.

3.Ventilation and Heat Dissipation
During installation, ensure a ventilation gap of at least 10mm around the headboard cutout to prevent overheating of the speaker’s power amplifier components during prolonged operation, which could lead to malfunction or fire hazards.

4.Hearing Protection
Do not set the volume too high while sleeping (recommended not to exceed 60% of the maximum volume). Listening at high volumes for extended periods may damage your hearing.

· 8 ·

5.Interference Prevention
The speaker emits a magnetic field during operation. Keep it at least 20 cm away from devices susceptible to magnetic interference, such as pacemakers, IC cards, and mechanical watches. If you experience abnormal Bluetooth connections or static noise, check for nearby 2.4 GHz band devices such as Wi-Fi routers or microwave ovens.

6.Child and Pet Safety
Prevent children from inserting foreign objects such as toys or metal pieces into the speaker grille. Do not allow pets to chew on the cables or the unit itself, as this could cause short circuits or choking hazards.

7.Cleaning and Maintenance
Always disconnect the power before cleaning. Wipe the surface gently with a soft, dry cloth. Do not use organic solvents such as alcohol or thinners, as these may seep into the grille and damage the speaker drivers.

8.Troubleshooting Abnormal Conditions
If the speaker produces abnormal noise, smoke, strange odors, or excessive heat, immediately disconnect the power and contact after-sales service for repairs. Do not attempt to disassemble the unit yourself.

· 9 ·

FCC STATEMENT
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
1) this device may not cause harmful interference, and
2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

· 10 ·

interference by one or more of the following measures:
● Reorient or relocate the receiving antenna.
● Increase the separation between the equipment and receiver.
● Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
● Consult the dealer or an experienced radio/TV technician for help.

· 11 ·