


GEL MOUSE WITH CHARM
Instruction Manual
Item Number: MU21036




Contents Included:

- 1 (One) Gel Mouse With Charm
- 1 (One) Instruction Manual
- 1 (One) 2.4GHz USB Receiver

Specifications:


- Connection: Wireless 2.4GHz
- DPI: 800/1200 (Default) /1600
- Number of Keys: 4 Keys
- Operating temperature: -5°C ~ 40°C
- Requires: 2 (Two) x 1.5V AAA Alkaline Batteries (Not Included)
- Mouse FCC ID: 2AYB6-MU21036
- USB Receiver FCC ID: 2AYB6-M3

Part Name




How To Operate

1. Open the battery cover ⑥ on the battery compartment, insert 2 x "AAA" batteries (not included, need to purchase additionally), and remember to check for the correct polarity(+/-).
2. Take out the USB receiver and secure the battery cover ⑥ to the battery compartment.
3. Set the mouse switch ⑦ to the ON position.



Front

4. Turn on your computer and connect the USB receiver to the USB port of your computer, wait a minute until the device has been automatically detected and installed (Plug and Play). When installation is complete, you can use the device.



NOTE: To avoid losing this receiver during transport, we suggest to insert the receiver into the battery compartment on the bottom of this device when it isn't in use.

Q&A

1. Mouse fails to respond

- Is the mouse sensor lit?
No Light: Check battery power, confirm correct (+/-)polarity and verify the power switch is set to ON.
- Is the USB receiver detected normally?
Detection failure: Try a different USB port or restart your computer.

2. Cursor skipping / jittering

- Is your desktop surface smooth?
Use a flat, smooth mouse pad if the surface is uneven.
- Is the battery power low?
Replace with new batteries when power is insufficient.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

WARNING: TO AVOID BATTERY LEAKAGE

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

Back