

TP-LINK®

User Guide

Camera Control for Windows



1910012275
REV1.1.0

Contents

Chapter 1	Introduction	1
1.1	Overview	1
1.2	System Requirement.....	1
Chapter 2	Software Installation.....	2
Chapter 3	Quick Start	5
3.1	Create a New Account.....	5
3.2	Add Your Cameras	6
3.3	View Your Cameras	8
Chapter 4	Software Screen	10
4.1	Live.....	10
4.2	Devices.....	12
4.2.1	Added Devices	12
4.2.2	New Devices	13
4.3	Schedule	14
4.4	Playback.....	15
4.5	Settings	16

Chapter 1 Introduction

1.1 Overview

The TP-LINK Camera Control is a software for you to conveniently view and control multiple TP-LINK IP cameras on a single computer screen.



1.2 System Requirement



FPS (QVGA)	~120	120~360	360~540	540~720	720~
CPU	Intel P4	Intel P4 D	Intel Core 2 Duo	Intel Core 2 Duo	Intel Core 2 Quad
RAM	512MB	1GB	1GB	2GB	4GB
Display	Support 1024x768 resolution or above Support DirectX 9.0b or above Intel 945G or Intel 965G or above				
Hard disk	60GB or above				
Ethernet	100Mbps or above, Gigabit (1000Mbps) LAN recommended				
Motherboard	Intel 945 or Intel 965 or above				
OS	Microsoft Windows® XP SP3 or higher Windows version (2003, Vista, Win7, Win8, Win8.1) (32bits or 64 bits)				




Chapter 2 Software Installation


- Step1: Download the software package from <https://www.tplinkcloud.com/download.php>.
- Step2: Double-click the software package. The setup wizard will pop up.
- Step3: Follow the setup wizard to install the TP-LINK Camera Control.









When the installation is completed, the TP-LINK Camera Control shortcut will appear on your computer desktop.




Chapter 3 Quick Start

3.1 Create a New Account


Step1: Right-click the  icon and select **Run as administrator** to open it. The **Login** page will pop up.



Step2: Create a new account and log in.



The TP-LINK Camera Control screen will pop up.




Note:

At your first login, the **Devices** → **New Devices** page will be displayed. You can add your cameras here for centralized control.


3.2 Add Your Cameras


Step1: Connect your cameras to the network your computer is on.


For details, refer to the Quick Installation Guide of your cameras.




Step2: Go to the **Devices** → **New Devices** page. The system will automatically discover the cameras on your network.



Step3: Click  or double-click each entry, and enter the camera's password (**admin** by default) to add your cameras one by one.



The added cameras will be moved to the **Devices** → **Added Devices** page.




Step4: Click or double-click each entry to rename your cameras for easy identification.

Roof	192.168.0.101	00-0C-43-76-CC-35	Wired	640 x 480	16 fps	Stop	MJPEG	
Passage	192.168.0.103	00-0C-43-76-80-23	Wireless	640 x 480	18 fps	Stop	MJPEG	
Compartment	192.168.0.104	00-0C-43-76-20-61	Wireless	640 x 480	16 fps	Stop	MJPEG	

3.3 View Your Cameras


Go to the **Live** page and view the live video of the added cameras.







Chapter 4 Software Screen


After adding cameras to the system, you can log in whenever you want to view or control these cameras.











- : Click to logout.
- : Click to lock the system. A locked system can't be operated. To unlock it, click anywhere on the system screen and enter your login password.
- **Tabs**: Click to open the corresponding pages for camera control.

4.1 Live

On this page, you can view and control the live video of the added cameras.












➤ **Device List:**

- **Added Devices:** Displays the cameras added to your account. The camera will be marked red if it is disconnected from your local network.
 - **New Devices:** Displays the cameras ready to be added. The system can automatically discover the cameras newly connected to your local network. You can double-click them or drag them to the **Added Devices** list to add them.
- : Click to choose a layout for displaying cameras. The system can display one, four, six, or nine cameras on each page.
- : Click to take a snapshot of the camera(s) you select. To view the snapshots you take, click the **Playback** tab and find them by *Camera name/MAC* → *Date*.
-  / : Click to take a video record of the camera(s) you select. To view the video records you take, click the **Playback** tab and find them by *Camera name/MAC* → *Date*.
-  / : Click to switch to the previous/next page if there are multiple pages.
- : Click to set a cycle duration for auto-switching pages. The system can auto-switch pages every 20 seconds, 30 seconds, 1 minute, 3 minutes, or 5 minutes. This function is turned off by default.
- : Click to enter the full screen mode. To exit this mode, press **Esc** on your keyboard.

Single-camera monitoring

You can double-click the view of a camera to enter/exit single-camera monitoring.




- : Drag the slider behind it to adjust the brightness level of the camera view.
- : Drag the slider behind it to adjust the contrast level of the camera view.
- : Drag the slider behind it to adjust the saturation level of the camera view.
- : Click to restore the brightness, contrast, and saturation levels to their preset values.
-  / : Click to vertically/horizontally flip the current camera view.
- : Click to set the sound level of the camera's live video.
- : Click to exit single-camera monitoring.







4.2 Devices


On this page, you can view and manage camera information.

4.2.1 Added Devices






On this sub-page, you can view and manage added cameras.



Device Name	IP Address	MAC Address	Connection	Resolution	Frame Rate	Record Status	Video Codec	Edit
Roof	192.168.0.101	00-0C-43-76-CC-35	Wired	640 x 480	16 fps	Stop	MJPEG	 
Passage	192.168.0.103	00-0C-43-76-80-23	Wireless	640 x 480	18 fps	Stop	MJPEG	 
Compartment	192.168.0.104	00-0C-43-76-20-61	Wireless	640 x 480	16 fps	Stop	MJPEG	 


- **Device Name:** Displays the camera name. It will be marked red if the camera is disconnected from your local network. To edit the device name, click .



- **IP Address:** Displays the camera's IP address.
- **MAC Address:** Displays the camera's MAC address.
- **Connection:** Displays the camera's connection status, which can be wired or wireless.
- **Resolution:** Displays the resolution of video images. Higher resolution offers better image quality but requires more bandwidth. To edit the resolution, click .
- **Frame Rate:** Displays the rate of video frames. Larger frame rate offers better video quality but requires more bandwidth.
- **Record Status:** Displays whether the camera is recording (manually or on schedule) or not.
- **Video Codec:** Displays the video compression specification, which can be MJPEG or H.264.
- **Edit:**
 - : Click to edit the device name or resolution. After editing, click  to save or click  to cancel.
 - : Click to delete the camera from your account. The deleted camera will appear on the **New Devices** sub-page if it is connected to your local network; otherwise it will disappear from the system.
- **Open Web Page:** Click to open the web management page of the selected camera.
- **Refresh:** Click to refresh the device list.
- **Export:** Click to save the added camera list in a .tpmcs file to your local computer.
- **Import:** Click to import the camera list saved in a .tpmcs file to the system.

4.2.2 New Devices

On this sub-page, you can view and add newly connected cameras.




- **Device Name:** Displays the camera name, which is the camera model by default.
- **IP Address:** Displays the camera's IP address.
- **MAC Address:** Displays the camera's MAC address.
- **Video Codec:** Displays the video compression specification, which can be MJPEG or H.264.
- **Edit:**
 - : Click to add the camera. The added camera will be moved to the **Added Devices** sub-page.
- **Open Web Page:** Click to open the web management page of the selected camera.


4.3 Schedule


On this page, you set a schedule for your cameras to record video automatically.





To set a recording schedule:

1. Select a camera in the Device List, and click **Add**.
2. Specify the time and day(s). Then click .



This camera will automatically record video at the time and day(s) you specified.


 **Tips:**

You can add multiple schedules for each camera and click   to disable/enable each schedule according to your needs.

4.4 Playback


This tab redirects you to the path storing the snapshots and videos you have taken. You can find them by *Camera name/MAC* → *Date* → *Picture/Video*.





4.5 Settings

On this page, you can change system settings.



- **Default View Scale:** Choose whether to view the original scale or full screen on the live view screen.

Original scale



Full screen



- **Storage Path:** Specify the path for the system to store the snapshots and videos you have taken.
- **Save Recording Every:** Specify the interval for the system to save video records automatically.
- **On Screen Display:** Specify the information to be displayed on the live view screen.
- **Other Settings:**
 - **Auto login:** If selected, any user using your computer can log in to the system without the need to enter the account and password information. Don't select this if you want to prevent other users from accessing your system.
 - **Prevent screen-saver:** If selected, your computer will not enter the screen-saving mode when the system is running.
 - **Prompt when exiting program:** If selected, the system will prompt you every time you exit the program.
- **Change Password:** Set a new system login password.