



## N600 Wireless Dual Band Router

Model WNDR3400v3


### Package Contents



Ethernet cable



Router stand  
(two pieces)



Power adapter




N600 Wireless Router  
(with stand attached)

### Attach the stand to the router:


1. Position the router so that the Power button is at the bottom and the USB port is at the top.
2. Snap each piece of the stand onto a bottom corner of the router.



**Step 1:**  
Unplug the power  
to turn off your modem.




**Step 4:**  
Connect the power adapter to the  
router, then plug it into an outlet.

Wait for the 2.4 GHz LED (  ) to light.

If none of the LEDs light, make sure the Power On/Off button is in the on position (pushed in).

**Step 2:**  
Connect one end of the yellow  
Ethernet cable to your modem, and  
and the other end to the  
yellow Internet port on your router.



**Step 5:**  
Connect your computer  
to the router.

Use another Ethernet cable to establish a wired connection as shown in this diagram.

Optionally, connect wirelessly by using the preset wireless security settings located on the product label.

**Step 3:**  
Plug in, then turn on your modem.



Wait approximately two minutes until your modem turns on.

If your modem has a battery backup, first remove and reinsert the battery before connecting your modem to power.


**Step 6:**  
Open a browser.

If the web page doesn't display, close and reopen the browser and enter **http://routerlogin.net** in the address bar. The user name and password are on the product label.

## Preset Wireless Security

This product has a unique WiFi network name (SSID) and network key (password). The default SSID and password are uniquely generated for every device (like a serial number), to protect and maximize your wireless security. This information is on the product label.

NETGEAR recommends that you do not change the preset SSID or password. If you do change the settings, the information on the product label does not apply.



Find the preset wireless settings on your router and record them here:

WiFi network name (SSID) \_\_\_\_\_

Network key (password) \_\_\_\_\_

If you change the preset wireless settings, record them here:

WiFi network name (SSID) \_\_\_\_\_

Network key (password) \_\_\_\_\_

If necessary to retrieve or update your password, type <http://www.routerlogin.net> in a web browser and log in using the default user name (**admin**) and password (**password**).

Select **Wireless Settings** to locate your wireless password.

## Connect Wireless Devices to Your Router

Choose either the manual or Wi-Fi Protected Setup (WPS) method to add wireless computers and other devices to your wireless network.

### Manual Method

1. Open the software utility that manages your wireless connections on the wireless device that you want to connect to your router (iPhone, laptop, computer, gaming device).  
This utility scans for all wireless networks in your area.

2. Look for the preset NETGEAR wireless network name (SSID), and select it. The preset SSID is on the product label.

**Note:** If you changed the name of your network during the setup process, look for that network name.

3. Enter the preset password (or your custom password if you changed it) and click **Connect**.
4. Repeat steps 1–3 to add other wireless devices.

### WPS Method

If your wireless device supports WPS (Wi-Fi Protected Setup), NETGEAR calls this method Push 'N' Connect, you might be prompted to press the WPS button on the router instead of entering a password. If you are prompted:

1. Press the **WPS** button on the router.
2. Within two minutes, press the **WPS** button on the client device, or follow the WPS instructions that came with your wireless device to complete the WPS process.  
The device is then connected to your router.
3. Repeat this process to add other WPS wireless devices.

**Note:** WPS does not support WEP security. If you try to connect a WEP client to your network using WPS, it does not work.

## Support

Thank you for purchasing this NETGEAR product.

After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website.


For product updates and web support, visit <http://support.netgear.com>.

NETGEAR recommends that you use only the official NETGEAR support resources.

You can get the user manual online at <http://downloadcenter.netgear.com> or through a link in the product's user interface.

For the current EU Declaration of Conformity, visit [http://support.netgear.com/app/answers/detail/a\\_id/11621/](http://support.netgear.com/app/answers/detail/a_id/11621/).

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>. See the regulatory compliance document before connecting the power supply.



Download the free genie app from [www.NETGEAR.com/genie](http://www.NETGEAR.com/genie).

Easily share media, files, and printers on the network from your smartphone, tablet, or laptop.



NETGEAR, Inc.  
350 East Plumeria Drive  
San Jose, CA 95134 USA

April 2014

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved.