

A6mini说明书

99mm

84mm

Guidelines for use

AROMA

A6 mini
Essential Oil Diffuser

Overview

- 1 Mist Outlet
- 2 Bluetooth Indicator Light
- 3 Gear position light
- 4 Gear position key
- 5 Timer Indicator Light
- 6 Timer Key
- 7 Switch Indicator light
- 8 Power Key/ Light Key
- 9 Type-C Charging Port

Diffuser

Charging Cable

Essential Oils 10ml*4

Operation

Step 1
the atomizing head counterclockwise rotation to remove.

Step 2
Add essential oil into the atomizing bottle.
Do not fill above the maximum oil level line (marked MAX) on the bottle.

Step 3
Please screw the atomizing bottle tightly onto the atomizer head.

Step 4
Screw the essential oil-filled atomizing assembly (atomizer head + atomizing bottle) tightly onto the diffuser main body, then turn on the power to use the diffuser normally.

Buttons/Indications

Gear / Bluetooth	
Gear Click to switch gears	● ○ ○
Bluetooth Press and hold for 2 seconds until the Bluetooth indicator light turns on. Download the APP and enable Bluetooth on your phone, then the diffuser will enter APP-controlled mode.	○ ● ○
Timer Click to switch the timer	○ ○ ●
Power / Light Switch Power: Long press for 2 seconds Light: After power-on, short press to switch the light mode or turn off the light.	● ○ ○ ○ ● ○ ○ ○ ●

When low on power:
The indicator light flashes for three seconds and then the device shuts down. The product cannot be turned on. Please plug in the power supply before use.

When charging:
The gear indicator light flashes cyclically. All indicator lights turn on after being fully charged.

Gear 1
Works 15s, pauses 200s

Gear 2
Works 15s, pauses 100s

Gear 3
Works 15s, pauses 30s

1h
Auto off after 1 hour.

8h
Auto off after 8 hours.

24h
Auto off after 24 hours.

* When the three lights no longer turn on, the machine has no timer.

Product Notes

Cautions
① Please do not use overloaded power socket, broken power cord or adapter, otherwise your safety may be endangered, if found please replace it in time to avoid fire hazards. ② If you are not a technician please do not try to modify, disassemble, repair the equipment to avoid equipment damage, if the equipment is abnormal, please check that it is operated in accordance with the requirements of normal use, or in accordance with the troubleshooting check. If you can not solve the problem, please contact the seller in a timely manner. ③ add essential oils, please do not drop essential oils within the equipment, equipment use shall not be inverted, tilted, if the equipment needs to be transported to other places, please first of all maintenance and cleaning of the equipment (see the maintenance of the equipment), put can be packaged and transported to avoid damage to the equipment of the penetration of essential oils. Please make sure to maintain and clean the equipment to ensure that the equipment maintains the best working condition.

Equipment maintenance
In order to ensure that in the best diffusion effect, please customers every six months on the equipment to check the maintenance, when the need to replace the new type of incense or diffusion effect is weakened also need to maintain the equipment. ① Unscrew the bottle of essential oils used up. ② Pour the appropriate amount of alcohol into the bottle to clean. ③ After cleaning, pour a small amount of alcohol into the bottle, install the bottle into the device, and turn on the device to work for 2-8 minutes. ④ After cleaning, switch off the power.

Prohibitions

It is prohibited to put down and tilt the product body

Do not drop essential oils directly into the mist outlet

Why isn't the essential oil atomizing?

→

When adding essential oils each time, note the following tips.

Replacement of Essential Oils

① When adding essential oils, do not exceed the MAX line of the atomization bottle. This is to prevent the essential oils in the bottle from being overfilled, which may cause the oils to surge due to air pressure, potentially submerging the atomization hole, producing gurgling sounds, and affecting the atomization effect.

② Prohibited to pour in other liquids! Do not mix fragrance oils with different ingredients to avoid chemical reactions between components in some inferior oils, which may cause corrosion of the atomization core or block the precise atomization system of the diffuser!

If the equipment is blocked and fails to atomize, please refer to the maintenance methods in (Precautions/Maintenance) of this manual for deep cleaning of the atomization pipeline.

We recommend APEXSCENT fragrance essential oils. Our oils are carefully blended, safe and harmless, specially developed for cold mist diffusers, offering multiple fragrance options at reasonable prices.

1
Is the essential oil bottle tightened ?

2
Is the nebulising head system tightened

Tighten up here.

Tighten up here.

Troubleshooting

1. After powering on, the diffuser does not operate or only runs without atomizing the essential oil.

- ② Check if the machine has a low battery
- ✓ Please connect the power cable to charge
 - During charging-The gear indicator light flashes cyclically.
 - Fully charged-The four gear indicator lights are always on.
 - Low battery-The gear indicator lights flash three times before turning off and shutting down.

2. Power on, the device runs, but the device no mist/small mist

- ② Check if it is waterless aroma-essential oil
- ✓ Add essential oils specifically designed for aroma diffusers. Avoid adding water or using essential oils made for humidifiers or spa treatments.
- ② Check if the bottle, atomizing head, and body of the machine are tightly screwed
- ✓ The atomization component must be fully tightened; otherwise, the machine will leak air due to incomplete sealing, resulting in the inability to atomize essential oils.
- ② After turning on the device, single-click the button to switch light modes or turn off the light.
- ✓ Do not add essential oil beyond the MAX line. Overfilling the oil will submerge the air holes of the atomizer head and may cause failure to atomize.

❖ Using for a Period

- ② Check if the device is clogged. After turning on the machine, press your finger against the mist outlet to check for air jet pressure.
- ✓ Refer to the machine cleaning and maintenance steps, clean the machine regularly.
- ② Check if the essential oil in the oil storage tank is below the minimum capacity of 5%.
- ✓ Add essential oils specifically designed for aroma diffusers

The fragrance is not strong enough.

- ✓ Under normal circumstances, our machine can cover an area of 400-600 square feet. However, you can enhance the fragrance by following the methods below.
- ✓ Choose high-concentration waterless essential oil (recommended not to exceed 85%)
- ✓ Re-select the gear button or open the app to reset a longer mist/work time.
- ✓ Place the machine near the air intake of the room, and the natural air flow will carry the subtle dry fragrance throughout the space.
- ✓ Ensure that there's at least 3 feet of clearance above the diffuser so that nothing is blocking the air from passing over the diffuser and dispersing scent in the room.

Product parameters

Product name	Essential Oil Diffuser
Product model	A6 mini
Max power	7.5W
Input power	DC 5V = 2A(Type=C)
Coverage	800 Sq.ft
Battery	2000mAh
Essential oil	10ml
Product size	Φ71×223mm
Net weight	0.6kg

FUTURE FRAGRANCE RESEARCH (HONGKONG) LIMITED
ADDRESS: RM 08, FLAT 4, 3/F, BLK A, TAK LEE IND CENTRE, 8 TSINGYUING CIRCUIT, TUN MUN HONG KONG

If you have any questions while using the device, please feel free to contact us.

apexscentsupport@163.com

Order ID:
Describe the issues you met...
Add some pictures or video

495mm



A6mini 蓝牙折页



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.