



折页:正面展开尺寸:450X180MM 折好尺寸:90X180MM.

六折页

90mm

正面

180mm

Security Camera

User Manual

SC-02

Contents

Customer Support

2

Safety Instructions

2

Package Contents

3

Product Overview

4

Status Indicator Light

4

App Setup & Camera Pairing

5

Key Features Guide

6

Home Security Cloud Storage Introduction

7

Specifications

8

Troubleshooting

9

Environmental Protection & Compliance Statement

11

1. What is cloud storage?

Cloud storage saves video recordings from your security camera to the cloud, allowing you to view them anytime anywhere through the app.

2. What are the benefits of cloud storage?

Cloud storage provides secure and reliable video backup with instant upload, hiding point recordings from loss, theft, or device damage. All data is encrypted for security, and you can access your recordings anytime to review important events.

3. How do I subscribe to cloud storage?

Depending on your purchase channel, you can subscribe to the cloud storage service through the app.

Anti-Flicker Enable / Disable

Anti-flicker function is enabled by default on this device. Please disable it when using outdoors during daytime.

Package Contents

Smart Camera Kit x 1

User Manual x 1

Adhesive Mounting Pads x 2

USB Charging Cable x 1

Mounting Hardware Kit x 1

Note: The Micro SD card is not included. A Class 10 or higher Micro SD card is recommended.

Product Overview

Indicator Light

On/OFF Button

Type-C Port

TF Card Slot

Reset Button

Status Indicator Light

Blue Light Flashes Slowly: Ready for pairing

Stays Solid Blue Light: Network connected; working normally; blue light off.

Stays Solid Red Light: Low battery / Malfunction / Network disconnected / Charging; once fully charged, the red light turns off.

Troubleshooting

Problem	Possible Cause	Solution
Unable to connect to Wi-Fi network / Setup keeps failing	Incorrect Wi-Fi band / Incorrect password / Device too far from router / AP isolation enabled on router	- Make sure the device is connected to a 2.4GHz Wi-Fi network. - Verify the Wi-Fi password. - Move the device closer to the router and try again. - Disable AP isolation or Guest Network on the router. - TF Card: If isolation or Guest Network on the router, press and hold the RESET button for 5 seconds until you hear the reset confirmation, then reconnect the device.
Indicator light off / Device keeps resetting	Low battery / Power issue / Protection mode activated	- Try using a different charging cable / power adapter. - Charge the device for at least 30 minutes. - Press and hold the RESET button for 5 seconds until you hear the reset confirmation, then reconnect the device.

App Setup & Camera Pairing

1. Scan the QR code to download and install the Toopsee App.

2. After downloading and installing the app, open it. Select your region first. After that, create a Toopsee account using your email address or phone number.

3. After successfully registering and logging in to your account, power on your camera, enable Bluetooth on your phone, and then tap "Add Device".

4. After tapping "Add Device", the screen will display the camera image and name. Tap "Add", and the system will automatically go to the Wi-Fi setup screen. Follow the on-screen instructions to enter your Wi-Fi password and connect the camera to your current Wi-Fi network. Once the password is entered, the camera will automatically connect to the network. Please wait for the connection to complete.

5. After the camera successfully connects to the network, you can name the camera and select a usage scenario. Then tap "Next" to enter the live view screen. In the live view screen, tap the live video to access the Camera Details page.

Key Features Guide

- Live View:** Open the app and tap the device card to enter the live streaming screen. Supports full-screen landscape view, screenshots, and video recording.
- Motion Detection Alerts:** Go to Device Settings → Alarm Settings to enable this function. You can adjust sensitivity, set detection zones, and set do-not-disturb periods.
- Two-Way Audio:** Tap the microphone icon to enter talk mode.
- Local Storage (Micro SD Card) Playback:** Go to Playback, select a date, then drag the timeline to view recordings. Supports play, download, and share.
- Cloud Storage Playback:** Requires a cloud subscription. Recordings are securely encrypted and stored in the cloud, with event-based tagging for easy finding.
- Night Vision Mode:** Go to Settings → Image Settings → Night Vision Mode (Auto / IR Night Vision / Full-Color Night Vision / Off).
- Device Sharing:** Go to Settings → Device Sharing. Enter the recipient's registered account or generate a sharing link. Once accepted, the recipient can view and control the device.
- Firmware Update:** When a new version is available in the app, ensure the device battery level is above 30% and the network connection is stable, then tap "Update Now".

Environmental Protection & Compliance Statement

- This product complies with international safety and environmental standards, including RoHS, FCC, and CE.
- When disposing of this product, please follow local electronic waste (WEEE) recycling regulations and do not dispose of it with regular household waste.
- The packaging is made from recyclable paper materials and eco-friendly ink; please dispose of it properly according to local recycling guidelines.
- The content of this manual may be updated due to firmware or hardware improvements; please refer to the latest version published on the official website.
- © 2025 All rights reserved by the brand owner. No part of this document may be reproduced, modified, or used for commercial purposes without prior written authorization.

背面

Quick Start Guide – App Setup & Camera Pairing

1. Scan the QR code to download and install the Toopsee App.

2. After downloading and installing the app, open it. The following screen will appear. Please select your region (2-1). After that, create a Toopsee account using your email address or phone number (2-2).

2-1

2-2

3. After successfully registering and logging in to your account, the following screen will appear. Power on your camera, then tap "Add Device" to add a device.

4.1

4.2

4. Connect Your Camera to Wi-Fi

4-1. After tapping "Add Device", the screen will display the camera image and name. Tap "Add", and the system will automatically go to the Wi-Fi setup screen.

4-2. Follow the on-screen instructions to enter your Wi-Fi password and connect the camera to your current Wi-Fi network.

4-3. Once the password is entered, the camera will automatically connect to the network. Please wait for the connection to complete.

Note: Make sure the camera is connected to the same Wi-Fi network as your phone. If the connection fails, check the Wi-Fi signal and reset the device before trying again.

5. Customize Your Camera

5-1. After the camera successfully connects to the network, the system will display the following screen. You can name the camera and select a usage scenario.

5-2. Then tap "Next" to enter the live view screen.

5-3. In the live view screen, tap the live video to access the Camera Details page.

5-1

5-2

5-3

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.