

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully. This product is only designed to function properly on specific vehicle applications. Please verify that the vehicle requirements match the product specifications and application notes for this part.

Specifications:

FCC ID: OHT692713AA, OHT692427AA, M3N5WY72XX, M3N65981772

Replaces P/N: 05175786, 56040669, 56040649-AE, 56040649AC, 56040649AE, 05175789AA, 05175786AA, 05175817AA

Type: 3 Button Remote

Frequency: 315 MHz

Battery: CR2032

Function: Lock, Unlock, Panic alarm

Condition: 100% Brand New

Material: Plastic + Metal

Compatible with:

2008-2014 Dodge Avenger

2007-2012 Dodge Caliber

2006-2007 Dodge Charger

2005-2011 Dodge Dakota

2004-2009 Dodge Durango

2005-2007 Dodge Magnum

2007-2011 Dodge Nitro

2006-2009 Dodge Ram

2006-2007 Jeep Commander

2007-2016 Jeep Compass

2005-2007 Jeep Grand Cherokee

2008-2012 Jeep Liberty

2007-2018 Jeep Patriot

2006-2017 Jeep Wrangler

2011-2014 Chrysler 200

2005-2007 Chrysler 300

2007-2009 Chrysler Aspen

2006-2010 Chrysler PT Cruiser

2007-2009 Chrysler Sebring

About Program and Compatibility:

1. Self-programmable with 2 working original master keys
2. It Doesn't work on Push Start Button Vehicles. Only Supports Regular Key Vehicles.
3. It Doesn't Support vehicles with Passive Entry Passive Start (Also Called PEPS, Push Button Ignition, Smart Key or Proximity System)

Step by Step How to Configure Instructions:**Remote Programming****Transponder Vehicles:**

Transmitter for the remote key combo is programmed during the Key Programming procedure. Click on the Key Programming for your vehicle to access programming instructions.

NON-Transponder Vehicles:

This programming procedure requires you to already have at least 1 working original remote transmitter. (All buttons must be functional). If you do not have any remote transmitters you must get this new one programmed by a qualified locksmith or dealership. Obtain all remote transmitters for this vehicle. Any existing keys/remote transmitters not used during programming will become inoperative so make sure to reprogram them during procedure describe below. Sit in vehicle with all doors closed and the driver's seat-belt on. Make sure no one else is in the vehicle.

1. Put key in ignition and turn ignition switch to ON position (as far as you can turn key without cranking engine).
2. Using a programmed key/remote transmitter perform the following:
Press and hold UNLOCK button.
After holding the UNLOCK button for a at least 4 seconds, continue holding the UNLOCK button and also press PANIC button within 6 seconds.
Ensure acoustic signal is emitted indicating programming mode active.
Release both buttons.

3. Within 60 seconds carry out the following procedure for each remaining key/remote transmitter:

On the unprogrammed remote, press both the LOCK and UNLOCK button at the same time for 2 seconds then release both buttons.

Ensure acoustic signal is emitted

Within 4 seconds press and release the UNLOCK button.

Ensure acoustic signal is emitted

4. Repeat step 3 now for each remaining key/remote transmitters including working remotes.

5. Switch ignition to OFF position or wait 60 seconds to exit programming mode.

6. Programming is now complete. Test all remotes to ensure proper programming.

Please note: a maximum 6 key remote transmitters can be programmed

Please note: if the vehicle goes into programming mode, but there is no acoustic signal from the new remote, then repeat this procedure again starting from 1st Step.

Key Programming

Transponder Vehicles:

You must have two working programmed or original keys to use this procedure.

1. Insert first programmed key into the ignition and turn ignition switch to ON. Wait for approximately 3 seconds then turn ignition to OFF and remove key.

2. Within 15 seconds of removing first key insert second programmed key into ignition and turn ignition switch to ON. Wait approximately 10 seconds. You will see the immobilizer warning lamp illuminate on the dash and you will hear an audible tone. Turn ignition OFF and remove the key.

3. Within 50 seconds insert the new unprogrammed key into ignition. Turn ignition switch to ON. After approximately 10 seconds you should hear an audible tone and the immobilizer lamp will remain illuminated for 3 seconds. Once this occurs programming is completed.

4. For each additional key you must repeat these steps starting with step number 1.

NON-Transponder Vehicles:

Programming is not required, just get the key blade cut at your local locksmith/dealer and it will start the engine.

Still need help?

Please Contact our Technical Support team for assistance.

Vurkcy-Service@outlook.com

Disclaimer:

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed in accordance with such standards and that you do not disable any motor vehicle safety feature.