Purchase Date:___/___/___ Order/Customer Reference Number:_____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit https://tiny.cc/SunnydazeWarranty


If you have any questions, comments or concerns, feel free to contact us by phone at **833-982-1977**, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

30" STEEL LOG RACK

QXWR30 COMBO

Review all assembly and care information before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.






Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

Save the packing slip.

No.	Parts		Qty.
1		End Panel	1
2		End Panel with Hooks	1
3		Rail	2
4		M8x60mm Bolt	8
5		Lock Nut	8
6		Washer	8
7		Cover	1

Tools Required (not included)	
	13mm Socket Wrench
	13mm Wrench


⚠ WARNING ⚠

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.


⚠WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

ASSEMBLY

Review all information and understand assembly before beginning.



IMPORTANT: Lock nuts must be installed with the nylon insert on the outside. Tools are required to fully tighten lock nuts, failure to properly tighten the lock nuts may result in product malfunction or personal injury.



1. Loosely attach Side Panel (1) to two Rails (3) by hand-tightening four M8x60mm Bolts (4), Washers (6), and Lock Nuts (5).
2. Ensuring the hooks face outward, loosely attach Side Panel with Hooks (2) to the rails using four M8x60mm Bolts (4), Washers (6), and Lock Nuts (5).
3. Fully tighten hardware.

SAFETY STATEMENTS & WARNINGS

- Place log rack on a hard, dry surface.
- Do not overload the log rack — holds approximately 1/8 face cord of firewood.
- Ensure fittings are tight before use. Periodically check and tighten hardware as necessary.
- Protect the unit from outdoor elements with the included cover.
- Do not allow children to play with or around the log rack.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.