



KAISER[®]

MODEL: KSF-8024

Portable Rechargeable Speaker with FM Player

CHARGE
FOR
8 HOURS
BEFORE
FIRST
USE



Images are for illustrative purposes only; colors and design may vary.

Read the entire manual before using this product for the first time.

mitzu.com

 [mitzu.official](https://www.instagram.com/mitzu.official)

 [MitzuCorp](https://www.youtube.com/MitzuCorp)


 [mitzu.official](https://www.tiktok.com/mitzu.official)

 [Mitzu.Corp](https://www.facebook.com/Mitzu.Corp)

WELCOME

Thank you for purchasing the new KAISER® product. We are confident that you will be very satisfied with your purchase.

CONTENTS



1. Speaker (1 piece).
2. Adapter (1 piece).

HOW TO TURN ON?




- Set all switches to OFF.
- Check that the volume is set to the lowest level.
- Verify that the voltage of the power source is compatible with the equipment's required voltage.

1. Connect the power cable to the speaker and then to the power outlet. Allow it to charge for 8 hours before turning it on for the first time.
2. Press the power switch (ON) to turn on the equipment after charging the battery for the first time.
3. Connect the product to the power outlet when the battery is low for up to 7 hours in order to maximize battery life. The unit can continue to be used while connected.



If the device is used intermittently, it is recommended to fully charge the battery at least every 30 days.


GENERAL DESCRIPTION



- A) BUTTONS AND CONNECTIONS.
- B) WOOFERS.

OPERATION

A) BUTTONS AND CONNECTIONS



- 1) TF: Play the Mp3 file from TF card
- 2) USB : Play the Mp3 file from USB
- 3) AUX: 3.5mm aux in jack
- 4) Guitar in jack
- 5) Microphone input jack
- 6) Microphone input jack
- 7) DC: 15V input
- 8) Turn on / off the unit
- 9) VOLUME: Adjust the main volume
- 10) Knob to adjust the Echo
- 11) Knob to adjust the guitar volume
- 12) Knob to adjust the bass
- 13) Knob to adjust the treble
- 14) BT: press to switch to bluetooth mode, and press to disconnect in bluetooth mode
- 15) Recording function: Hold press for recording,short press to play recording files
- 16) MIC. VOL: Adjust the Microphone volume
- 17) Led :Short pess to transfer light mode and turn off light
- 18) MODE / TWS: change to the different function, Hold press for TWS function.
- 19) Previous button
- 20) Play and pause
- 21) Next button
- 22) Microphone priority

TWS CONNECTION

- (1) TWS connection: TWS connection is only for two active speakers of same model, can not support quantity over 2 PCS.
- (2) Turn on two Speakers , press the MODE button to switch to BLUETOOTH® mode for both speakers
- (3) Please long press the (LINK) button on one speaker for 3 seconds. Then two speakers will automatically connect together
- (4) Connect the phone: Open the phone Bluetooth settings, Search and Connect the main device Bluetooth® Name "KSF-8024" . Select music from phone and enjoy TWS playing in pairs with two Speakers.

Charging

Plug the Adaptor into speaker DC jack and connect to power source.

Red LED on when charging.

The LED light will turn off after charge fully.

FM Mode: All FM channels display here. Long press "play / pause" button for auto scan all channels. Please turn off the light switch to have a better FM signal reception

SPECIFICATIONS

Model: KSF-8024

Product Name: Portable Rechargeable Speaker with FM Player

FCC ID: TBD

Power supply: 15 Vcc 4 A

Battery: 7,4 Vcc 4 500 mAh (rechargeable battery)

Woofers: 2 x 8" (2 x 20,32 cm)

Impedance: 3.6 ohm

Frequency response: 45 Hz - 8 kHz

Sensitivity: 92 dB

Tweeter: 2" (5,08 cm)

Bluetooth® version: 5.3

Bluetooth® frequency range: 2,4 GHz

Bluetooth® operating range: Up to 32.8 ft tested in an unobstructed line of sight under optimal conditions




Adapter ca/cc


Input: 100 - 240 Vca 50 - 60 Hz 1 A

Output: 15 Vcc 4 A


Volume level	Battery duration
25% volume	360 minutes
50% volume	180 minutes
100% volume	90 minutes

IMPORTANT


 During use, keep other devices at least 30 cm away from this equipment.


 This equipment has no ventilation slots.

 Do not place the device on flammable sources such as lit candles.


 The device should not be exposed to dripping or splashing water, and objects filled with liquids (such as glasses) should not be placed on the device

CAUTION


 Installed batteries should only be replaced by qualified personnel.

 Risk of explosion if the battery is not replaced correctly.


 Replace only with the same type or equivalent.

 Batteries (installed) should not be exposed to excessive heat such as sunlight, fire, or similar.

This device must not be exposed to dripping or splashing liquids.

 *Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

 *This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device should be installed and operated with a minimum distance of < 1cm between the radiator and your body.*

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and*
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

For questions regarding operation or compliance, contact:
MITZU GLOBAL, LLC
828 Hallmark Dr.
Laredo Tx 78045
contact@mitzu.com
+1 (956)740-7746