



VEHICLE

USB CHARGING CABLE
(INCLUDED IN BATTERY COMPARTMENT)



7.4V Rechargeable Battery Required (Included)

- BATTERY INFORMATION:**
1. Charge the 7.4V battery using the USB cord (included).
 2. Please charge for at least 2.5 hours on your first charge. A red light on the cord will be lit while charging.
 3. When the light turns off, the battery will be fully charged.
 4. Open the battery compartment under the vehicle, insert and plug charged 7.4V battery into vehicle.
 5. Once battery is plugged in, close the battery compartment.
 6. Open the battery compartment on the bottom of the transmitter, insert 2 x "AA" batteries (not included).
 7. Close the battery compartment. Once the vehicle and the transmitter have working batteries, turn the "ON/OFF" buttons on both the vehicle and the transmitter to "ON" and you are all set to drive.

BATTERY CAUTION:

VEHICLE

1. The car contains rechargeable batteries that are replaceable.
2. There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
3. Do not dismantle, crush, incinerate or short-circuit battery.
4. Never expose battery to extreme temperatures or moisture.
5. Keep away from flammable materials and direct sunlight.
6. Only charge using the provided charger, cable, and/or adapters.
7. Rechargeable battery is only to be charged by an adult.
8. Adult supervision of the battery while it is charging is required.
9. Allow battery to cool to room temperature before charging.
10. Charge on a non-flammable surface and keep away from flammable products.
11. Discontinue charging if battery becomes hot, smells, smokes, or gives off a strong odor.
12. Battery charger user with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

TRANSMITTER

1. Rechargeable batteries are not recommended.
2. Alkaline batteries are recommended.
3. Non-rechargeable batteries are not to be recharged.
4. Rechargeable batteries are to be removed from the toy before being charged.
5. Rechargeable batteries are only to be charged under adult supervision.
6. Do not mix alkaline standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
7. Do not mix old and new batteries.
8. Only batteries of the same or equivalent types as recommended are to be used.
9. Batteries are to be inserted with the correct polarity.
10. The supply terminals are not to be short-circuited.
11. If batteries are loose, bend out the contacts for a tight fit.
12. Exhausted batteries are to be removed from the toy and be disposed of immediately, never dispose of batteries in fire.
13. If storing product for long periods of time, make sure to remove batteries.
14. Check the product periodically for signs of damage to electrical parts; do not play with product until damage has been properly assessed.




Batteries should be installed by adults only.



All rubber bands, plastic and wire ties, as well as tags, are not part of this toy and should be discarded for your child's safety. Remove wire ties before giving toy to child. Please keep this packaging for future reference. Colors, designs & contents may vary.

TRANSMITTER



2 x 1.5V "AA" Batteries Required (Not Included)
Alkaline batteries are recommended.

Guangde HFT Development Ltd.
East Ocean Ctr., Gwailu Rd.,
TSL Hong Kong

GD0000106265

NO. 95056

MADE IN CHINA



8 83788 96094 0