



KEPEAK

User Manual

KEPEAK

Catalog

PRECAUTIONS DURING USE	01
PRECAUTIONS FOR STORAGE	01
PRODUCT ACCESSORIES	02
PRODUCT STRUCTURE	03
5 LIGHT MODE	03
HOW TO INSERT THE BATTERY	04
HOW TO ADJUST THE ZOOM	05
COMMON PROBLEM SOLVING	06

SAFETY PRECAUTIONS

PRECAUTIONS DURING USE

- Please read the instruction manual of this product carefully before use.
- Do not shine directly into the eyes to avoid eye damage.
- The torch should not be disassembled and modified for repair by non-professionals as this may damage the circuit board.
- The repair warranty is not included with the modified product.
- If the flashlight is abnormally hot, makes strange noises and smells, or feels abnormal, stop using it immediately.

PRECAUTIONS FOR STORAGE

- Keep out of reach of children.
- For batteries that are not used for a long period of time, store them fully charged and then charge and discharge them once every three months to avoid chemical corrosion.
- Do not use this product underwater for long periods of time.
- Do not leave the torch in contact with sunlight, water, chemicals and corrosive gases for long periods of time as this may damage the torch.

PRODUCT ACCESSORIES

Before using this product, please check that the flashlight and its full set of accessories are included



2* Small flashlight



2* 18650 Battery Tube



2* AAA Battery Holder



2* Lanyard

PRODUCT STRUCTURE




* 5 LIGHT MODE :

When the flashlight is on, just press the tail power button to switch 5 modes in the following order:





→high brightness→medium brightness→low brightness→flash→SOS
→off.

* ONE-CLICK OFF:



Deep pressing the tail button, the flashlight can be turned off in any mode.



HOW TO INSERT THE BATTERY



Supports 2 types of batteries



HOW TO ADJUST THE ZOOM

- 1 Large irradiation range:
Floodlight for wide range illumination.

Zoom in



- 2 Long range illumination:
Spotlight Suitable for long range illumination, throws a beam of light up to 1000ft.

Zoom Out



COMMON PROBLEM SOLVING:

Q Must you cycle through all the modes each time you turn the flashlight on?

A: Press the tail on/off button HARD to turn on or off . While it is ON, press it LIGHTLY to change the light modes: high /middle/low/strobe/SOS.

Q How do white tube work?

A: The white tube is used to fix the 18650 battery. Put the 1*18650 battery in the white tube, and then install it in the flashlight, then install the tail and click the tail switch.

Q Does the portable flashlights included batteries ?

A: Not included.

Q How to insert the battery?

A1: Install AAA Battery: According to "+" "-" direction, Put 3 * AAA battery into the AAA battery holder and install it in the flashlight, then install the tail and click the tail switch.

A2: Install 18650 battery : Put the 1*18650 battery in the white tube, and then install it in the flashlight, then install the tail and click the tail switch. * Do not insert +-in the opposite direction

If you have any other questions, please contact us through Amazon Buyer-Seller Messaging or contact our after-sales mailbox: kepeak@hotmail.com