

Instructions on Dismantling at end of life of Light sources and separate control gear (EU) 2019/2020

Product details

Product : Refrigerator-Freezer
Brand : SAMSUNG
Model(s) : Refrigerator (RR40*****, RR70*****, RR80*****)
 Freezer (RZ40*****, RZ70*****, RZ80*****)


Manufacturer: : Samsung Electronics Co., Ltd

Factory

Samsung Electronics HCMC CE Complex Co.,Ltd.
 Lot I-11, D2 Road, Saigon Hi-Tech Park Tang Nhon Phu B Ward, Thu Duc City, Ho Chi Minh
 City, Vietnam

- Which components are included;
 : Yes
 - light source(s) : No
 - separate control gear(s)
-

1. Tools needed




Item	How to use	Pictures
Driver	Use for assembling and disassembling of screw.	 Phillips Head Driver & Flat Head Driver

2. Dismantling LED light at end of life: Please refer to the disassembly method below.



[Precautions]

- Be sure to unplug the power cord before dismantling.
√ Electrification
- Dismantling of Lamp(s) and Control gear(s) shall be done by Samsung Service Center or Professional repairer.

- Refrigerator

Light Source 1	Description	Image
	<p>1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.</p> <p>⚠ Make sure the unit turned off</p>	
	<p>2. Remove the housing by pressing the housing connection using a flat head driver.</p>	
	<p>3. Assemble the new lamp in the case to be replaced and connect it to the top housing.</p> <p>Caution : 5 LED for Refrigerator's lamp</p>	

- Freezer

Light Source 1	Description	Image
	<p>1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.</p> <p>⚠ Make sure the unit turned off</p>	
	<p>2. Remove the housing by pressing the housing connection using a flat head driver.</p>	
	<p>3. Assemble the new lamp in the case to be replaced and connect it to the top housing.</p> <p>Caution : 3 LED for Freezer's lamp</p>	