

40.00 mm

65.00 mm

Selfie Stick
自拍杆 L20

使用说明

冷靴口

可拆卸磁吸手机支架

铝合金

拍照键

开关键

兼容

ios

Android

怎样使用

1.开关键: 向上拨动开关键开机; 向下拨动则关机。

2.蓝牙配对: 指示灯闪烁进入配对状态, 使用手机搜索“Selfie”来配对, 配对成功后指示灯熄灭。

3.拍照: 遥控器与手机处于连接状态时, 短按拍照键, 指示灯闪烁。

4.无配对: 开机后, 无配对连接状态下无操作5分钟自动关机(如需开机须重复拨动开关键)

5.自动连接: 开机后如上一次已配对手机蓝牙是打开状态, 直接自动连接。

按键功能

取出遥控器并连接手机后使用

开关键

亮灯

开机

熄灯

关机

拍照键

单击: 拍照/录视频

取出遥控器

先拉出杆子再向上滑动即可取出

可拆手机支架

将支架箭头旋转至竖直状态后向上取出

怎样打开三脚架

手柄底部位置拨开即可打开三脚架

自由伸缩

加长稳固的杆身可自由伸缩

规格

· 自拍器型号:25710 - Magnetic Tripod

· 主要材料:ABS+铝合金

· 收纳尺寸:210mm

· 拉伸尺寸:1045mm

· 产品尺寸:210X58X54mm

· 产品重量:186g

· 电池:Lithium battery
(电池不得暴露于诸如日照、火烤或类似过热环境中)

提醒

遥控器兼容Android 4.4以上和IOS 5.1以上
(Android设备设置:如果你在相机选项下改变了你的“音量键功能”,请把它改为“默认”或者“拍照”,让遥控器正常工作)

感谢您的支持!

CE

FC

RoHS

MADE IN CHINA

25710 - Magnetic Tripod

User Manual

冷靴口

可拆卸磁吸手机支架

铝合金

拍照键

开关键

兼容

ios

Android

How to use

1. Switch on and off: Dial the key up to turn on the power; dial the key down to turn off the power.

2.Wireless pairing: Indicator light flashes to enter the pairing state,use your phone to search for "Selfie",and the indicator light will turn off after the paieing is successful.

3. Take photos: When the remote control device is connected to the mobile phone, press the photo button and the indicator will blinks.

4. Unpaired: After starting up, it will automatically shut down for 5 mins without operation in unpaired connection state (if you need to turn on the switch again)

5. Automatic connection: After powering on, if it has been connected with the paired mobile phone, it will be connected directly and automatically.

Key function

Use after taking out the remote control and connecting the phone.

Power key

light up

Power on

light out

Power off

Photo key

click: Take pictures/video

Take out the remote control

Pull the rod out first, then slide it up to remove.

Place phone

Just use your phone near the magnetic phone mount to attach it.

Detachable phone mount

Rotate the mount arrow to the vertical position and then remove it upwards.

Widely compatible

Cold shoe can be connected to the video light, microphone, etc.

How to open a tripod

Open the handle outwards to turn it into tripod mode.

Adjust various angles

Adjust various angles to shoot.

Extendable

Long and stable rod can be extended.

Specification

· Remote Model:25710 - Magnetic Tripod

· Main Material : ABS+Aluminum alloy

· Folded Length : 210mm

· Extended Length : 1045mm

· Product Size : 210X58X54mm

· Product Weight : 186g

· Battery : Lithium battery

(The battery must not be exposed to sunlight, fire or similar overheatingenvironments)

REMIND

Remote control compatibility Android 4.4 or above & IOS 5.1 or above
(Android devices settings: If you change your "volume key function" on the camera, be sure to change it to the "default value" or "Shooting".Getting the remote control to work)

Thank you for your support!

CE

FC

RoHS

MADE IN CHINA

材质：157g铜版纸

M

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.