Papablic

Portable Bottle Warmer

USER MANUAL

WE DON'T DEFINE PARENTING

WE CREATE POSSIBILITIES

Warranty Activation

Authorization of the guarantee

Looking for help? Please contact us at service@papablic.com

TABLE OF CONTENTS

ENGLISH

IMPORTANT SAFEGUARDS 1
COMPONENTS 2
OPERATION GUIDE 2
SPECIFICATIONS 2
HOW TO USE 3
TROUBLESHOOTING GUIDE 10
WARRANTY SERVICE 11
FCC COMPLIANCE 16

IMPORTANT SAFEGUARDS

Read these instructions carefully before using your product and save this manual for future reference.

GENERAL

1. Do not touch hot surfaces with the palm and use the oven mitt to avoid burns.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children should be supervised to ensure that they do not play with the appliance.
4. Do not use this appliance for anything other than its intended purpose. This product is designed exclusively for baby bottles and food containers. Do not use with non-approved containers.
5. Do not operate the appliance if the power cord or plug is damaged, or if the appliance is not working properly, or if it has been dropped or damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
7. Do not use outdoors or for commercial purposes.
8. Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
9. Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
10. Extreme caution must be exercised when moving an appliance containing hot oil or other hot liquids.
11. Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to off, then remove the plug from the wall outlet.
12. Do not use this appliance for any purpose other than its intended use as described in this manual.

IMPORTANT SAFEGUARDS

SAVE THESE INSTRUCTIONS.

CAUTION

1. Before first use, wash all parts except the base unit with mild soap and water. Rinse and dry thoroughly.
2. Do not immerse the base unit in water or allow water to enter the motor housing.
3. Always ensure the bottle or container is properly positioned before operating the appliance.
4. Do not operate the appliance for more than 15 minutes continuously. Allow it to cool down for at least 5 minutes before reusing.
5. Do not use the appliance if the bottle or container is damaged, cracked or has a loose lid.
6. Do not heat baby food directly in the appliance. Always transfer food to a suitable container first.
7. Do not use the appliance to heat liquids other than breast milk, formula or water.
8. Do not leave the appliance unattended while in use.
9. Do not use the appliance if the bottle or container is damaged, cracked or has a loose lid.
10. Do not heat baby food directly in the appliance. Always transfer food to a suitable container first.
11. Do not use the appliance to heat liquids other than breast milk, formula or water.
12. Do not leave the appliance unattended while in use.

COMPONENTS

Check What You Have Received

Check that all components are present. Please contact us at service@papablic.com immediately if anything is missing.

OPERATION GUIDE

Getting To Know the Settings

Control Panel Functions:

Power Button: Press to turn the unit on or off.

Temp. Unit Selector: Switch between °C and °F.

Temp. Adjustment: Press + to increase temperature, press - to decrease temperature.

Preset Modes: Press to cycle through preset modes.

Temperature Display: Shows the current temperature or the selected preset mode.

Indicator Lights: Red light indicates heating, green light indicates the set temperature is reached.

OPERATION GUIDE

Operation Tips

For a more heating experience, this bottle warmer will work optimally at room temperature. Ensure the appliance is placed on a stable, flat surface.

Operation	Indicator Light	Heating Process	Heating Result
Power On	Red light on	The heating tube starts working, and the water in the base unit begins to heat up.	The temperature rises.
Heating	Red light on	The heating tube continues working, and the water in the base unit continues to heat up.	The temperature rises.
Heating Complete	Green light on	The heating tube stops working, and the water in the base unit stops heating up.	The temperature reaches the set value.
Keep Warm	Green light on	The heating tube starts working intermittently, and the water in the base unit is heated intermittently.	The temperature is maintained at the set value.
Power Off	Light off	The heating tube stops working, and the water in the base unit stops heating up.	The temperature drops.

HOW TO USE

How To Warm

1. Place the bottle into the bottle unit.
2. Add water to the base unit. Make sure you do not exceed the upper line. (1/3 of the bottle is the right amount for most bottles.)

HOW TO USE

3. Press the [⏻] button to turn the unit on. The default temperature is 37°C/98°F. Press the [+] or [-] button to adjust the temperature. Alternatively, you can press the [MODE] button to choose from a preset mode.

4. Keeping the silicone lid in place first, then screw the bottle cap on tightly.

5. The bottle will begin the heating process. The heating indicator light will turn red.



NOTE:
The bottle warmer will automatically shut off after 120 minutes as a safety measure. Always allow your formula to cool to a safe temperature before feeding.

HOW TO USE

Keep Warm Mode

1. Press the [⏻] button to turn the unit on.
2. Press the [MODE] button to enter the keep warm mode. The default temperature is 37°C/98°F.

HOW TO USE

NOTE:
- The silicone cover helps prevent water vapor from escaping during heating, ensuring more consistent results. It is not necessary to use it.
- The temperature range for the keep warm mode is 35°C/95°F to 50°C/122°F.
- If you're unsure what temperature to set, start with the lowest setting (35°C/95°F) and gradually increase it until you find the most comfortable temperature.
- Always test the temperature of the milk before feeding your baby, even when using the keep warm mode.
- The keep warm mode will automatically turn off after 120 minutes to prevent overheating.

Keep Warm Mode

1. Press the [⏻] button to turn the unit on.
2. Press the [MODE] button to enter the keep warm mode. The default temperature is 37°C/98°F.

HOW TO USE

Heating

1. Press the [⏻] button to turn the unit on.
2. Press the [+] or [-] button to set the desired temperature.

3. The bottle will begin the heating process. The heating indicator light will turn red.

NOTE:
The bottle warmer will automatically shut off after reaching its set temperature.