


面



M31 摄影手柄补光灯

中文



使用说明书
User Manual

前言

感谢您购买本产品。

重要提示

请认真阅读本说明书。
请妥善保管说明书,将产品交给他人使用时,请务必携带本说明书。
请注意所有警告提示,并遵守说明书内的所有指令。

警告


请勿将本产品放置在有腐蚀性化学物品的地方,以免产品受到腐蚀,被腐蚀可能引起产品故障。

- 请用软布、干布清洁本产品。
- 请勿将本产品放置在温度过高的地方,高温可能导致产品内部电池受损或爆炸。
- 本产品属于精密仪器,请避免使用的掉落、碰撞或重击。
- 需要维修时请联系授权的维修人员,本产品内有精密的电子线路,未经许可不得擅自拆卸导致故障不在本司保修范围内,但用户可以付费维修。
- 建议使用本产品原厂线缆,由于使用非原厂附件导致本产品的任何损坏,不在本司保修范围内但用户可以付费维修。
- 本产品已经通过RoHS和CE认证,请参考相关国家标准使用和操作,因使用操作不当而造成机器损坏,不在保修范围内,但用户可以付费维修。
- 此说明书依据本公司严格测试制定,设计和规格如有变更,恕不另行通知。


设备的规范使用

- 仔细阅读本说明书特别是“重要提示”部分。
- 在本说明书规定的工作条件下使用 and 保存本产品。
- 如不按照本说明书使用产品,或不遵守规定的工作和保存条件,将被视为违规使用。

物品清单



产品简介



- ① 电源键/亮度切换键: 长按电源键两秒,可实现开机或关机。单击切换亮度,双击切换色温。
- ② 蓝牙指示灯: 指示灯闪烁时为待连接状态,常亮为已连接状态。
- ③ 电量/亮度指示灯
- ④ 变焦拨杆
- ⑤ 常亮/闪光模式切换按钮
- ⑥ 闪光灯区域
- ⑦ 手机拍照模式调节
- ⑧ 补光灯区域
- ⑨ 呼吸灯
- ⑩ 1/4"标准螺口
- ⑪ 拍摄按钮
- ⑫ Type-C充电口

产品简介

1. 长按电源键2秒以开启设备。然后,选择蓝牙名称“M31”进行连接。**安卓用户跳过以下步骤**
2. 对于iPhone用户进入设置>辅助功能>放大>缩放区域(全屏缩放),并开启缩放功能。
3. 当启用缩放功能时,屏幕将被放大。您可以用三根手指在屏幕上双击以返回正常视图。

使用说明

2. 摄影手柄使用方法



手机支架 / 切换常亮和闪光灯模型演示 | 摄影手柄离机使用演示

产品规格

型号	M31		
功率	(标) 3W / (闪) 15W		
外形尺寸	123*87*32mm		
充电接口	Type-C		
充电时间	约2.0h		
电池容量	1200mAh		
标称电压	3.7V		
光照角度	120°		
显指	≥ 96+		
色温	(标) 2500-9000K / (闪) 6500K		
灯珠数量	(标) 冷白光/暖光24颗	(闪) COB灯珠	(闪) 3000+次数
续航时间	(标) 最大功率=120min	(闪) 3000+次数	(闪) -
照度	距离	(标) 30 cm	(闪) --
	亮度	(标) 500lux	(闪) --

产品保修卡 WARRANTY CARD

订单号: _____
购买ID: _____
联系电话: _____

保修条款
本公司对产品第一购买客户提供为期一年的质量质保期。
重要说明
请保留您原始购买单据及保修卡,确定您购买的供应商资料都在此单据,同时包括您的购买日期,产品序列号等,这些资料质保服务时都会需要提供。

质保范围不包括

- 产品不当使用, 破坏, 意外错误接线, 不良或失窃的外接装置, 不适合的外接装置所造成的损坏(包括暴露于雨水等损坏), 不在质保范围。
- 自购买30天后产品外观的损伤, 或是不当的表面处理接触造成的外观损失, 不在质保范围。


质保无效说明

- 产品序列号标识已经被撕去或无法辨识, 本质质保无效。
- 产品未经本公司或者指定授权维修公司的检修及改装, 本质质保无效。



M31 Photo Grip Flash Unit

English



User Manual

Foreward

Thank you purchasing

Instructions

Please read this product manual carefully. Keep this product manual. Always include this product manual when passing the products on to third parties. Head all warnings and follow all instructions in this product manual.

Warning


Do not place the product in a place where there are corrosive chemicals to avoid corrosion of the product, which may cause product failure.

- Use only a microfibre and dry cloth for cleaning the product.
- Operate carefully to not cause any damage by dropping or physical shocking it.
- Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
- Please have the product checked by the authorized service or agent if your product has some problems. Please note that this warranty does not apply to repair arising out of the malfunction of unauthorized disassembly, although you may request such repairs on a chargeable basis.
- Use of original cable accessories is recommended. Please note that this warranty does not apply to repair arising out of the malfunction of original accessories, although you may request such repairs on a chargeable basis.
- The product is certificated by RoHS and CE. Please operate the product in full compliance with the operation standards. Please note that this warranty does not apply to repair arising from malfunction, although you may request such repairs on a chargeable basis.
- The instructions and information in this manual are based on thorough, controlled company testing procedures. Further notice will not be given if the design and specifications change.


Standardized use of the product

- Use and store the product under the working conditions specified in this manual.
- Read this manual carefully, especially the Important Tips' sections.
- Failure to use the product in accordance with this instruction manual, or failure to comply with the specified working and storage conditions, will be considered illegal use.

Packing List



Product Introduction




- ① Power/Brightness Button: Press and hold for 2 seconds to turn the device on or off. Click to switch brightness levels, double-click to switch color temperature modes.
- ② Bluetooth Indicator: Flashes when pairing is available, stays solid when connected.
- ③ Battery/Brightness Indicator
- ④ Zoom Rocker
- ⑤ Continuous Light / Flash Mode Switch
- ⑥ Flash Unit
- ⑦ Smartphone Photography Mode Controls
- ⑧ Fill Light Unit
- ⑨ Breathing Light Effect
- ⑩ 1/4" Standard Screw Socket
- ⑪ Shutter Button
- ⑫ Type-C Port

Connection Instructions

1. Press and hold the power button for 2 seconds to turn on the device. Then, select the Bluetooth name "M31" to connect.
2. For iPhone users: Go to Settings > Accessibility > Zoom > Zoom Region (Full-Screen Zoom) and turn on the Zoom feature.
3. When the Zoom feature is enabled, the screen will be magnified. You can double-tap the screen with three fingers to return to the normal view.

Instructions

2. How to Use the Photo Grip



Phone Holder / Mode Switching Demonstration | Detached Grip Usage Demonstration

Product Specifications

model	M31		
power	(标) 3W / (Flash) 15W		
Dimensions	123*87*32mm		
Charging Port	Type-C		
Charging Time	Approx. 2.0 h		
Battery Capacity	1200mAh		
Rated Voltage	3.7V		
Beam Angle	120°		
CRI	≥ 96+		
Color Temperature	(标) 2500-9000K / (Flash) 6500K		
Number of lamp beads	(标) 24 Cool White 24 Warm White LEDs	(Flash) COB LED	(Flash) COB LED
Run Time	Maximum Power=120min	(Flash) 3000+ Times	
	Minimum power=4h	(Flash) -	
Illuminance	Distance 30 cm	(Flash) -	
	Brightness 500lux	(Flash) -	

WARRANTY CARD

Order number: _____
Purchase ID: _____
Contact number: _____

Guarantee clause
The company provides a one-year warranty period for the first customer to buy the product.

Important note
Please keep your original purchase documents and warranty card, and make sure that the supplier information you purchased is included in the documents, including your purchase date, product serial number, etc., which will be provided during the warranty service.

The warranty does not cover

- Improper use of products, damage, accidental incorrect wiring, poor or mismatched external devices, unsuitable external devices caused by damage (including exposure to rain damage), are not covered by the warranty.
- Damage to the appearance of the product 30 days after the date of purchase, or damage caused by improper surface treatment contact, is not covered by the warranty.

Invalid warranty statement

- Product serial number identification has been torn off or cannot be identified, the essence of the warranty is invalid.

• Without the maintenance and modification of the product by the Company or the designated authorized maintenance company, the essential warranty clause is invalid.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.