

Tapware is to be installed by a Licensed Plumber in accordance with AS/NZS 3500:2003

Recommended working water pressure 300-500 kpa.
Maximum water temperature is 65 deg.c.

INSTALLATION GUIDE

Voda Sink Mixer Pull Out
Product code: VSMPO

INSTALLATION GUIDELINES

- Ensure adequate cupboard space has been provided to allow the Pull-out hose to move freely.
- Prior to installing the mixer, remove the Clamp and Fixing Nut from the assembly. Mounting surface must be flat and level.
- Remove the Weights from Hose.
- Ensure a 35 - 38mm clearance hole is provided through the mounting surface.
- Pass the Pull-out Hose through the hole and lower the Mixer onto the mounting surface.
- Working from underneath, fit the Clamp and Fixing Nut.
- Gently bend the Flexible Tail Extensions away from the Thread Bar and Pull-out Hose.
- Use the provided Tube Spanner to tighten and secure the Mixer to the mounting surface.
- Attach the DCV Assembly to the Thread Bar (note the arrow direction).
- DCV has an O-ring seals. No need for thread tape.
- Connect the Pull-out Hose to the DCV Assembly and tighten well.
- NOTE:** Do not remove the Hose adapter fitting from the Pull-out Hose.
- Attach the Weights (2) to the Hose, ensure the Rubber stop is between the Clamp and the Weights.
- The maximum recommended length of Nozzle pull-out is approximately 400mm.
- Connect the provided Hot and Cold Flexible tails to the Mixer.
- Connect the Hot and Cold Flexible tails to the corresponding 1/2" BSP water feed lines.
- The 1/2" connection of the Flexible tails have a conical seal, ensure the mating threads are cut square and burr free.
- Isolating stop valves are recommended with all installations. (Not supplied).
- Ensure all fittings and connections are watertight.
- Check Mixer functions correctly with a smooth action.
- Ensure the Pull-out Hose operates freely with minimal contact to other parts.

PLUMBER NOTE

- On-site testing using higher water pressures must be conducted with the Mixer in the closed position. (STATIC TEST)
- Under no circumstances is the Mixer to be opened when exceeding the maximum stated water pressure.
- At the completion of testing, do not relieve any high water pressure by opening the Mixer.
- Exposing the internals of the Mixer Cartridge to higher than specified water pressures will void the manufacturers warranty

