


托特复古音响

DZ-022



产品使用说明书

感谢您选择我们的产品 希望您尽情享受音乐之旅

• 安全指导

在使用前请仔细阅读此说明书，并保存好以供之后参考。

01. 远离热源，太阳暴晒和尖锐物体。
02. 远离明火。
03. 不要插入任何金属物体，避免短路。
04. 不要自行修理产品而应联系授权维修厂家。
05. 避免产品淋雨，喷雾。
06. 如果产品过热，损坏或坠入液体中，请停止使用。
07. 根据标准和规定使用产品。

• 包装配件


01. DZ-022音响*1
02. TYPE-C充电线*1
03. 产品说明书*1

• 内置电池

01. 内置可充电电池，初次使用需2-3小时完成充电，放电周期。
02. 不要把充满电的电池继续充电，过度充电会缩短电池寿命。
03. 如果放置不用，满电的电量可能会有些许流失。
04. 产品置于过热或者过冷的地方，都会缩短产品寿命。

• 充电功能

01. 插入TYPE-C充电线，另一头连接充电器。
02. 产品的LED充电指示灯常亮红灯，即音响正常充电。
03. 当产品充满电时，LED指示灯红灯熄灭。



• 操作功能

- | | | |
|---------------|------------|------------|
| ① 开 / 关机 | ② 音量加減 | ③ 上一曲/暂停播放 |
| ④ 下一曲 | ⑤ 音响互联 | ⑥ FM 收音机模式 |
| ⑦ TYPE-C 充电端口 | ⑧ USB 优盘端口 | ⑨ TF 卡端口 |
| ⑩ AUX 音频接入端口 | | |

1. 开/关机：向右顺时针旋转开机，向左逆时针旋转关机。
2. 音量加減键：向右顺时针旋转音量增大，向左逆时针旋转音量减小。
3. 上一曲/暂停播放：短按上一曲歌曲，长按暂停/播放歌曲
4. 下一曲：短按下一曲歌曲。
5. 音响TWS互联：同时将两台音响开机，然后长按“DOWN”键听到提示音后则对联成功，再次长按则关闭。
6. 收音机：(1)短按FM键进入收音机模式。(2)将充电线TYPE-C插入音响作为信号增益天线，另一端不要插在充电器上。(3)长按FM键5秒钟进行自动搜台。(4)搜索到电台后短按“UP/DOWN”键切换电台进行收听。
7. 充电功能：充电时亮红色指示灯，充满后红灯灭。
8. U盘功能：在关机状态下插入U盘再开机，则开机后自动优先播放U盘内音乐(注:支持最大内存为:32GB，音频文件格式仪支持:MP3、WAV格式)。
9. TF卡功能：在关机状态下插入TF卡再开机，则开机后自动优先播放TF卡内音乐(注:支持最大内存为:32GB，音频文件格式仪支持:MP3、WAV格式)。
10. AUX功能：开机状态下，插入音频线自动进入AUX。

• 故障排查

故障现象	可能原因	解决方案
无法搜索蓝牙	电池没有电关机了	给音响充电
无法配对蓝牙	音响已经配对了另外的设备 且没有进入配对模式	关闭其他配对设备 重新搜索并进行配对

• 技术规格


产品型号	DZ-022
蓝牙名称	BT-022
蓝牙接收距离	直线无障碍10米
喇叭功率	5W
电池容量	500mAh
充电接口	TYPE-C接口
充电时长	2H
工作时长	音量最大时≥3H，音量最小时≥4H (注：手机的类型和实际情况不同，时间也会有所不同)

感谢您的支持！

FC CE RoHS

Tote Vintage Speaker

DZ-022



Product Instruction Manual

Thank you for choosing our products and I hope you enjoy your musical journey

• SAFETY INSTRUCTION

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE

- 01.Keep away from heat, sun exposure and sharp objects.
- 02.Stay away from the open fire.
- 03.Don't insert any metal objects. Avoid short circuit.
- 04.Don't repair the product by yourself, but contact the authorized repairer .
- 05.Avoid products from getting caught in the rain,Spray.
- 06.If the product is overheated. Damaged or fell into liquid. Please stop using.
- 07.Use products according to standards and regulations.

• PACKAGING ACCESSORIES


- 01.DZ-022Audio*1
- 02.TYPE-C charging cable*1
- 03.Product description*1

• INTERNAL BATTERY

- 01.Built-in rechargeable battery takes 2-3 hours to complete the charging and discharge cycle.
- 02.Don't continue charging a fully charged battery. Overcharging will shorten the battery life.
- 03.If the full load is placed, it may be a little lost.
- 04.Placing the product in a place that is overheated or too cold will shorten the product life.

• CHARGING FUNCTION

- 01.Plug in the TYPE-C charging cable and connect the charger at the other end.
- 02.The product's LED charging indicator light is always on in red, that is,the sound is charging normally.
- 03.When the product is fully charged, the LED red light is off.



• OPERATION FUNCTION

- | | | |
|----------------------------|-----------------------------|------------------------------|
| ① Power on /Power off | ② Volume +/- | |
| ③ Previous Song/Play/Pause | ④ Next Song | ⑤ AudioInterconnection |
| ⑥ FM mode | ⑦ TYPE-C charging port | ⑧ The USB superior disk port |
| ⑨ TF card port | ⑩ The AUX audio access port | |

1. Power Button: Turn clockwise to turn on; turn counterclockwise to turn off.
2. Volume Buttons: Turn clockwise to increase volume; turn counterclockwise to decrease volume.
3. Previous Track/Pause: Press briefly to skip to the previous track; press and hold to pause or resume playback.
4. Next Track: Press briefly to skip to the next track.
5. TWS Pairing: Turn on both speakers simultaneously, then press and hold the “DOWN” button until you hear aprompt to confirm successful pairing; press and hold again to disconnect.
6. Radio: (1) Press the FM button briefly to enter radio mode. (2) Insert the Type-C charging cable into the speakerto use it as an antenna for signal enhancement; do not connect the other end to a charger. (3) Press and hold the FM button for 5 seconds to performan automatic station scan. (4) After stations are found, press the “UP / DOWN” buttons briefly to switch between stations and listen.
7. Charging Function: The red indicator light turns on during charging and turns off when fully charged.
8. USB Drive Function: Insert a USB drive while the device is powered off, then turn it on. Upon startup, the device will automatically prioritize playing music from the USB drive(Note: Supports up to 32GB of storage; audio file formats supported: MP3 and WAV only).

9. TF Card Function: If you insert a TF card while the device is off and then turn it on, it will automatically prioritize playing music from the TFcard upon startup (Note: Supports a maximum capacity of 32GB; supported audio file formats are limited to MP3 and WAV).
10. AUX Function: When the device is on, inserting an audio cable will automatically switch to AUX mode.Translated with Deepl.com (free version)

• TROUBLESHOOTING

Failure phenomenon	Possible reasons	Solution
Unable to search Bluetooth	The battery is not powered off	Charge the audio
Unable to pair Bluetooth	The audio has been paired with another device and has not entered pairing mode	Turn off other paired devices Search again and pair

• TECHNICAL SPECIFICATIONS

Product Model	DZ-022
Bluetooth Name	BT-022
Bluetooth receiving distance	Straight line obstacle free 10m
Speaker Power	5W
Battery capacity	500mAh
Charging Interface	TYPE-C Interface
Charging duration	2H
Working hours	Maximum volume ≥ 3H, minimum volume ≥ 4H (Note: The time will vary depending on the type of mobile phone and the actual situation)

Thank you for your support!

FC CE RoHS

80×274mm

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.