



95mm


70mm

气传导耳机



使用指南及保修说明
User Manual & Warranty Information

示意图



充电口
指示灯
麦克风
音量-/上一曲
电源键/模式键
音量+/下一曲

基础使用指南

无线配对
首次配对：开机自进入配对模式。在手机设置里的无线列表中找到 " L10 Air " 并连接，连接成功后指示灯熄灭。

切换 / 重连设备：先断开当前连接，耳机将进入红蓝交替闪烁的配对模式。其他设备可搜索并点击 " L10 Air " 完成配对。

自动重连：正常开机后，耳机将自动连接最近配对的设备。确保前端设备（如手机）的无线已开启。

充电
连接充电线后，手机将显示耳机电量。当电量过低时，请插入充电线充电。

充满电约需 2 小时，充电时指示灯为红色，充满后变为蓝色。

注意：请使用输出为 5V/≤1A 的 USB 充电器。

本产品内置可充电电池，需回收处理，请勿投入火中，以防爆炸。

按键操作指南

功 能	操 作	状 态
开机	长按 " " 3-5秒	红蓝灯闪烁1秒
关机		红灯亮1秒
音量 +	单击 " "	无线已连接
音量 -	单击 " "	
下一曲	长按 " " 2秒	播放音乐
上一曲	长按 " " 2秒	
暂停播放	单击 " "	音乐暂停播放
恢复播放		
挂断电话		来电时
接听电话		
拒接电话	长按 " " 2秒	通话中
手机/耳机音源切换		
游戏/音乐模式切换	4击 " "	无线已连接

指示灯状态说明

状 态	指示灯表现
搜索配对	红蓝灯交替闪烁
正在充电	红灯常亮
充满电量	蓝灯常亮

AI智能语音控制 (手机需支持语音唤醒功能)

功 能	操 作	状 态
语音控制	双击 " "	无线已连接

说明：在无线连接状态中，双击 " "，听到提示音后即可语音操控手机，便捷高效。

示例指令：
查询类：现在几点钟？ / 今天天气怎么样？
导航 / 通话：导航去深圳世界之窗 / 打电话给某某
应用 / 音乐控制：打开网易云音乐 / 播放刘德华的《冰雨》 / 下一曲 / 音量降低 / 打开美团 / 打开喜马拉雅 / 打开微信 / 播放戏曲

智能运动，轻松好玩

故障排查与解决

无法开机
确定耳机是否充满电量，按键是否误操作，同时充电激活。

无法无线连接
耳机指示灯是否处于红蓝灯交替闪烁阶段，如耳机处于蓝灯熄灭，表示耳机与其他设备已经连接，需要断开当前连接设备。

无法回连
确定前端（如手机无线）是否正常开启。

耳机音量较小
手机是否需加大音量，需要手机增加或减小音量。确认佩戴方式是否正确。

产品参数

型号：L10 Air	版本：6.0
重量：≈26g	充电：≈2h
通话：-38dB	播放：≈10h&60%音量
距离：≈10米	输入：5V/180mA
容量：220mAh	
协议：HFP A2DP AVRCP	

注意事项

- **防水警示：**耳机严禁浸入水中，避免短路损坏。
- **电池养护：**长期不使用时，至少每月充满电一次。
- **拆装与售后：**禁止私自拆装部件；产品出现缺陷时，请立即停用并联系销售方售后。
- **清洁保养：**运动后及时擦拭耳机，重点清洁充电口，防止汗水、盐水腐蚀，延长使用寿命。
- **安全须知：**远离火源、热源、冷冻源及化学品，严禁暴力撞击、挤压或拆装。
- **充电要求：**请使用输出为 5V/1A 及以内的充电头。

合格證
Q.C.Passed

产品保修卡

该卡为产品保修凭证，请妥善保管

产品名称：	产品型号：
购买日期：	客户名称：
联系方式：	

产品维修记录


日期	不良现象	方案

AIR CONDUCTION MOTION HEADPHONES



使用指南及保修说明
User Manual & Warranty Information

Schematic diagram



充电口
指示灯
麦克风
音量- / Previous
Power / Mode key
音量+ / Next

Basic Usage Guide

Wireless Connection
First Pairing: Power on to enter pairing mode automatically. Find " L10 Air " in your device's Wireless list and connect. The indicator light will turn off once connected.

Switch/Reconnect Devices: Disconnect from the current device, then the earphones will enter pairing mode with red and blue lights flashing alternately. Other devices can search for and tap " L10 Air " to pair.

Auto-Reconnect: Power on normally to reconnect to the last paired device automatically. Ensure the front-end device's Wireless is enabled.

Charging
When connected, your phone will display the earphone battery level. Plug in the charging cable when the battery is low.

Full charge takes approx. 2 hours. Indicator is red during charging and blue when fully charged.

Use a USB charger with 5V/≤1A output only.

The rechargeable battery must be recycled properly. Do NOT dispose of it in fire to avoid explosion.

Button Operation Guide

Function	Operation	Status
Power on	Press ' ' for 3-5s	Red and blue lights flash for 1s
Power off		The red light stays on for 1s.
Volume +	Click ' '	Wireless connected
Volume -	Click ' '	
Next song	Press ' ' for 2s	Music playing
Previous song	Press ' ' for 2s	
Pause	Click ' '	Music pause
Resume		
Hang up		Phone calls in
Answer the call		
Decline the call	Press ' ' for 2s	On the phone
Switch Earpiece Phone/Headphone		
Switch between Game/Music mode	4-click ' '	Wireless connected

LED Indicator Status

Status	Indicator Light Behavior
Search for a match	Blue and red lights flash alternately
Charging	Normally on red light
Finished charging	Normally on blue light

AI intelligent voice control (Phone needs to support voice wake-up function)

Function	Operation	Status
Voice control	Double-click ' '	Wireless connected

While connected via Wireless, double-click the " " button and you'll hear a prompt tone, after which you can control your phone with voice commands.

Example Voice Commands:
What time is it now.....Today's weather.....
Navigate to Taipei 101.....Call someone

Smart exercise, easy and full of fun

Troubleshooting & Solutions

Unable to boot
Determine whether the headset is fully charged, whether the button is misoperated, and then charge and activate.

Unable to connect to Wireless
Check if the earphone indicator light is in a stage of alternating blue and red flashes. If the blue light is off, it indicates that the earphones are already connected to another device, and you need to disconnect the current connected device.

Can't back to even
Make sure the front end (e.g., Wireless) is open properly.

Headphone volume is low
Whether the phone increases the volume, the phone needs to increase or decrease the volume. Wearing a way Whether it is right.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Product parameter

Model: L10 Air	Version: 6.0
weight: ≈26g	Battery: 220mAh
Input: 5V/180mA	Charging time: ≈2h
Call parameters: -38dB	
Distance: ≈10 meter	
Operating time : ≈10h@60% Volume	
Profile: HFP A2DP AVRCP	

Care & cleaning

- **Water Resistance:** Do not immerse the earphones in water, as it may cause short-circuit and damage.
- **Battery Maintenance:** Fully charge the earphones at least once a month if left unused for long periods.
- **Disassembly & After-sales:** Do not disassemble the product without authorization. Stop use immediately and contact after-sales support if defects are found.
- **Cleaning:** Wipe the earphones clean after exercise, especially the charging port, to prevent corrosion from sweat or saltwater.
- **Safety Precautions:** Keep away from fire, heat, freezing sources, and chemicals. Avoid violent impact, squeezing, or disassembly.
- **Charging:** Use only a USB charger with an output of 5V/≤1A.

Certificate of conformity
Q.C.Passed

Product warranty card

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Purchase date:	Clients name:
Contact:	

Product maintenance records

Date	Bad phenomenon	Solution