



Digital Kitchen Timer Instruction Manual


03-V20230404 EN

1. Introduction


Congratulations on your purchase of the ThermoPro Digital Kitchen Timer. You will now be able to keep track of time with this digital timer!

2. Components

- 1 x Digital Kitchen Timer
- 1 x AAA Battery
- 1 x User Manual



-01-



3. Features

1. Large LCD Screen.
2. Function: Countdown timer or count-up timer.
3. Countdown Time Range: 99min59sec.
4. Count-Up Time Range: 99min59sec, infinite cycled.
5. Two adjustable volume settings.
6. Tabletop, magnet-mountable and wall-mounted design.
7. Power: 1 x AAA battery.

-02-

4. Buttons

M BUTTON: Press to set countdown minutes. Press and hold to quickly scroll through digits, the setting range is 00~99 minutes.

S BUTTON: Press to set countdown seconds. Press and hold to quickly scroll through digits, the setting range is 00~59 seconds.

ST/SP BUTTON: Press to start or to pause the timing function, during the timing, you can press this button to change the timing. Press the **M** and **S** buttons simultaneously to clear the current set minutes and seconds.

VOL: Press to adjust volume settings.

5. Before First Use

1. Remove the battery compartment cover on the back of the device.
2. Insert 1 x AAA battery into the compartment matching the + and - symbols as indicated inside the battery compartment.

-03-

3. Replace battery cover, making sure it locks in place.
4. Remove the protective film from the display.

6. To Use Count Down Timer (Up to 99 MIN 59 SEC)

1. Press the **M** and **S** buttons for desired timing period. Press and hold the buttons for faster setting.
2. Press the $\frac{ST}{SP}$ button to begin timing. The “M” and “S” on the display will flash when timer is in use.
3. To stop timing, press the $\frac{ST}{SP}$ button. To restart the timer press the $\frac{ST}{SP}$ button again.
4. After time elapses, alarm beeps for 30 seconds. To stop the beeping, press either the **M**, **S**, or $\frac{ST}{SP}$ button.

7. To Use Count Up Timer (Up to 99 MIN 59 SEC)

1. Press the **M** and **S** buttons simultaneously to reset to 00:00.
2. Press the $\frac{ST}{SP}$ button to start counting up in seconds.

3. To interrupt the count, press the $\frac{ST}{SP}$ button. To resume counting, press the $\frac{ST}{SP}$ button again.

8. Declaration of Conformity

Hereby, the manufacturer declares that this product complies with the basic requirements and applicable regulations of the EMC Directive 2014/30/EU. The complete declaration of conformity can be found at:
<https://buythermopro.com/eu-declaration-of-conformity/>

9. Disposal of the Electronic Appliance



This electronic appliance should not be disposed of with normal household waste. Dispose of the unit at an approved facility or at your local recycling center. Please observe the current rules and regulations when disposing of the appliance. Contact your local council if in doubt.

10. Limited One-Year Warranty

ThermoPro warrants this product to be free of defects in parts, materials and workmanship for a period of one year, from date of purchase.

Should any repairs or servicing under this warranty be required, contact Customer Service by phone or email for instructions on how to pack and ship the product to ThermoPro.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

11. Customer Service

Call or Text: 1-877-515-7797(USA & Canada only)
Email: service@buythermopro.com
Hours: Weekdays 9:00AM- 5:00PM EST