

Thank you for having chosen our company's fog machine. For your own safety, please read this user manual carefully before installing the device.

When receiving the machine, open the package and check carefully whether the machine is damaged or the accessories are lost, if any problems, please contact the supplier.

Accessories

Name	Quantity	Name	Quantity
Smoke machine	1piece	Handle	1piece
Power cord	1 piece	pad	2 piece
Manual	1 piece	Screw knob	4pieces
Remote controller	1 piece		

Technical Parameter

Power: 1500W	Voltage: AC 110V 60Hz
Warm-up time: 3minutes	Capacity of tank : 2.5liters
Smoke distance: 4-5 meters	Weight: 5.4kg
Fluid consumption(100%output): 20000Cuft/min	Size : 47*25*20cm
Remote control	Voltage:DC 12V
Frequency	433.92MHz

Guidance

1. This product can be installed in high places(with hanger), or placed on the ground.
2. Keep the fog machine flat,do not tilt or flip. Before connecting this unit to the mains power supply, you must add the fluid tank with high quality fog fluid and check that the nozzle is clean and unobstructed.
3. Before connect to power, you should check whether the voltage you use is suitable for the fog machine or not.
4. Power cord should be plugged into a grounded electrical outlet,put the switch to "ON", then fog machine start warming up, can spray fog after warming up is completely.
5. Connect the controllers with the fog machine, then you can control the fog

machine by the controllers.

Control Mode.....

1. Remote control key functions:

S button control pump, M is the LED mode (menu) key, "+" and "-" are the key of changing color. (press and hold button for one second)

2. Digital display: has 4 buttons.

MENU button: the switch of LED lights

UP/DOWN button : can change color of LED lights

ENTER button : press to spray fog, press again will stop to spray fog.

Notice 1.....

1. This fog machine should be used in dry and well-ventilated place . Please avoid any water or rain fall in the machines, if water and rain fall in, turn off the power immediately. The room for cool should be at least 30cm. Keep far away from children, fire, explosive and flammable things, and avoid scalding.
2. In the first time use, some water spray out is normal.
3. When the fog fluid is used up, you should add fog liquid in time. If the fog machine work without fog fluid, the pump and other parts will get damaged. When adding fluid, remember to turn off the power, and carefully avoid spilling over to cause short cut.
4. The fog machine should work under professional worker's supervision, please do not add flammable liquids, gas or perfume into the fog fluid tank.
5. When working, do not touch the machine and power cord..
6. When long time no use or after use, please disconnect power or unplug the power cord.

Other notice.....■

1. All fog machine will have condensation in condensation or moisture around the nozzle.
2. All fog machine are used occasionally during or after you stop using a small amount of smoke emitted.
3. All fog machine have cycles and temperature cooling to a point, the pump will automatically turn on and begin heating, until heating complete, the machine starts to spray smoke

Routine Maintenance and common faults■

Periodically clean your machine to reduce replacement parts and repair expenses.

1. The poor fog liquid can cause blockage, it is recommended to use high quality fog liquid.
2. The machine might be blocked due to high concentration fluid, not clean fluid or overheat, so regular care and maintenance can ensure long-term use. After about 40 hours continually use, please use 80% distilled water and 20% white vinegar to remove the accumulated impurities inside the heat pipe , as following:

- 1) washing the pipe in the tank and the filter head.
- 2) Pour out the fog liquid , replacing the cleaning liquid (80% distilled water and 20% white vinegar), turn on the power , keep it operating till the cleaning liquid runs out.
3. If the fog turns less, and the pump makes noise, or can not spray fog, you should turn off the power immediately and at the same time check the fluid tank, fuse, controller interface and power plug. If all of these are normal, please connect the power with the plug and try again, if the problems still can not be solved, you should contact supplier.

1500W LED FOG MACHINE MANUAL



Please read this manual carefully before using

Remote control :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.