


NO.1

If there is not enough room between pressure washer frame and pump



NO.2

make the crankshaft rotate and the keyway to the left by pulling the recoil rope slowly



NO.3

The inlet and outlet fittings of pump are straight up vertical so there is enough name.