

EPZ × GM55


Wireless Over-Ear Gaming Bluetooth Headphones

5模头戴式游戏耳机使用说明书

Wireless Over-Ear Gaming Bluetooth Headphones User Manual

■ Product Description

- ① LED Status Indicator
- ② Power Switch
- ③ Microphone On/Off Switch
- ④ BT (Bluetooth) Mode Key
- ⑤ Volume Up/Down Knob
- ⑥ Type-C Charging Port, 3.5mm Headphone Jack
- ⑦ USB Audio DAC Sound Card



■ Product Specifications / List

Equipment Name	Wireless Over-Ear Gaming Bluetooth Headphones	Detailed List	earphone 1Pcs
Charging Port	Type-C Port		3.5mm Headphone cable 1Pcs
Headphone Dimensions	166mm*89.5mm*203mm		Type-C Charging Cable 1Pcs
Headphone Weight	Approx. 290 $\pm$ 5% g (including transmitter)		Detachable Microphone 1Pcs
Headphone Battery Capacity	2000mAh		
Charging Time	Approximately 6 hours		USB Audio DAC Sound card 1Pcs
Charging Voltage	DC 5V		manual 1Pcs
			Certificate of Conformity 1Pcs

■ Power On/Off

Power On: Long-press the "Power Button" for 3 seconds to turn on; the blue light will illuminate for 1 second, and the device will begin searching for a signal.

Power Off: Long-press the "Power Button" for 3 seconds to power off; the red light will flash three times.

Automatically powers off after 5 minutes in an unpaired state.

When charging while powered on, the earbuds will not automatically shut down; you must manually force them off.

When 3.5mm headphones are plugged in while the device is powered on, the headphones automatically power off.

■ One-Touch Mute Button:



Short press to toggle the microphone on/off.

■ Volume Adjustment



In Gaming, Music, or Call Mode:

Slide towards the "+" sign to increase the volume.

Slide towards the "-" sign to decrease the volume.

■ Play/Pause/Answer/Decline



Answer/Hang Up/Play/Pause: Short press the Power button; **Reject:** Double-press the Power button.

While music is playing: Short-press the Power button to pause the music; short-press the Power button again to resume playback.

■ Wireless Connection Mode Switching



The toggle switch enables BT mode.

■ Introduction to Five Connection Modes

① Bluetooth Mode

After powering on, turn the "BT (Bluetooth) Mode Key" to enter Bluetooth mode. The blue indicator light will flash rapidly, indicating that the earphones are in Bluetooth pairing mode. Turn on the Bluetooth search function of the device, locate "EPZ GM55," and select to connect and pair. Once the pairing is successful, the blue indicator light will remain steadily lit.




 BT (Bluetooth) Mode Key



② 3.5mm Wired Connection Mode

① When powered off, plug in the Type-C to 3.5mm audio cable to switch the headphones into wired mode;


② With the device powered on, connecting the Type-C to 3.5mm audio cable automatically powers off the headphones, switching them into wired mode.



③ USB Audio DAC Sound Card Connection Mode

① While the device is powered off, connect a Type-C to 3.5mm audio adapter cable to the USB Audio DAC, then connect your headphones to enter the USB Audio DAC operating mode;

② While the device is powered on, connect the Type-C to 3.5mm audio cable to the USB Audio DAC; then, connect your headphones. The headphones will automatically power off and enter the USB Audio DAC operating mode.



Prompt

1. Please read this instruction manual carefully before using the product and keep it properly.
2. For first-time use, please fully charge this product
3. If the product is not used for an extended period (more than 3 months), please charge it
4. You must choose charging cables and power adapters produced by reputable manufacturers and certified by a third-party authoritative organisation
5. Wearing in a dry environment may cause a momentary tingling sensation in the ears due to static electricity, which is not related to the quality of the product.
6. Listening to music with headphones at high volumes for extended periods may damage your hearing.



- *请勿以任何理由拆开，维修或改装耳机，否则可能引起火甚至彻底损坏本产品。
- *请勿将设备置于温度过低或过高 (0°C 以下或者 45°C 以上) 的环境中。
- *请勿在暴雨天气下使用本产品，雷暴可能引起设备的使用异常，并增加触电的危险。
- *请避免产品与液体接触。
- *遵守所在地区或国家的相关规定，驾车时请勿使用本设备。
- *本设备并非玩具，可能包含部分小零件，请勿长时间用高音使用本产品。
- *请勿将耳机放入火中或热烤箱中，可能会导致爆炸或易燃液体或气体泄漏。
- *请勿将使用快充或者超快充的充电头充电，以免造成发热起火。
- *该设备内置电池，不能拆卸或更换，请勿自行拆卸或改装电池。



- *Do not disassemble, repair, or modify the headphones for any reason, as this may cause fire or completely damage this product.
- *Do not place the device in environments with temperatures that are too low or too high (below 0°C or above 45°C).
- *Do not use this product during thunderstorms, as lightning may cause the device to malfunction and increase the risk of electric shock.
- *Avoid contact between the product and liquids.
- *Comply with local or national regulations; do not use this device while driving.
- *This device is not a toy and may contain small parts; do not use this product at high volume for extended periods.
- *Do not place the headphones in fire or in a hot oven, as this may cause explosion or leakage of flammable liquids or gases.
- *Do not use fast charge or super fast charge adapters to charge, to avoid causing overheating and fire.
- *This device has a built-in battery that cannot be removed or replaced; do not disassemble or modify the battery yourself.

FAQ

- 1.My headphones won't turn on. How can I fix this?
Please check if the earphones have power. If they are out of power, please charge them before use.
- 2.How do I resolve the issue where an Android phone successfully connects to headphones but fails to play music?
Once the headphones have successfully connected to your mobile phone, tap the icon located to the right of the connected device's name; upon entering the settings, ensure that the "Media Audio" option is enabled.
- 3.If your Android phone successfully connects to headphones but you are unable to make calls, how can you resolve this issue?
Once the headphones have successfully connected to your mobile phone, tap the icon to the right of the connected device's name; upon entering the settings, ensure that the "Phone Audio" option is enabled.
- 4.The Bluetooth connection is unstable and keeps cutting in and out. How can I resolve this?
(1) Please minimize the distance between the headphones and the mobile phone, and avoid physical obstacles;
(2) Please stay away from environments with strong interference (Wi-Fi/GPRS) ;
(3) Please ensure that the mobile phone antenna is not obstructed.
- 5.Why do some features differ from the specifications outlined in the user manual when using third-party music playback software?
(1) Differences in headphone functionality arise from definitional distinctions between mobile applications and third-party software;
(2) We recommend using the built-in music player provided by your mobile phone's operating system.

Product Name:Wireless Over-Ear Gaming

Bluetooth Headphones model :GM55

Speaker Size:Ø 53mm

impedance:32Ω±15%

Sensitivity:110±3dB@1kHz

Frequency Response Range:20Hz-20kHz Product

Dimensions:166mm*89.5mm*203mm Product

Dimensions:Approx. 290 ± 5% g

(including transmitter)

Headphone Charging Time:Approximately 6 hours

Charging Voltage: : DC 5 V

Charging Port: Type-C Port

Protocol Support:Compliant with Bluetooth V6.0
+ BR + EDR)

Call Duration:Approx. 95 hours (at 100% volume)

Connected Standby Time:Bluetooth Mode:
Approx. 270 hours

Music Playback Battery Life:

Bluetooth Mode: Approx. 110 hours(100% Volume)

Battery Capacity:2000mAh

Charging Time:Approximately 6 hours

Operating Band:2.4-2.483GHz

Received Power: -85dBm

Wireless Transmitter Transmission Distance:10 meters (360°)

Headphone Operating Current:

Tested Bluetooth mode 18mA

(Test conditions: Music mode, 100% volume)

*The specifications and parameters represent laboratory test data and may vary depending on device settings, environmental conditions, usage scenarios, and numerous other factors.

EPZ

保修卡
warranty card

姓名 _____

电话 _____

地址 _____

型号 _____

购买日期 _____

故障原因

Name _____

Phone _____

Address _____

Model _____

Date of purchase _____

Cause of failure

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.