


AOZORA

User Manual



Quick Start Guide

- **User's Guide**
 - Please read this pamphlet carefully in order to make your tablet PC in perfect condition, to ensure safe and correct use .
 - Our company may change this mobile tablet without prior written notice and reserves the final right to interpret the performance of this tablet .
 - Due to different software and network operators, display on your tablet may be different, refer to your tablet for details .
- **Equipment part diagram and function**



1	Power key	7	Light sensor
2	Volume key	8	Speaker 2
3	Nano SIM Card & SD Card slot	9	Type-C charging hole + 3.5mm standard headphone jack
4	Microphone	10	Rear camera
5	Speaker 1	11	Flashlight
6	Front camera		



● Compliance Information

FCC NOTICE

The following statement applies to all products that have received FCC approval . Applicable products wear the FCC logo, and /or an FCC ID in the format FCC ID: **2BNQ8-K101** on the product label .

- This device complies with Part 15 of the FCC Rules . Operation is subject to the following two conditions:
 - This device may not cause harmful interference .
 - This device must accept any interference received, including interference that may cause undesired operation .
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment .

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules . These limits are designed to provide reasonable protection against harmful interference in a residential installation .

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications . However, there is no guarantee that interference will not occur in a particular installation . If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna .
- Increase the separation between the equipment and receiver .
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected .
- Consult the dealer or an experienced radio/TV technician for help .

RF warning statement:

The device has been evaluated to meet general RF exposure requirement . The device can be used in portable exposure condition without restriction .

● Certification Information



This device complies with Part 15 of the FCC Rules . Operation is subject to the following two conditions:

- this device may not cause harmful interference,
- this device must accept any interference received, including interference that may cause undesired operation .

SAR warning statement:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: Rugged Tablet (FCC ID: 2BNQ8-K101) has also been tested against this SAR limit. SAR information can be viewed on - line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested simulation typical 0mm to body. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above, use accessories should not contain metallic components in its assembly, the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Content

- **Quick Start Guide**
 - User's Guide 3
 - Equipment location map and function 3 - 4
 - Charge a battery 5 - 6
 - SIM or USIM card 7
 - Micro SD 8 - 9
 - Turn on or off the device 10
 - Initial setting 10
 - Linking to the Networks and devices 11
 - Equipment overheating condition and solution 12-13
 - Safety warning and attentions 14
- **Using the Menus**
 - Browser 15
 - Calendar 16
 - Clock 17
 - Sound Recorder 17
 - Flash Light 17
 - YouTube 18
 - Search 18
 - Email 19
 - Calculator 16
 - Camera 17
 - Downloads 17
 - Video Player 17
 - File Manager 17
 - Google Play 18
 - Settings 18-19
- **Appendix** 20
- **Compliance Information** 20-21
- **Certification Information** 21

