

xo
poppy

MAGNETIC WIRELESS
POWER BANK
5000 mAh

FOR USE WITH ALL
MAGSAFE® COMPATIBLE DEVICES



Model Number: PY-PBK5M

ITEMS INCLUDED:


- (1) X MagSafe® Compatible Power Bank (5000 mAh)
- (1) X Charging Cable
- (1) X Instruction Manual

PRODUCT OVERVIEW:

This MagSafe® Compatible Power Bank is designed to conveniently charge your phone either wirelessly or with a charging cable.

Built-in magnets securely attach the power bank to MagSafe® compatible devices for easy, on-the-go charging.

PRODUCT DETAILS :



KEY FEATURES:

- 5000 mAh battery capacity
- Wireless MagSafe® charging
- USB-A output (5V)
- USB-C input/output (5V)
- Micro-USB input (5V)
- LED indicator light

PORTS & COMPONENTS:

- Magnetic Ring–Aligns with MagSafe® compatible devices
- Indicator Light–Shows charging and battery status
- USB-C Port–Input/output charging
- Micro-USB Port–Input charging
- USB-A Port–Output charging

CHARGING THE POWER BANK:

1. Connect the charging cable (only the included USB-C charging cable) to the USB-C or Micro-USB input port on the power bank.
2. Plug the other end into a wall charger or power source.
3. The indicator light will turn on while charging and will let you know when the power bank is fully charged.

Tip: For best performance, fully charge the power bank before first use.

CHARGING YOUR DEVICE:

You can charge your phone in two easy ways:

Option 1: Wireless (MagSafe® Charging)

1. Turn on the power button.
2. Place the power bank against the back of your MagSafe® compatible phone.
3. The magnets will automatically align and attach securely.
4. Charging will begin automatically.
5. Check your phone screen for the charging icon to confirm charging.

Note: Your device must support MagSafe® technology for wireless charging.

CHARGING YOUR DEVICE CONT:

Option 2 : Cable Charging

1. Plug your device's charging cable (not included) into the USB-A or USB-C output port on the power bank.
2. Connect the other end to your device.
3. Unplug once your device is fully charged.

SAFETY & CARE INSTRUCTIONS:

Please follow these guidelines to ensure safe and proper use:

- Use the power bank in open, ventilated areas only.
- Do not place the power bank in pockets, bags, or enclosed spaces while in use.
- Keep away from heat, direct sunlight, fire, and hot environments.
- Do not drop, puncture, crush, or expose the power bank to strong impacts.
- If the power bank becomes hot, smells unusual, looks damaged, or behaves abnormally, stop using it immediately.
- Do not disassemble, modify, or attempt to replace any part of the battery.
- Keep the power bank dry at all times. Do not expose it to water or moisture.
- Only charge using the recommended ports and cables.

STORAGE & DISPOSAL:

- For long-term storage, charge the battery for about 1 hour before storing.
- Never dispose of batteries in household trash.
- Always recycle batteries at an approved local battery recycling center.

LEGAL:

This battery is meant for use only in conjunction with the appropriate mobile device. Please consult your device packaging to determine whether this battery is compatible with your particular mobile device. Manufacturer is not responsible for any damage to any mobile device incurred through the use of this product.

Manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this battery in conjunction with any device or accessory other than the appropriate mobile device for which this battery is designed. Manufacturer will not be responsible for any damages you or any third party may suffer as a result of misuse of this battery as outlined above. If you are responsible for battery use with an unintended mobile device and damages result from such use, you agree to indemnify Manufacturer for any resulting injuries to any third parties).

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

XOPOPPY® COPYRIGHT ALL RIGHTS RESERVED.
XOPOPPY® is an innovative brand of BH Brand Holding LLC. No portion of this design may be reproduced without express written permission. Other trademarks and trade names are those of their respective owners. All rights reserved. Distributed by Truststone Group LLC, 1359 Broadway, New York, NY 10018.

Please visit us at www.truststonegroup.com

FCC ID: 2BBPL-PYPBK5M

MADE IN CHINA

