
AIR PURIFIER

USER MANUAL

- High Clean Air Delivery Rate
- Double Sided Filtration
- PM 2.5 Sensor
- Low Noise Level
- Child Lock



CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.

www.mookashops.com

support@mookashops.com

1-855-666-9955

DIRECTORY

IMPORTANT SAFEGUARDS ---------- 01

ATTENTION ---------- 05

PRODUCT TECHNICAL FEATURES ---------- 06

PRODUCT OVERVIEW ---------- 07

PARTS TO INTRODUCE ---------- 09

OPERATION INSTRUCTIONS ---------- 10

INSTRUCTIONS FOR USE ---------- 12

TROUBLESHOOTING ---------- 19

PARAMETERS OF THE UNIT ---------- 20

1 IMPORTANT SAFEGUARDS

READ AND SAVE THESE INSTRUCTIONS

1. When servicing or replacement of a component in an appliance requires the removal or disconnection of a safety device, the safety device is to be reinstalled or remounted as previously installed.

2. Warn the user to unplug or disconnect the appliance from the power supply before servicing.

3. Use this product to reduce the risk of fire, electric shock, or personal injury, and to facilitate cleaning and user maintenance.

4. To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).

5. Wiring instructions provided with an appliance can not conflict with any requirement in this standard or in the National Electrical Code, ANSI/NFPA 70.

IMPORTANT SAFEGUARDS 2

In order to prevent harm or damage happened to users or others, be sure to comply with the requirement as below:

WARNING/ATTENTION

WARNING

It reminds that misusing or mishandling may cause death.

ATTENTION

It reminds that misusing or mishandling may cause hurt.




FORBID



FORCE

3 IMPORTANT SAFEGUARDS

⚠ WARNING



Please supervise your children and avoid them from touching or using machine.



AVOID WET

Do not connect or disconnect the power with wet hand.
It may cause electrical shocking.



NO DISASSEMBLE

Do not disassemble, repair or reconstruct.
It may cause fire or damage.
Please contact customer service for replacement.



FORBID

Do not use over-limit sockets or wiring connectors. Please use the rated voltage.
It may cause a fire.




FORBID

Do not repair it when the cord or plug is damaged.
It may cause short circuit, electric shocking or fire. Please contact customer service for replacement.

IMPORTANT SAFEGUARDS 4



Do plug the power into the socket completely.
It may cause fire because of heating or electrical shocking.
Do not use the damaged plug or loose socket.



AVOID WET

Avoid any water on the surface of the unit.
It may cause short circuit or electrical shocking.




DISCONNECT POWER

The appliance must be disconnected from the supply mains before cleaning or other maintenance.
Otherwise the unit may start working in a sudden which may cause electrical shocking or hurt.




If there is dust on the plug, it may weaken the insulation and even cause a fire.
Take out the plug and clean it with dry cloth.
Please remove the plug from the socket if not using for a long period.



Do not insert any metal objects into the unit.
It may cause hurt or electric shocking.

5 ATTENTION


ATTENTION




Do not use in the room with a gas stove.
It may cause hurt because the machine is not a ventilator.




Do not place the unit near fires.
It may cause fire.




Do not use in the watery or high temperature room such as the bathroom etc.
Otherwise it may cause creepage, electric shocking or fire.



Please hold the plug instead of the cord when unplug the power.
Otherwise it may cause short circuit, breaking of the cord, electric shocking or fire.



Keep away from alcohol, organic impregnant.
It may cause cracking, short circuit, electric shock, injury or fire.



Please ventilate timely when used with fire in the room.
Please remove the plug from the socket if any conditions as below:


- If all switches do not work
- If the power cord or plug hot singularly
- If any peculiar smell, exceptional noise or vibration
- Any other abnormality or failure

If the power cord is damaged,please contact our customer service for replacement.
Do not change or repair it by yourself.

PRODUCT TECHNICAL FEATURES 6

The Double Sided filter is composed of pre-filter, HEPA layer and activated carbon layer.Can filter and purify dust, pollen and smoke in the air.

DIAGRAM OF PURIFICATION




FILTER PARAMETERS

Item name	Dimensions	Life time
High efficiency HEPA filter	288*270*30（mm）	1440H

7 PRODUCT OVERVIEW


APPEARANCE DIAGRAM





PRODUCT OVERVIEW 8

Installation manual for the legs


Put the❶ screw in the ❷ leg base hole, align with the❸ base mounting hole, tighten the screw. Install the rest of the legs in the same way.







9 PARTS TO INTRODUCE



OPERATION INSTRUCTIONS 10

PLACEMENT


◆ Make sure the appliance is placed at least 30cm away from any wall or piece of furniture.Do not position the appliance directly under furniture or objects that may obstruct the exhaust air flow.
◆ Do not use the appliance near any source of heat.

REPLACE THE FILTER


◆ Replace the filter and reset
When the accumulated air purifier running time reaches 1440 hours, the "RESET" indicator lights red and blinks. Replace the filter with a new one.
After replacing the filter, long press the "RESET" button for 3sec to reset the filter lifetime counter: The filter indicator will be turned off after 3sec.

POWER CONNECTION

◆ DC Voltage: 100-240V~50/60Hz
Before connecting the appliance, ensure the voltage indicated on the device matches the local power supply. Do not connect to an incorrect voltage.



Machine socket



Adapter

11 OPERATION INSTRUCTIONS


FILTER REMOVAL

Turn off and unplug the power, ❶ open the cover, ❷ remove the old filter.


FILTER INSTALLATION

❸ Remove the protective film from the new filter before installation.
❹ Install the filters element and close the cover tightly.


❶




❷



❸



❹



INSTRUCTIONS FOR USE 12

POWER

- Power on : After the power cord is pluged in, the power indicator will light up in white. Touch the "POWER" button to turn on the air purifier.
- Power off : While operating (If in Child-Lock, exit this mode first), press the "POWER" button again to shut down the air purifier.



Standby Mode




Power-on default state


13 INSTRUCTIONS FOR USE

FAN SPEED SETTING


- When the air purifier is running on press the "SPEED" button to manually adjust the fan speed, tap again and press the "L-M-H" sequence cycle, the corresponding fan speed indicator shall light up.



Low fan speed



Medium fan speed



High fan speed

INSTRUCTIONS FOR USE 14

CHILD LOCK SETTING

- Child lock on : When the air purifier is running, long press “LOCK” button for 3 seconds to lock the device from children. The Child lock indicator will illuminate, and other function buttons cannot be operated.
- Child lock off : While in locked mode, long press "LOCK" button for 3 seconds once again to unlock the device. The Child lock indicator will turn off, and other function buttons will be restored to normal operation.



Child Lock On




Child Lock Off


15 INSTRUCTIONS FOR USE

TIMER SETTING


- Set timer : While operating, press the "TIMER" button to turn on the timing function, press again for the "2H - 4H - 8H - off" sequence cycle. The corresponding timing indicator shall light up. Air purifier will automatically shut down after working to the set time and enter the standby state.



Time Setting for 2 Hours



Time Setting for 4 Hours



Time Setting for 8 Hours

INSTRUCTIONS FOR USE 16

FILTER RESET SETTING

- When the reset indicator lights up red and blinks, please replace the filter in time! (See the part "OPERATION INSTRUCTIONS" to learn how to change the filter)
- Filter reset : After filters are replaced, press and hold the "RESET" button for 3sec. Filter reset indicator shall deem, meaning that filter lifetime is now reset.



The indicator light is on



Filter lifetime is reset


17 INSTRUCTIONS FOR USE

AI/SLEEPING MODE SETTING

- Press "AI/SLP" button to switch between AI mode and Sleeping mode as: AI MODE - SLEEPING MODE - AI MODE.

- AI mode : In this mode, the air purifier fan speed automatically adjusts to the ambient air quality.
  During the normal operation, except for when the child lock feature is on, touch the "AI/SLP" button to enter the AI mode, the digital screen display "AI" for 3 seconds, and then display the PM2.5 value.

- Sleeping mode : In this mode, the air purifier runs at the most quiet fan speed and the lighting and display turns off.
  When the machine is in AI mode, touch the "AI/SLP" button again to switch to the sleeping mode, The digital screen displays "SLP" for 3 seconds before the display go off.
  When in sleep mode, press any button to wake up the sleep mode and then can switch to other modes.




AI Mode



Sleeping Mode

INSTRUCTIONS FOR USE 18




AIR QUALITY LIGHT COLOR


- The digital screen displays the current PM2.5 concentration in real time, and the displayed value is updated every 2sec.

- Light color indication：


Air Quality Indicator Chart		
PM2.5 Range	**Air Quality**	**Indicator Color**
0-75	Good	Blue
76-150	Moderate	Orange
>150	Poor	Red



Blue



Orange



Red

19 TROUBLESHOOTING

Problem	Possible Solution
Air purifier do not work	Please check if the plug is disconnected from the socket.
	Check to see if the power cord is damaged.If it is, stop using the air purifier and contact customer support.
	The air purifier may be malfunctioning, Contact customer support.
Air Quality Indicator always stays red.	If you're using an ultrasonic humidifier near the air purifier, the mist may affect the accuracy of the sensor. Avoid using an ultrasonic humidifier near the air purifier.
Air purifier makes an unusual noise.	Make sure the filter is properly in place with plastic packaging removed.
	Make sure the air purifier is operating on a hard, flat, level surface.
	Replace the filter.
	The air purifier may be damaged, or a foreign object may be inside. Stop using the air purifier and contact Customer Support. Do not try to repair the air purifier.
Poor air purification quality.	Tap speed button to increase the fan speed.
	Make sure no objects are blocking the front, sides, or top of the air purifier.
	Make sure the filter is removed from its packaging and properly in place.
	Close doors and windows while using the air purifier.
	If the room is too larger, air purification will take longer.
	Replace the filter.

Note: If your problem is not listed,please contact customer support.

PARAMETERS OF THE UNIT 20

PARAMETERS OF THE UNIT

Model	HKB320F
Adapter power	Input 100-240V~, 50/60Hz, 1.5A max.Output: DC 24V, 2A
Power consumption(w)	36W
Net Weight	3.2Kg
Dimensions	298x176x408（mm）

PACKING LIST

Name	Quantity
Air purifier	1
Adapter	1
Legs / Screws	4 / 6
User manual	1

mooka

Beyond Elegance

www.mookashops.com

support@mookashops.com

1-855-666-9955

Made in China