


PoE Security Camera System Quick Start Guide

Version: POETZ50213


English



Thank you for purchasing our products. Be sure to read this instruction manual thoroughly before use the product appropriately

1. After receiving the product, Please double check product parts. Contact our customer service if it has damaged or missing parts, wrong item, etc.
2. We recommend that you do the installation work after confirming that the product is working properly. (Make sure the camera image is properly displayed on the monitor or HD TV.)
3. Before installation, please scan the following link or QR code to watch the installation demo video on Youtube.

POE NVR System



<https://www.ohwoai.net/pages/jheqfgrgruw>

Monitor POE NVR System



<https://www.weilailifetech.com/pages/pmaygn6ggro>

4. Cannot get any display on home monitor from the NVR system. There is NO Picture if All-in-One Computer or Laptop is Connected to NVR Box Directly. Please DON'T Do That. The default output resolution of the NVR system may not be compatible with some monitors. If the image does not display properly when connected to monitor, please refer to "14. FAQ 12".
5. To make sure the safety of your system, please change the password on your monitor screen. Right Click on the home screen of your monitor, navigate to System setup>Account/APP>Modify Password>Create a password and type it in the field (Keep it short. 8 characters Max.)> repeat new password>Click ok. Be sure to remember your password.
6. Depending on the production time, the product information in this manual may differ from the actual product. Note that it matches the real product.

Safety Notice

1. Please do not store or use the NVR in a place that is hot, humid, dusty or oily, or subject to vibration.
2. Please place the NVR horizontally and install it in a well-ventilated place. Do not block the ventilation holes.
3. Please do not place anything on the NVR. Be careful not to get wet.
4. Please note that if the ambient temperature and humidity are high, water vapor may appear inside the product due to the temperature difference.
5. Check the supply voltage. Please do not use voltages other than the indicated power supply voltage. Keep power cords away from heating equipment.
6. If dust collects inside the device, it may cause malfunction. We recommend that you clean it regularly. Be sure to turn off the power when cleaning this product.
7. For your safety, please be sure to turn off the power when moving or not in use for a long time.
8. If you find abnormal conditions such as smoke and odor, please stop using it immediately and turn off the power.

Before setting camera system, please visit our website:
www.weilailifetech.com to watch demo videos. You can also scan the QR code below to get our after-sales support.



Facebook Online Service Robot

info@weilailifetech.com



Setup Demo Video Or Visit

1. Product Parameters

POE Security NVR Specification	
Name	WEILAILIFE POE NVR
Video input	4ch/8ch/16ch HD 5.0MP/8.0MP/12MP
HDMI Output	1ch Resolution 1024x768, 1280x1024, 1366x768, 1440x900, 1920x1080, 4K/30Hz
VGA Output	1ch Resolution 1024x768, 1280x1024, 1366x768, 1440x900, 1920x1080
Resolution	HD 5.0MP/8.0MP/12MP
Playback	4 channel
Recording	Manual, time, motion detection, alarm
Storage	1 SATA
Storage capacity	MAX 6TB for each HDD
Network interface	1 RJ45 100M
USB interface	2 USB2.0
Power consumption	15W without hard drive
Working temperature	-4 F -- +140 F
Working humidity	10%--90%RH
Dimension (mm)	258mmx210mmx42mm
Power	DC 48V 2A

POE Camera Specification		5.0 Megapixel	8.0 Megapixel	12.0 Megapixel
Technical Parameters	Model	5.0 Megapixel	8.0 Megapixel	12.0 Megapixel
	Sensor	1/3 Progressive Scan Sensor		
	Signal System	PAL/NTSC		
	Resolution	2560x1960 16:9	3840x2160 16:9	4000x3000 16:9
	OSD	Date Time & Title(NVR system can change Title name)		
	Day & Night	IR cut filter with auto switch		
General Specification	Mirror/Flip	On / Off(NVR system setup)		
	Interface	RJ45		
	Anti-thunder Level	Standard IEC61000-4-5		
	Working Temperature/Humidity	-4 F to +140 F / 30% to 80% RH		
	Storage Temperature/Humidity	-20 F to +180 F / 20% to 90% RH		
	Power Input	DC12V-1A		
Power consumption	≤6W			
Size	66*180mm			

2. System Components

POE camera X 2/4/8/16

POE 8 Channel Network Video/Audio Recorder X 1

POE NVR power supply 48V DC X 1

Ethernet cable for cameras 18.2 meters (60ft) X 2/4/8/16

Network cable 3 feet X 1

Waterproof connector for network cable X 2/4/8/16

Camera screw pack X 2/4/8/16


Hard Drive(pre-install, if you purchase kit with hard drive) X 1

HDMI cable & USB mouse X 1


Manual X 1

Sticker X 4/8

The Appearance of The Product will Vary According to The Configuration



3. Installation Settings




3.1 Connect NVR to AC power adapter.

Note:
NVR AC power adapter is 48V 2A. Please make sure the power connect is right. Power adapter supports input from AC 110-240V.

3.2 Connect NVR to monitor with HDMI / VGA cable


Note:
Please do not use laptop monitor or all-in-one PC as camera system monitor. TV or PC monitor would be a perfect choice. Please use a HDMI cable or a VGA cable to connect NVR to monitor. Switch TV to HDMI mode or VGA mode.

3.3 Connect the mouse to the USB port at the back of NVR



Interface description

WAN port: Connects to the Internet.
VGA port: Hooked up to liquid crystal display.
HDMI port: Connects to high-definition TV.
USB port: Connects to mouse or USB Device.
NVR power input: 48V 2A.
RJ45 port: For matching code and wired connection between IPC camera and NVR. Our POE NVR kit is already matched code before delivery. If you need to re-match code, please refer to how to add IP camera(as shown in 3.6).




info@weilailifetech.com

3.4 NVR

1. Connect power supply to NVR for power on
2. Use a network cable to connect the base NVR to a router that can access the Internet;

3.5 Manually Add Camera

1. On the main interface, move the mouse down to reveal the toolbar and click the '+' button.
2. Add the search one by one, then click 'Add All'.



3.6 App Installation

3.6.1 APP Download and Installation

- Please search "Honestview" on APP Store or Google Play, Backup APP "Eseecloud" or scan the QR code below to install the APP.
Note: For iOS system, it requires iOS9.0 version or above. For Android, Android 5.1 or above.





Honestview APP



Backup APP 'Eseecloud'


1. When NVR is powered on, connect NVR to internet router by Ethernet cable.
2. Open the APP and click on the "+" in the upper right corner to enter the scan code interface;




info@weilailifetech.com

3.6.2 Account login

- Account login: Click Register to register an account to log in the APP for the first time log in. Please use cellphone number or email address as USERNAME, and put your password which is created when register APP account.




3. Scan the QR code on NVR and add device according to instruction in the APP. The cameras matched into the system previously will be display on the APP.






www.weilailifetech.com

4. In the add device interface, click 'Add';
5. Set a name for the device to add successfully.




3.7 Notification, Preview and Playback


1. Click the push information or "info" button to view the alarm information of the system.
2. Click 'NEWS' to view motion detection alarms from the system.




3. Click the playback view the video which is on the device.



Alarm information



storage playback



Video playback

HERE FOR YOU 24/7

Have an issue?

Before you return your product or write a review please contact our dedicated customer service team directly.

We guarantee a professional service that can fix your issue in a faster, more efficient manner.

Phone	+1(904)717-0799 (EST Monday to Friday 9:00am - 5:00pm)
Website	www.weilailifetech.com
Email	info@weilailifetech.com
Address	116-117 2012 Jaffa Drive, St Cloud, FL, 34771 USA

info@weilailifetech.com

