

## Package Contents

- (1) Sub-woofer Cabinet
- (2) Satellite Speakers
- (1) User Manual
- (1) 3.5mm RCA Cable
- (1) Remote Control

## Features

- 2.1 channel multimedia speaker for computer, gaming or home system
- Full audio spectrum performances, ideal for your favorite entertainment such as MP3, MP4, CD/DVD movies and digital playbacks
- Specially designed woofer cabinet for bass and resolution

## Front Panel



1. INPUT: Press to choose between different modes: USB, SD, AUX and BT

2. NEXT: Press to go to next track in USB, SD and BT mode
3. SD CARD INPUT
4. USB INPUT
5. VOL +: Press Vol+ to increase the volume
6. PREVIOUS: Press to go to previous track in USB, SD and BT mode
7. PLAY/PAUSE: Press to play or pause the track in USB, SD and BT mode

## Rear Panel



1. BASS CONTROL KNOB
2. AUDIO INPUT
3. AUDIO OUTPUT
4. POWER ON/OFF SWITCH
5. AC IN/POWER CORD

## Remote Control Function



- **POWER:** Turn on or Stand-by the system
- **INPUT:** Choose between modes: USB/SD/AUX/BT. When in BT mode the LED display will flash to search for the Bluetooth capable device. Turn on your device and connect your device to the speaker
- **0-9 NUMBERS:** use numbers to choose tracks
- **VOLUME -/+:** Press Vol+ to increase volume or Vol- to decrease volume
- **▶||** : Play or Pause
- **◀◀** : Previous Track
- **▶▶** : Next Track
- **MUTE:** Press to suspend all sound
- **EQ:** Press to scroll through equalizer presets to find your preferred sound
- **10 -/+:** Go forward or back 10 tracks in USB/SD mode


## System Connections



1. Insert all satellite speaker cables into their respective output sockets located at the rear of the sub-woofer (FL: Front Left Speaker, FR: Front Right Speaker)
2. To connect a mobile device or laptop etc. connect the 3.5mm to RCA cable into the respective input sockets
3. Once you've connected the system in your preferred method, insert the power plug into ~ 110V wall outlet and switch power to ON.

**NOTE:** Please avoid leaving magnetic objects near the system

## Positioning the Speakers



\***Sub-woofer** can go anywhere on the floor of the room (there is no directional requirement for bass effect)

\***FL and FR** speakers should be in front of the listener facing inward toward the center

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.