

**Model:** GS778BK | **Brand:** gorsun | **Type:** Lightweight Stereo Wired Over-Ear Headphones

## Overview

The gorsun Kids Headphones are wired over-ear headphones designed for children aged 3–15. They feature an adjustable headband, cushioned earpads, and a lightweight construction for comfortable daily use with smartphones, tablets, computers, and other devices with a standard 3.5 mm audio jack.



The headphones are built with food-grade materials and a tangle-free cord. The headband has marked spots to help identify the left (L) and right (R) earpieces.

## What's in the Box

- 1x gorsun Kids Headphone (GS778BK)
- 1x User Manual
- 1x Product Certificate

## Features

### Design and Build

- **Adjustable Headband:** The headband can be extended to fit different head sizes.
- **Soft Cushioned Earpads:** Padded earpieces provide comfort during extended use.
- **Lightweight Construction:** Easy for children to carry and wear.
- **Durable Materials:** Made with food-grade plastic and a twistable, bendable, stretchable frame.
- **Tangle-Free Cord:** 1.2 m (approx. 4 ft) cable resists tangling.

### Audio and Connectivity

- **Driver Diameter:** 40 mm
- **Sensitivity:** 103 dB
- **Impedance:** 32 Ohm
- **Frequency Response:** 20 Hz – 20 kHz
- **Plug Type:** 3.5 mm gold-plated stereo jack
- **Compatibility:** Works with all devices that have a 3.5 mm headphone output (smartphones, tablets, laptops, MP3 players, etc.).

### Safety and Child-Friendly Design

- No sharp corners on the earpieces or headband.
- Marked L/R indicators on the headband help children correctly identify left and right.
- Recommended for ages 3 and up.



## Specifications

<b>Brand</b>	gorsun
<b>Model Number</b>	GS778BK
<b>Color</b>	Black (also available in Blue, Orange, Pink, White, Yellow)
<b>Ear Placement</b>	Over Ear
<b>Form Factor</b>	On Ear
<b>Driver Diameter</b>	40 mm
<b>Sensitivity</b>	103 dB
<b>Impedance</b>	32 Ohm
<b>Frequency Response</b>	20 Hz – 20 kHz
<b>Plug Type</b>	3.5 mm gold-plated stereo jack
<b>Cord Length</b>	1.2 m (approx. 4 ft)
<b>Connectivity Technology</b>	Wired
<b>Noise Control</b>	Passive (no active noise cancellation)
<b>Audio Driver Type</b>	Dynamic Driver
<b>Enclosure Material</b>	Plastic (food-grade)
<b>Additional Features</b>	Adjustable, Foldable, Soft Cushions, Tangle-Free Cord, Stereo
<b>Age Range</b>	3 – 15 years
<b>Warranty</b>	1 Year

## Use Guide

### Connecting the Headphones

1. Locate the 3.5 mm headphone jack on your device (smartphone, tablet, computer, etc.).
2. Insert the gold-plated plug of the headphone cable firmly into the jack.
3. Ensure the plug is fully inserted for proper audio output.

## Adjusting the Fit

1. Place the headphones over the child's head with the headband resting on top.
2. Extend or shorten the headband by sliding the earpieces up or down until the fit is snug but comfortable.
3. Check that the earpads fully cover the ears without pressing too tightly.
4. Use the L (left) and R (right) markings on the headband to ensure correct orientation.



## Using the Headphones

- Play audio from your connected device. Volume is controlled by the source device (no inline remote on the cable).
- The headphones deliver stereo sound. Ensure the audio source is set to stereo output for best experience.
- To store or transport, fold the earpieces inward (the headphones are foldable).

## Safety Information

Recommended for children over 3 years old. Adult supervision is advised during first use. Do not expose the headphones to liquids or extreme temperatures.

## Product Video

The following video demonstrates the product in use and provides setup guidance.

Your browser does not support the video tag.

*Video: The video showcases the product in use and guides you through product setup.*

## Troubleshooting

<b>No sound from one side</b>	Check that the plug is fully inserted. Test with another device. If the issue persists, the audio source may be set to mono – switch to stereo.
<b>Sound is distorted or too quiet</b>	Increase volume on the source device. Ensure the headphone plug is clean and free of debris.
<b>Headphones do not fit comfortably</b>	Adjust the headband length. The headphones are designed for children; if too tight, extend the headband fully.
<b>Cable tangles easily</b>	The cord is designed to be tangle-resistant. Store the headphones folded and avoid wrapping the cable tightly around the device.

## Warranty and Support

The gorsun Kids Headphones come with a **1-year warranty**.

For support, contact the manufacturer:

- **Manufacturer:** Dongguan Gorsun Electronic Co., Ltd
- **Warranty Description:** 1 Year

For additional assistance, refer to the product manual included in the box or visit the gorsun store on Amazon.

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.