


Overview

The miisso 6000mAh Ultra Slim Power Bank is a portable charger designed for convenience and portability. It features built-in cables, eliminating the need to carry separate charging cords. Its credit card-sized body makes it easy to slip into a pocket or handbag.



The power bank includes a built-in USB-C cable and a Lightning cable, along with a USB-A output port, allowing you to charge up to three devices simultaneously.



1. Button
2. LED Light
3. USB Output
4. Micro USB Input
5. Type-C Input
6. Lightning Cable Output
7. Type-C Cable Output

Features


Built-in Cables

The power bank has a built-in USB-C cable and a built-in Lightning cable. These cables are stored within the unit and can be pulled out to charge compatible devices directly.



Credit Card Size and Slim Design

Measuring approximately 4.13 x 2.6 x 0.51 inches and weighing only 4.32 ounces (122g), the power bank is designed to be as compact as a credit card. This makes it easy to carry in a pocket, wallet, or small bag.



6000mAh Battery Capacity

The internal 6000mAh lithium-polymer battery provides enough power for approximately one full charge for most smartphones. It is suitable for daily use and travel.



Charge Three Devices Simultaneously

The power bank features two built-in cables (USB-C and Lightning) and one USB-A output port. This allows you to charge up to three devices at the same time.



Input and Output Ports

- **Input:** USB-C and Micro USB ports for recharging the power bank itself.
- **Output:** Built-in USB-C cable, built-in Lightning cable, and a USB-A port.

Recharging the power bank takes approximately 2.5 to 3 hours using a 2A charger.

What's in the Box

- 1x miisso 6000mAh Power Bank (Snow White)
- 1x USB Cable (for recharging the power bank)
- 1x User Guide

Product Specifications

Specification	Details
Brand	miisso
Model Number	5K95
Battery Capacity	6000mAh
Micro input	5V/2.0A
Type-C Input	5V/2.0A
Type-C Cable Output	5V/2.0A
Lightning Cable Output	5V/2.0A
USB Input	5V/2.1A
Input Charging time	~3-4 hours
Recycling time	>500times
Battery Cell Type	Lithium Polymer
Connector Type	USB Type-C, Lightning, USB-A
Voltage	5 Volts
Power Source	Battery
Special Feature	Built-in Cable
Color	Snow White
Item Weight	4.32 ounces (122g)
Item Dimensions	4.13 x 2.6 x 0.51 inches
Manufacturer	Shenzhen Weilaishenniao Technology Co., Ltd.

Use Guide


Power Indicator

Press the power button and check the four power lights which can be showed how much power is left with the power bank, as below sheet:

Power Indicator	One light on	Two light on	Three light on	Four light on
Battery status	≤25%	25%~50%	50%~75%	75%~100%

Charge for Power Bank


Put the enclosed USB of charging cable in power supply equipment, like **AC adapter (1)** or **computer USB (2)**, plug into input of power bank.



1. Connect the provided USB cable to the power bank's input port (USB-C or Micro USB).
2. Connect the other end of the cable to a USB wall charger (2A recommended) or a computer's USB port.
3. The power bank will begin charging. A full charge takes approximately 2.5 to 3 hours.

Note: The power bank does not have a power indicator light visible in the provided images. Charging status is indicated by the connected device.

Power bank charge for other devices



Recharge the Apple phone and Android phone.

Charging Your Devices

1. Pull out the appropriate built-in cable (USB-C or Lightning) for your device, or use the USB-A port with your own cable.
2. Connect the cable to your device. The power bank will automatically start charging.
3. To charge multiple devices, connect up to three devices using the two built-in cables and the USB-A port simultaneously.



Compatible Devices

This power bank is compatible with a wide range of smartphones, including:

- **iPhone:** iPhone 16 Pro, 16 Pro Max, 16, 16 Plus, 15, 15 Plus, 15 Pro, 15 Pro Max, 14, 14 Pro, 14 Pro Max, 14 Plus, 13, 13 Pro, 13 Pro Max, 13 Mini, SE, 12, 12 Pro, 12 Pro Max, 12 Mini, 11, 11 Pro, XS, XS Max, 8, 8 Plus, 7, 6, 5, and more.

- **Samsung:** Galaxy Z Fold 6, Z Flip 6, Z Fold 5, Z Flip 5, Z Fold 4, Z Flip 4, S24, S24 Ultra, S24+, S23, S23 Ultra, S23+, S22, S22 Ultra, S22+, S21, S21 Ultra, S21+, C55, A55, A54, A53, A52, and more.
- **Other Android Devices:** Google Pixel, Motorola, LG, OnePlus, and other USB-C or Lightning compatible devices.

Important Usage Notes

- The power bank is designed for indoor and outdoor use.
- Use only the provided cable or a certified 2A charger to recharge the power bank.
- Do not expose the power bank to extreme temperatures or moisture.
- If the power bank is not used for an extended period, recharge it every three months to maintain battery health.

Safety and Care

Warning: To prevent fire or injury, do not disassemble, crush, or puncture the battery. Do not short-circuit the output terminals.

- Keep the power bank away from children and pets.
- Do not use the power bank if it appears damaged or swollen.
- Disconnect devices after charging to conserve battery life.
- Store in a cool, dry place.

Troubleshooting

Problem	Cause	Solution
Indicators can't display a full charge status after a long time of charging the product.	1. Not enough charging time. 2. Adapter or product malfunction.	1. Charge the product for 12 hours. 2. Consult the distributor or the after-sale service.
The remaining power of the product cannot be detected.	1. No remaining power. 2. Power button or indicator malfunction. 3. Power failure of the product.	1. Consult the distributor or the after-sale service. 2. Charge the product again.
The product cannot charge other devices.	1. Low power of the product. 2. No power transmission in the USB cable or the adapter. 3. Improper choice of adapters. 4. The power management system of the product prohibits charging for the device.	1. Charge the product again. 2. Change the USB cable or the adapter. 3. Look for a proper connector suitable for the interfaces of the product. 4. The product is incompatible with the device.
The product can charge other devices but can't fully charge them.	The battery of the product is used up.	Charge the product.
When charging other devices with the remaining power, the product suddenly stops working or fails to display any power.	External short circuit or overload of the product leads to an automatic shutdown for self-protection.	1. Charge the product again. 2. Consult the distributor or the after-sale service.

Usage Recommendations

1. For optimal performance, we recommend using an adapter with **45W or lower** when charging the power bank. Higher wattage adapters may cause the power bank to malfunction.
2. If the built-in cable fails to charge your phone, please clean the charging connector with a dry tissue or cloth, then attempt to charge your phone again.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.