

Model: B011 | **ASIN:** B0C6X7JBDV

Overview

The LAREX Fast Bottle Warmer is a multifunctional baby bottle warmer designed to heat breast milk, formula, and baby food. It uses a gentle water bath to warm bottles evenly, preserving nutrients while preparing milk quickly. The device features a clear LCD display and knob controls for setting time and temperature, along with multiple safety functions including automatic shut-off and power-off protection.



This 10-in-1 warmer combines several feeding functions into one appliance, including fast warming, keep warm, thawing, food heating, and steaming. It is compatible with various bottle types and sizes, making it suitable for most standard baby bottles.

Features

10-in-1 Functionality

The bottle warmer provides multiple functions to cover various feeding needs:

- **Fast Warming:** Heats milk in 2-7 minutes using a gentle water bath
- **24-Hour Keep Warm:** Maintains desired temperature for extended periods
- **Thaw:** Safely thaws frozen breast milk
- **Food Heating:** Warms baby food jars or containers
- **Steam:** Provides steaming function for certain items
- **Timer:** Precise timer for accurate heating control
- **Temperature Setting:** Adjustable temperature control
- **Auto Shut-off:** Automatically powers off after heating cycle
- **Power-off Protection:** Shuts down if water runs dry
- **Memory Function:** Remembers last used settings

Control Panel and Display

The device features a clear LCD display and knob buttons for intuitive operation. The display shows current settings including time and temperature. The knob controls allow for precise adjustment of heating parameters.



Bottle Compatibility

The warmer is designed to accommodate various bottle types:

- Wide-neck and narrow-neck bottles
- Glass and plastic bottles
- Compatible with both breast milk and formula

Safety Features

- **Automatic Shut-off:** Prevents overheating and ensures safe operation
- **Power-off Protection:** Automatically shuts down if water inside the warmer dries out
- **BPA-Free Materials:** Safe for baby use

Memory Function

The memory function stores your last used temperature and timer settings. This allows for quick and consistent operation without needing to reconfigure settings each time.

Portability

The compact and lightweight design makes it easy to carry and store. Product dimensions are 10.12 x 6.38 x 6.06 inches and it weighs only 1.61 pounds.

Use Guide

Before First Use

1. Remove all packaging materials from the device
2. Wipe the exterior with a soft, damp cloth
3. Hand wash any removable parts with mild soap and water
4. Place the warmer on a flat, stable, heat-resistant surface
5. Ensure the power cord is accessible and not damaged

Basic Operation

Follow these steps to warm a bottle:

1. Fill the warmer with water to the appropriate level
2. Place the bottle securely in the warmer
3. Use the knob to set the desired temperature
4. Set the timer for the desired heating duration
5. Start the warming cycle
6. Wait for the cycle to complete or for the automatic shut-off
7. Remove the bottle carefully and test the milk temperature before feeding

Note: Always test the milk temperature on your wrist before feeding your baby to ensure it is not too hot.

Setting Temperature and Timer

The device uses a clear LCD display and knob buttons for setting parameters:

- Turn the temperature knob to adjust the desired warming temperature
- Turn the timer knob to set the heating duration
- The LCD display shows the current settings
- The memory function will recall your last used settings for convenience

Using the Memory Function

1. Set your preferred temperature and timer settings
2. Complete a warming cycle
3. The device will remember these settings for the next use
4. On subsequent uses, the device will automatically display your last used settings

Warming Different Types of Bottles

The warmer is compatible with various bottle types:

- **Wide-neck bottles:** Place directly in the warmer
- **Narrow-neck bottles:** Place directly in the warmer
- **Glass bottles:** Ensure the bottle is at room temperature before placing in the warmer
- **Plastic bottles:** Check that the bottle is BPA-free and heat-safe

Heating Baby Food

1. Place the food container in the warmer
2. Set the temperature to the appropriate level for food
3. Set the timer based on the amount of food
4. Stir the food thoroughly after heating to distribute heat evenly
5. Test the temperature before serving

Thawing Frozen Milk

1. Place the frozen milk container in the warmer
2. Select the thaw function if available
3. Set a lower temperature to gently thaw the milk
4. Monitor the process to avoid overheating
5. Swirl the milk gently after thawing to mix separated layers

Keep Warm Function

The 24-hour keep warm function maintains the desired temperature for extended periods. This is useful for:

- Preparing bottles in advance
- Night feedings
- Maintaining temperature during travel

Cleaning and Maintenance

Important: Always unplug the device and allow it to cool completely before cleaning.

- **Care instructions:** Hand wash only
- Wipe the exterior with a soft, damp cloth
- Clean the interior with a soft cloth and mild soap
- Do not immerse the device in water
- Do not use abrasive cleaners or scouring pads
- Dry all parts thoroughly before storing

Safety Precautions

- Always use the device on a flat, stable surface
- Do not operate the device without water
- Keep the power cord away from water and heat sources
- Do not touch hot surfaces during operation
- Keep the device out of reach of children
- Do not use the device for purposes other than its intended use
- If the device malfunctions, discontinue use and contact support

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Power connection issue	Check power cord and outlet connection
Device shuts off during operation	Water level too low	Add water to the appropriate level
Milk not warming evenly	Insufficient water or incorrect placement	Ensure proper water level and bottle placement
Settings not being remembered	Power interruption	Reset settings after power is restored

Technical Specifications

Product Dimensions	10.12 x 6.38 x 6.06 inches
Item Model Number	B011
Material	BPA Free
Care Instructions	Hand Wash Only
Item Weight	1.61 pounds
ASIN	B0C6X7JBDV

Product Videos

The following video demonstrates the product in use and provides setup guidance:

Your browser does not support the video tag.

Video demonstrates the product in use and guides you through product setup.

Additional Video Demonstrations

The product page includes multiple videos that showcase the product in use, guide through setup, compare multiple products, and show the product being unpacked.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.