

The Ambrane MiniVac 01 is a portable, cordless, handheld vacuum cleaner designed for cleaning car interiors and other small spaces. It is lightweight, rechargeable via USB Type-C, and features a HEPA filter.



Package Contains

The main unit consists of the vacuum body, motor, dust collection chamber, HEPA filter, and a power button. The charging cable has an integrated LED indicator. 1 N MiniVac-01 Portable Vacuum Cleaner

- 2 N Product Attachments
- 1 N LED Indicator Charging Cable
- 1 N Rating Card

Product Overview



How to Use

- **Power On:** Press the power button once to activate the vacuum cleaner.
- **Power Off:** Press the power button again during operation to turn off the machine.

Note: Pause usage after 20 minutes of continuous operation and resume after a 5-minute break.

Before First Use

1. Unpack the vacuum cleaner and ensure all components are present.
2. Fully charge the device using the provided USB Type-C cable before initial use.

Charging the Vacuum

1. Connect the provided USB Type-C cable to the charging port on the vacuum cleaner.
2. Connect the other end of the cable to a standard USB power adapter or a computer USB port.
3. The LED indicator on the cable will light up, showing the charging status. Refer to the indicator's behavior for battery level information.
4. A full charge takes approximately 3.5 hours and provides up to 20 minutes of use.

Operating Instructions

1. Ensure the vacuum cleaner is fully charged before the first use. Plug the charging cable directly into the back of the unit to charge.
2. The battery requires approximately 3.5 hours for a full charge.
3. Enjoy up to 20 minutes of continuous usage in working mode.
4. Remember to empty the dust container after each use to prevent overflow.
5. The HEPA filter is washable. After washing, ensure it is completely dry before reusing it to avoid motor damage.

Product Specifications

- Power: 70W
- Suction Speed: 4000pa
- Battery: 2000mAh*2
- Usage Time: Up to 20 minutes
- Portable & Lightweight: 142g
- HEPA Filter
- Fast Type-C Recharge: 3.5 hours
- Durable ABS Material
- LED Indicator Charging Cable
- Input: 5V/1.5A
- Speed: 3200 RPM
- Metal Blade
- 365 Days Warranty

Cleaning & Maintenance

- **Rinse and Reassemble:** The dust cup, filter screen, replaceable filter, and suction head are washable. After drying, reassemble in order.
- **Body Care:** Wipe the body with a damp cloth, avoiding the charging port. Replace the filter every 3 months for optimal performance.
- **Surface Cleaning:** For dirt, use a neutral detergent and a dry cloth for a thorough wipe.
- **Avoid Harsh Cleaners:** Do not use volatile oils, thinners, alcohol, or spray cleaners to prevent damage.
- **Prevent Direct Rinsing:** Avoid rinsing the product directly; follow specified cleaning instructions.

- **Regular Dust Cup Maintenance:** Clean the dust cup regularly to prevent debris buildup.
- **HEPA Filter Care:** Clean the HEPA filter with water, ensuring it's dry before reinstalling.
- **Periodic Charging:** Charge the product fully at least once every three months if unused for a long period to maintain battery health.

Emptying and Cleaning the Dust Chamber

1. Turn off and disconnect the vacuum from the charger.
2. Open the dust collection chamber as per the product design (specific mechanism should be intuitive, often a twist or slide lock).
3. Empty the collected debris into a trash bin.
4. If necessary, remove the HEPA filter and rinse it with water. Allow it to dry completely before reassembling.
5. Reassemble the chamber and ensure it is securely closed before next use.



Troubleshooting Guide

1. **Insufficient Suction:**
 - Check the battery; recharge if necessary.
 - Ensure the exhaust port is clear from obstructions.
1. **Automatic Shutdown Shortly After Startup:**
 - Charge the vacuum promptly to resolve this issue.
1. **Abnormal Vacuuming:**
 - Verify the correct installation of the dust collection bin.
 - Empty the dust cup if full.
 - Clean or replace the HEPA filter if clogged.

Note: For unresolved problems, please contact our customer service for assistance.

Safety Instructions & Warning

- **Not a Toy:** This product is not intended for children. Use under adult supervision to prevent injury.

- **Accidental Injury:** Seek immediate medical attention in case of accidental injury.
- **Avoid Liquids and Flammable Substances:** Do not vacuum water, liquids, flammable materials, or uncooled ashes to prevent hazards.
- **Read Carefully:** Familiarize yourself with the user manual to prevent accidents.
- **No Unauthorized Modifications:** Do not disassemble or modify the product without authorization.
- **Avoid Extreme Conditions:** Prevent exposure to fire, heat, direct sunlight, shocks, vibration, or high falls.
- **Safe Charging:** Use a charger that meets safety standards and matches the product's voltage marking.
- **Suitability Warning:** Not suitable for physically or mentally impaired individuals, children, or inexperienced users without supervision by experienced individuals.
- **Damaged Unit Warning:** Do not use the vacuum cleaner if it is damaged.
- **Temperature Range:** Operate and charge the product within the temperature range of 0°C to 40°C.
- **Cable Removal After Charging:** Remove the charging cable promptly after charging to avoid safety hazards.

Avoid Usage In:

- **High Heat Areas:** Avoid proximity to heating equipment or hot air sources.
- **Steamy or Smoky Environments:** Do not use near steamy areas like pools, hot springs, or kitchens.

Outdoor or Industrial Settings: Avoid outdoor, commercial, or industrial usage.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.