

Model: 960 | Color: Pink

Overview

The ZIHNIC Active Noise Cancelling Headphones (Model 960) are wireless Bluetooth over-ear headphones designed for immersive audio, low-latency performance, and extended comfort. They feature active noise cancellation, Hi-Fi stereo sound, and up to 60 hours of battery life.



Features

Active Noise Cancellation

The headphones use advanced noise reduction technology to minimize surrounding environmental noise, allowing you to focus on your audio without distraction.

Low Latency Performance

Designed for TV, gaming, and video calls, the Bluetooth connection provides stable, low-latency audio for a seamless experience with minimal delay between sound and picture.

Hi-Fi Stereo Sound

High-fidelity stereo drivers deliver clear, detailed audio with deep bass, bringing music, movies, and calls to life.

Long Battery Life

A full charge provides up to 60 hours of playback time. Actual battery life may vary depending on volume level, usage patterns, and other factors.

Comfortable Earpads

The ear pads are designed for extended wear, using soft, breathable materials to provide a comfortable fit during long listening sessions.

Foldable and Adjustable Design

The headphones feature rotatable earcups, an adjustable headband, and a foldable construction for easy storage and portability.

What's in the Box

- ZIHNIC Active Noise Cancelling Headphones (Model 960)
- User Manual

Product Specifications

Brand	ZIHNIC
Model Number	960
Color	Pink
Ear Placement	Open Ear (Over-Ear)
Form Factor	Open Ear
Impedance	32 Ohms
Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz – 20,000 Hz
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless Bluetooth
Headphone Jack	No Jack (Wireless only)
Battery Average Life	60 Hours
Control Type	Media Control (Remote)
Compatible Devices	Bluetooth-enabled devices
Enclosure Material	Plastic
Cable Features	Without Cable
Additional Features	Noise Cancellation
Unit Count	1.0 Count
Manufacturer	zihnic
ASIN	B0CSK24L88



Use Guide

Charging the Headphones

1. Connect the included charging cable to the headphones' charging port.
2. Plug the other end into a USB power source (such as a computer, wall adapter, or power bank).
3. A full charge takes approximately 2–3 hours. The LED indicator will show the charging status.

Power On / Off

- **Power On:** Press and hold the power button for 2–3 seconds until the LED indicator flashes.
- **Power Off:** Press and hold the power button for 2–3 seconds until the LED indicator turns off.

Bluetooth Pairing

1. Ensure the headphones are powered on and in pairing mode (the LED will flash rapidly).
2. On your Bluetooth-enabled device (smartphone, tablet, TV, etc.), go to Bluetooth settings and search for available devices.
3. Select "ZIHNIC 960" from the list of discovered devices.
4. Once connected, the LED will stop flashing and remain steady (or pulse slowly).

Adjusting Volume and Media Control

- **Volume Up/Down:** Use the dedicated volume buttons on the ear cup.
- **Play/Pause:** Press the multi-function button once.
- **Skip Track Forward/Backward:** Press and hold the volume up/down buttons (or use the multi-function button depending on configuration).
- **Answer/End Call:** Press the multi-function button once to answer; press again to end.

Activating Noise Cancellation

Press the ANC button (located on the ear cup) to toggle Active Noise Cancellation on or off. When active, ambient noise is significantly reduced.

Wearing and Adjusting Fit

- Adjust the headband by extending or retracting the arms until the headphones sit comfortably on your head.

- Rotate the ear cups to achieve the best seal and comfort.
- For storage, fold the ear cups inward and collapse the headband to minimize size.

Troubleshooting

- **Headphones not powering on:** Ensure the battery is charged. Connect to a charger and wait a few minutes before trying again.
- **Bluetooth not connecting:** Make sure the headphones are in pairing mode (LED flashing). Delete the device from your phone's Bluetooth list and re-pair.
- **Audio cuts out or is distorted:** Move closer to the connected device (within 10 meters / 33 feet). Avoid obstacles like walls or metal objects.
- **Noise cancellation not working:** Verify that ANC is turned on via the dedicated button. If the battery is low, ANC may automatically deactivate to conserve power.
- **Low battery warning:** When battery is low, the LED will flash red. Charge the headphones promptly.

Warranty and Support

This product is covered by a 1-year warranty from the date of purchase. For warranty claims or technical support, contact ZIHNIC through the official store page on Amazon or refer to the contact information provided in the product packaging.

Warranty Description: 1 YEAR WARRANTY

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.