

Portable Air Compressor with Pressure Gauge, LED Light

Overview

The ZGZUXO Tire Inflator is a battery-powered, cordless portable air compressor designed for inflating car tires, motorcycle tires, bicycle tires, balls, and other inflatables. It features a built-in pressure gauge with an LCD display, an LED light for low-light use, and an automatic shut-off function.



Package Contents

- ZGZUXO Tire Inflator unit
- Air Hose
- Nozzle

- USB Cable
- User Manual

Product Features

Power and Battery

- **Power Source:** Battery Powered (7.4 Volts)
- **Battery Capacity:** 5200mAh
- **Performance per Charge:** Inflates up to 4 car tires (29-36 PSI), 8 motorcycle tires, 15 bicycle tires, or 30 balls on a single charge.

Display and Controls

- **LCD Display:** Shows real-time pressure value. The backlit screen allows use in low-light conditions.
- **Preset Pressure and Auto-Off:** Set the desired PSI. The inflator stops automatically when the target pressure is reached, preventing over-inflation.
- **Memory Function:** The device remembers the last pressure setting, eliminating the need to reset it each time.
- **4 Modes:** Quickly switch between preset modes for Car, Motorcycle, Bike, and Ball.

Lighting

- **LED Light:** Provides illumination for use in dark or emergency situations.

Physical Specifications

- **Dimensions:** 5L x 5W x 8H Centimetres
- **Weight:** 300 Grams
- **Material:** Metal
- **Noise Level:** 70 Decibels
- **Style:** Vertical

Use Guide

Before First Use

1. Charge the inflator fully using the provided USB cable before first use.
2. Ensure the air hose and nozzle are securely attached.

How to Inflate a Tire

1. Remove the valve cap from the tire valve stem.
2. Attach the nozzle of the air hose firmly onto the valve stem.
3. Press the power button to turn on the inflator.
4. Use the mode button to select the appropriate preset (Car, Motorcycle, Bike, Ball) or manually set the desired PSI using the +/- buttons.
5. The LCD screen will display the current tire pressure.
6. Press the start button to begin inflation. The inflator will run until the preset pressure is reached and then automatically shut off.
7. Disconnect the nozzle from the valve stem and replace the valve cap.

Using the LED Light

Press and hold the light button to turn the LED light on or off. This is useful for nighttime or low-light conditions.

Using the Memory Function

The inflator automatically saves the last pressure setting you used. The next time you turn it on, it will default to that setting.

Safety Instructions

- Do not leave the inflator unattended while in use.
- Do not over-inflate. Always use the preset pressure or auto-off function to prevent over-inflation.
- Keep the inflator away from water and moisture.
- Do not use the inflator for purposes other than its intended use (Ball Inflation, Tire Inflation, Toy Inflation).
- This product is not applicable to bikes with thin tires.

Troubleshooting

- **Inflator does not start:** Check the battery charge level. Charge the unit if necessary.
- **Inflator stops before reaching set pressure:** The battery may be low. Recharge the unit.
- **Air leaking from the nozzle:** Ensure the nozzle is securely attached to the valve stem. Check the nozzle for damage.

Specifications

Brand	ZGZUXO
Model Number	CZK5646
Voltage	7.4 Volts
Maximum Pressure	150 PSI
Recommended Uses	Ball Inflation, Tire Inflation, Toy Inflation
Power Source	Battery Powered
Noise Level	70 Decibels
Special Features	Automatic Shut-Off, Built-In Gauge, Lightweight, Memory Function, Quick Inflation
Included Components	Air Hose, Nozzle, USB Cable, User Manual
Item Weight	300 Grams
Material	Metal
Product Dimensions	5L x 5W x 8H Centimetres

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.