

Overview

This manual provides instructions for the Tastyle Single Serve Hot & Iced Coffee Maker (2.0 Version, Gray). This compact coffee maker brews single servings of hot or iced coffee using ground coffee or K-Cup pods. It features a removable water reservoir, multiple brew sizes, and adjustable brew strength.



Features

Brewing Options

- **Three Brew Styles:** Classic, Bold, and Over Ice settings.

- **Two Coffee Input Types:** Compatible with ground coffee (using the included reusable filter) and K-Cup pods.
- **Six Brew Sizes:** 6 oz, 8 oz, 10 oz, 12 oz, 16 oz, and 24 oz.

Water System

- **Removable 40 oz Reservoir:** Detachable water tank allows for easy filling and cleaning. Brews 4-5 cups before needing a refill.
- **Water-Shortage Alert:** Notifies you when the water level is low.



Safety & Convenience

- **Auto Shut-Off:** Turns off automatically 10 minutes after brewing to save energy.
- **Dry Boil Protection:** Prevents the unit from operating without sufficient water.
- **BPA-Free Materials:** Constructed from food-safe, BPA-free plastic.
- **Splash-Preventing Drip Tray:** Heightened design helps prevent splashing. The drip tray can be removed to accommodate travel mugs up to 7.3 inches tall.

Cleaning & Maintenance

- **Built-in Cleaning Function:** Helps remove calcium deposits.
- **Dishwasher Safe Parts:** The removable reservoir, drip tray, and reusable filter basket are top-rack dishwasher safe.
- **Reusable Filter:** Includes a permanent #2 size filter for ground coffee.



Use Guide

Before First Use

1. Remove all packaging materials.
2. Wash the removable water reservoir, drip tray, and reusable filter basket with warm, soapy water. Rinse thoroughly.
3. Perform a cleaning cycle by filling the reservoir with fresh water and running a 12 oz brew cycle without coffee or a pod. Discard the water.

Brewing Coffee

Using Ground Coffee

1. Fill the removable reservoir with fresh, cold water and reattach it to the unit.
2. Place the reusable filter basket into the brew head.
3. Add ground coffee to the filter. A standard measure is one tablespoon per 6 oz of water.
4. Close the brew head lid securely.
5. Place a cup or mug (up to 7.3" tall with drip tray removed) on the drip tray.
6. Press the **POWER** button to turn on the machine.
7. Select your desired **BREW SIZE** (6, 8, 10, 12, 16, or 24 oz).
8. Select your desired **BREW STRENGTH** (Classic or Bold).
9. Press the **BREW** button to start the cycle.

Using a K-Cup Pod

1. Fill the removable reservoir with fresh, cold water and reattach it.
2. Remove the reusable filter basket and insert a K-Cup pod directly into the pod holder.
3. Close the brew head lid securely, which will puncture the pod.
4. Place your cup on the drip tray.
5. Press **POWER**, select your **BREW SIZE** and **STRENGTH**, then press **BREW**.

Brewing Iced Coffee

1. Fill your cup with ice up to the fill line corresponding to your desired drink size (e.g., fill to the 12 oz line for a 12 oz iced coffee).
2. Place the cup on the drip tray.
3. Select the **OVER ICE** brew style. The machine will adjust the brew cycle for optimal iced coffee strength.
4. Select your **BREW SIZE** and press **BREW**.

Note: A recipe book for iced coffee is included with the product.

Control Panel & Indicators

The front panel includes the following buttons and indicators:

- **POWER Button:** Turns the machine on and off.
- **BREW SIZE Buttons (6, 8, 10, 12, 16, 24 oz):** Selects the volume of coffee to brew.
- **BREW STRENGTH Buttons (Classic, Bold, Over Ice):** Selects the brewing style.

- **BREW Button:** Starts the brewing cycle. A light will illuminate during brewing.
- **Water Shortage Alert:** An indicator light or message will activate if the water reservoir is empty or not properly attached.

Cleaning & Descaling

Daily Cleaning

- Remove and rinse the drip tray, water reservoir, and filter basket after use.
- Wipe the exterior with a damp cloth. Do not immerse the main unit in water.

Descaling (Monthly or as needed)

1. Fill the reservoir with a mixture of half white vinegar and half water.
2. Place a large cup on the drip tray.
3. Run a 24 oz brew cycle without coffee or a pod. Discard the liquid.
4. Repeat with two full reservoirs of fresh water to rinse the system thoroughly.

Important: Regular descaling prevents mineral buildup and maintains performance. Frequency depends on water hardness.

Specifications

Brand	Tastyle
Model	2.0 Version
Color	Gray
Dimensions (D x W x H)	10.3" x 4.7" x 12.2"
Weight	3.5 lbs
Water Reservoir Capacity	40 oz (Removable)
Brew Sizes	6, 8, 10, 12, 16, 24 oz
Input Voltage	120V, 60Hz
Wattage	1000W
Included Components	K-Cup Pod Holder, Permanent Ground Coffee Filter (#2)
Special Features	Adjustable Brew Strength, Auto Shut-Off, Permanent Filter, Removable Tank, Splash-Preventing Design

Troubleshooting

Problem	Possible Cause	Solution
Machine won't turn on.	Not plugged in. Power outlet issue.	Ensure the power cord is securely plugged into a working outlet.
No water flows during brew.	Water reservoir empty or not seated correctly. Dry boil protection activated.	Fill the reservoir with water and ensure it is clicked into place. Allow the machine to cool if it recently boiled dry.
Coffee is weak or cold.	Incorrect brew size or strength selected. Mineral buildup.	Select a smaller brew size or the "Bold" strength. Descale the machine.
Water leaks from unit.	Reservoir not properly attached. Drip tray overfull.	Remove and reattach the reservoir, ensuring it's locked. Empty the drip tray.
"Over Ice" coffee is watery.	Not enough ice in the cup.	Fill the cup with ice to the fill line corresponding to your selected brew size.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.