

## Overview

This manual provides instructions for the BEAUTURAL 304 Stainless Steel Countertop Soap Dispenser. The dispenser is a manual pump-style container designed for dispensing liquid soap, lotion, and other similar liquids in kitchens and bathrooms. It is constructed from 304 stainless steel with a rust-proof coating and features a refillable 15.2 oz (445 mL) capacity.



## Product Specifications

- **Brand:** BEAUTURAL
- **Material:** 304 Stainless Steel
- **Color:** Silver
- **Capacity:** 15.2 oz / 445 mL
- **Product Dimensions:** 3.2" L x 3.1" W x 8.1" H
- **Shape:** Round
- **Model Number:** JU52

## Features and Components



## Construction and Design

- **304 Stainless Steel Body:** Provides a durable and rust-resistant exterior.
- **Nano Anti-Rust Coating:** An additional protective layer to prevent corrosion.

- **Fingerprint-Resistant Finish:** A clear top coat helps minimize visible smudges and fingerprints.
- **ABS Plastic-Lined Nozzle:** The internal surface of the dispensing spout is lined with plastic to prevent the liquid from contacting the metal, preventing rust and leaks.

## Pump Mechanism

- **Manual Press Pump:** Dispenses liquid with a downward press on the pump head.
- **Controlled Dispensing:** Designed to deliver a consistent, measured amount of liquid per press.
- **Wide Refill Opening:** The top cap unscrews to reveal a wide opening for easy refilling.

## Stability and Safety

- **Included EVA Pads:** Three adhesive pads are included. These can be attached to the bottom of the dispenser to prevent slipping and tipping on smooth surfaces.

## Use Guide

### Initial Setup and Refilling

1. **Remove the Cap:** Firmly grip the main body of the dispenser and twist the top cap counterclockwise to unscrew it.
2. **Fill with Liquid:** Pour your chosen liquid (e.g., dish soap, hand soap, lotion, shampoo) into the container. Do not overfill. Leave some space below the neck of the opening.
3. **Replace the Cap:** Screw the top cap back on by turning it clockwise until it is snug.
4. **Prime the Pump (First Use or After Refill):** Press the pump head down several times until liquid is dispensed. This primes the pump mechanism by drawing liquid up the tube.



## Daily Operation

1. Place the dispenser on a stable, level surface such as a kitchen countertop, bathroom vanity, or near a sink.
2. To dispense liquid, place your hand under the spout and press down firmly on the pump head with your other hand.
3. Release the pump head to allow it to return to its original position, ready for the next use.

## Compatible Liquids

This dispenser is designed for use with a variety of low to medium-viscosity liquids, including:

- Liquid dish soap
- Hand soap
- Hand lotion
- Shampoo or shower gel
- Mouthwash
- Massage oil

**Note:** Do not use with corrosive, abrasive, or excessively thick liquids that may clog the pump mechanism.

## Cleaning and Maintenance

1. **Exterior Cleaning:** Wipe the exterior with a soft, damp cloth and mild soapy water. Dry with a clean cloth to maintain a shiny finish. Avoid abrasive cleaners or scouring pads.
2. **Interior Cleaning (Periodic):** To clean the interior and pump mechanism:
  - Empty any remaining liquid.
  - Fill the container partially with warm water and a small amount of mild dish soap.
  - Replace the cap and pump the solution through the dispenser several times to flush the tube and mechanism.
  - Repeat with clean water to rinse thoroughly.
  - Allow all parts to air dry completely before refilling with soap or lotion.
3. **Pump Maintenance:** If the pump becomes stiff or fails to dispense, disassemble it according to the manufacturer's instructions (if possible) and rinse components in warm water to remove residue.



## Troubleshooting

- **Pump does not dispense liquid:** Ensure the dispenser has been primed by pressing the pump several times. Check that the container is filled with liquid and the suction tube is submerged.
- **Liquid leaks from the pump or spout:** Ensure the top cap is screwed on tightly. Check that the internal plastic liner in the nozzle is intact and correctly positioned.
- **Pump feels stiff or stuck:** The mechanism may be clogged with dried or thick residue. Clean the pump and interior as described in the Cleaning section.
- **Dispenser tips over easily:** Attach the included adhesive EVA pads to the bottom of the unit to increase stability on smooth surfaces.

## Safety Information

- For household use only.
- Keep out of reach of small children to prevent accidental ingestion of contents or choking on small parts.

- Use only with compatible liquids as listed. Do not store food, beverages, or hazardous chemicals in this container.
- Ensure the dispenser is placed on a stable surface to prevent tipping and spills.

## Environmental Note

This product is designed to be refilled and reused, reducing waste from single-use plastic soap bottles. Its durable stainless steel construction is intended for long-term use.

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

---

Document generated by [ManualsFile](#)