

Overview

The ROVSUN 1.8 Cu.Ft Portable Clothes Dryer is a compact, front-loading electric dryer designed for use in apartments, dorm rooms, and homes with limited space. It features a stainless steel tub and a simple knob control interface.



Features and Specifications

Key Features

- **Compact & Portable:** Dimensions of 19.2" (W) x 18.1" (D) x 27.1" (H). Weighs 57.3 lbs. Can be installed on a countertop, firm level ground, or mounted on a wall using the included mounting kit.
- **Powerful Drying:** 1020W power. Maximum temperature of 140°F. Recommended drying capacity of 6.6 lbs of dry clothes (10.6 lbs wet).

- **Simple Operation:** Classic knob control with clearly listed functions on the control panel.
- **Safety & Durability:** Constructed with a high-quality stainless steel tub. Features a multiple filtration system to catch lint. The dryer will automatically stop if the door is opened during operation.

Technical Specifications

- **Brand:** ROVSUN
- **Model:** GYJ30-28
- **Form Factor:** Front Load
- **Capacity:** 1.8 Cubic Feet
- **Color:** White
- **Material:** Acrylonitrile Butadiene Styrene (ABS) housing with Stainless Steel tub
- **Rated Input:** 1020W
- **Voltage:** 110V
- **Door Orientation:** Left-hinged



Use Guide

Installation and Setup

The dryer can be installed in multiple ways:

1. **Freestanding:** Place the dryer on a firm, flat, and level surface.
2. **Countertop:** Ensure the countertop is sturdy enough to support the dryer's weight and vibration.
3. **Wall Mounting:** Use the included mounting kit to securely attach the dryer to a wall. Follow all instructions provided with the kit.

Important: Ensure the exhaust vent is not blocked and has adequate airflow.




Control Panel and Operation

The dryer is operated via a simple control knob. The panel lists various drying modes.

1. Load clothes into the drum. Do not exceed the recommended capacity of 6.6 lbs of dry clothes.
2. Close the door securely.
3. Turn the control knob to select the desired drying mode and temperature.
4. The dryer will begin operation. It will automatically stop if the door is opened during a cycle.
5. After the cycle completes, remove the lint from the filtration system.

Note: Allow the dryer to rest for 1 hour after long working periods to prolong its lifespan.



Maintenance and Care

- **Clean the Lint Filter Every Load:** A clean filter is critical for airflow, efficiency, and preventing overheating.
- **Avoid Overloading:** Fill the drum only to 70-80% capacity to allow proper air circulation.
- **Level Ground:** Periodically check that the dryer is on a flat surface to prevent drum misalignment.
- **Cool Down:** Allow a short break between multiple drying cycles to prevent component stress.
- **Ventilation:** Always ensure the exhaust vent is clear and unobstructed.

Safety Information

- This appliance must be plugged into a proper 110V electrical outlet.
- Do not use an extension cord.
- The dryer will automatically stop when the door is opened. Do not attempt to override this safety feature.
- Do not dry articles that have been cleaned with flammable chemicals or that contain foam rubber.
- Keep the area around the exhaust vent clear of lint and obstructions.
- Unplug the dryer before cleaning or performing any maintenance.

Troubleshooting

- **Dryer does not start:** Check that the door is fully closed. Ensure the power cord is securely plugged into a working outlet.
- **Clothes are not drying:** Clean the lint filter. Ensure the exhaust vent is not blocked. Do not overload the dryer.
- **Dryer stops during cycle:** The door may have been opened. Close the door to resume. The unit may have overheated; unplug it and allow it to cool for one hour.
- **Unusual noise:** Ensure the dryer is placed on a level surface. Check for small objects (like coins) in the drum or lint filter housing.

Warranty and Support

This product is covered by a 1 Year Warranty from ROVSUN. For any questions or to report a quality problem within the warranty period, contact ROVSUN customer care for service or free exchange.

Included Components: Portable dryer unit.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)