

BQYPOWER Handheld Vacuum Cordless

Model: Vacuum 151 (Silver Blue)

Brand: BQYPOWER

Key Features: 16000PA Strong Suction, Cordless, Rechargeable, Multiple Accessories

QUICK START GUIDE

Follow these steps to begin using your vacuum immediately.

1. Remove all packaging materials.
2. Charge the vacuum fully using the provided Type-C cable.
3. Attach the desired cleaning accessory.
4. Press and hold the power button to start cleaning.
5. After use, empty the dust cup and clean the filter.

Emergency Shutdown: Press and hold the power button for 3 seconds.

1. SAFETY INFORMATION

Important Safety Instructions

- Do not use the vacuum to pick up liquids, flammable materials, or sharp objects.
- Keep the vacuum away from children and pets during operation.
- Do not block the suction inlet or exhaust vent.
- Only use the provided charger and accessories.

Warning Symbols

- ⚠ Do not immerse in water.
 - Use only original charger.
 - Keep away from heat sources.
-

2. PRODUCT OVERVIEW

Package Contents

- Handheld Vacuum Cleaner (1)

- 2-in-1 Brush & Suction Nozzle (1)
- Scrubbing Brush (1)
- Flexible Hose (1)
- Type-C Charging Cable (1)
- User Manual (1)

Product Components Diagram

[Image: Labeled diagram of vacuum components]

1. Power Button
 2. Dust Cup Release Button
 3. Suction Inlet
 4. Type-C Charging Port
 5. Battery Indicator
-

3. GETTING STARTED

Charging the Vacuum

1. Connect the Type-C cable to the charging port on the vacuum.
2. Plug the other end into a USB power adapter or computer.
3. Charging time: Approximately 3–4 hours for full charge.
4. The battery indicator will light up during charging.

Installing the Dust Cup

Align the dust cup with the vacuum body and push until it clicks into place.

Attaching Accessories

Insert the desired accessory into the suction inlet and twist gently to lock.

4. OPERATING INSTRUCTIONS

Power On/Off

Press the power button once to turn on. Press again to turn off.

Using Cleaning Attachments

- **2-in-1 Brush:** Use on carpets, upholstery, and hard floors.
- **Scrubbing Brush:** For stubborn debris on hard surfaces.
- **Flexible Hose:** Ideal for tight spaces, car interiors, and keyboards.

Cleaning Different Surfaces

- **Hard Floors:** Use suction-only mode.
 - **Carpets:** Use the brush attachment.
 - **Car Interiors:** Use flexible hose with narrow nozzle.
-

5. MAINTENANCE & CLEANING

Emptying the Dust Cup

1. Press the dust cup release button.
2. Remove and empty contents into a trash bin.
3. Wipe with a dry cloth if needed.

Cleaning the Filters

Remove the filter from the dust cup and tap gently to remove dust. Rinse with water if necessary, then air dry completely before reinserting.

Replacing Filters

Replace the filter every 6 months or when visibly worn.

Storing the Vacuum

Store in a cool, dry place. Ensure the vacuum is fully charged if storing for extended periods.

6. TROUBLESHOOTING GUIDE

Problem	Solution
Vacuum does not turn on	Charge the battery fully. Check power button.
Weak suction	Empty dust cup and clean filter.
Battery not charging	Ensure Type-C cable is properly connected.
Overheating	Turn off and allow to cool for 30 minutes.

7. BATTERY INFORMATION

- **Type:** Rechargeable Lithium-ion
- **Charging Time:** 3–4 hours
- **Run Time:** Up to 30 minutes per charge
- **Charging Cable:** Type-C (included)

Battery Care: Avoid complete discharge. Store with at least 50% charge.

8. ACCESSORIES GUIDE

- **2-in-1 Brush & Suction Nozzle:** For versatile cleaning.
- **Scrubbing Brush:** For scrubbing hard surfaces.
- **Flexible Hose:** For reaching tight spaces.

Attachment Method: Align and twist gently until secure.

9. TECHNICAL SPECIFICATIONS

Feature	Specification
Suction Power	16000PA
Battery	2200mAh Lithium-ion
Charging Port	Type-C
Weight	1.2 kg
Noise Level	<75 dB
Dust Cup Capacity	0.6L

10. WARRANTY INFORMATION

Warranty Period: 12 months from date of purchase.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.