

Overview

The Vazone R6X is a corded stick vacuum cleaner designed for whole-home cleaning. It operates as a 2-in-1 device, converting from a stick vacuum for floors to a handheld vacuum for above-floor cleaning. The unit is powered by a corded electric connection, providing continuous suction without the need for battery recharging.



The vacuum features a 20 kPa suction motor, a HEPA filtration system, and a 1 L dust cup capacity. It weighs approximately 1.9 lbs (0.86 kg) and includes a 16 ft power cord. The product is recommended for use on hardwood floors, bare floors, and for picking up pet hair.

What's in the Box

- 1x Corded Vacuum Cleaner (main body with motor and dust cup)
- 1x Metal Extension Wand (connects handle to floor head)
- 1x Floor Brush (for hard floors and low-pile carpet)
- 1x Square Brush (for upholstery and delicate surfaces)
- 1x Crevice Tool (for tight spaces and corners)
- 1x HEPA Filter (pre-installed, with one spare)
- 1x Storage Base (for upright parking and accessory storage)
- 1x Instruction Manual (English)



Features

20 kPa Powerful Suction

The vacuum delivers a maximum suction power of 20 kPa. A single-button (one-touch) power control activates the motor, providing consistent suction for picking up dust, crumbs, debris, and pet hair from hard floors and low-pile carpets.



Cyclone HEPA Filtration System

The vacuum uses a high-efficiency cyclone technology combined with a HEPA filter. This system captures up to 99.99% of particles as small as 0.1 microns, separating dust by size and reducing secondary pollution. The filter is washable and should be fully dried before reuse.

2-in-1 Design: Stick and Handheld

The vacuum can be used in two configurations:

- **Stick mode:** Attach the metal wand and floor brush for cleaning large floor areas.
- **Handheld mode:** Detach the wand and attach the square brush or crevice tool directly to the main body for cleaning sofas, beds, cabinets, car interiors, and other above-floor surfaces.



16 ft Long Power Cord

The 16 ft (approx. 5 m) cord allows continuous cleaning without recharging. The cord length is sufficient to clean most rooms without switching outlets. A hook on the handle helps wind and store the cord after use.

Lightweight and Portable

The vacuum weighs only 1.9 lbs (0.86 kg), making it easy to carry and operate with one hand. The low-profile floor head tilts up to 90 degrees, allowing access under furniture.

Storage Base

The included storage base allows the vacuum to stand upright when not in use. Accessories can be stored on the base for easy access.

5 FILTRATION SYSTEM

Traps 99.99% of microscopic particles expels cleaner air.



Anti-tangle Floor Brush

The floor brush is designed with a practical structure that reduces hair tangling around the brush roll, making cleaning and maintenance easier.

Use Guide

Assembly

1. Insert the metal extension wand into the main body until it clicks.
2. Attach the floor brush to the bottom of the wand.
3. For handheld use, remove the wand and attach the desired accessory (square brush or crevice tool) directly to the main body.
4. Place the storage base on a flat surface and park the vacuum upright.

Note: Partial assembly is required. Refer to the included manual for detailed steps.

Operating Instructions

1. Plug the power cord into a standard 120 V AC outlet.

2. Press the power button on the handle to start the vacuum. The vacuum operates at a single speed.
3. Guide the floor head across the cleaning surface. The low-profile head allows cleaning under furniture.
4. To switch to handheld mode, press the release button and detach the wand. Attach the desired tool.
5. After use, press the power button to turn off the vacuum. Unplug the cord and wind it around the cord hook for storage.

Emptying the Dust Cup

1. Ensure the vacuum is turned off and unplugged.
2. Press the dust cup release button and remove the cup from the main body.
3. Hold the cup over a trash bin and press the bottom release latch to empty the contents.
4. Reattach the dust cup until it clicks into place.

Cleaning the Filter

1. Remove the dust cup and take out the HEPA filter.
2. Tap the filter gently to remove loose dust. For deeper cleaning, rinse the filter under running water.
3. Allow the filter to air dry completely (at least 24 hours) before reinstalling.
4. Do not use the vacuum without the filter in place.

Maintenance Tips

- Empty the dust cup after each use or when it reaches the MAX fill line.
- Clean the HEPA filter every 2–4 weeks, depending on usage.
- Check the floor brush for hair or debris buildup and remove as needed.
- Store the vacuum in a dry place, parked on the storage base.

Specifications

| | |
|-----------------------------|--|
| Suction Power | 20 kPa |
| Filter Type | HEPA (washable) |
| Cord Length | 16 ft (approx. 5 m) |
| Dust Cup Capacity | 1 L |
| Weight | 1.9 lbs (approx. 0.86 kg) |
| Power Source | Corded Electric, 120 V AC |
| Controller Type | Push Button (single speed) |
| Form Factor | Stick / Handheld (2-in-1) |
| Recommended Surfaces | Hardwood, Bare Floor, Pet Hair |
| Color Options | Orange, Blue/Black, Green, Pink |
| Model Number | R6X Vacuum Cleaners for Home |
| Included Components | Accessory Kit (floor brush, square brush, crevice tool, HEPA filter, storage base) |

Troubleshooting

Vacuum does not start

- Ensure the power cord is firmly plugged into a working outlet.
- Check that the power button is pressed fully.
- Inspect the cord for damage. If damaged, discontinue use and contact support.

Loss of suction or poor performance

- Empty the dust cup if it is full.
- Clean or replace the HEPA filter if clogged.
- Check the floor brush for blockages or tangled hair.
- Ensure all connections (wand, hose, tools) are securely attached.

Vacuum overheats or shuts off

- Turn off and unplug the vacuum. Allow it to cool for 30 minutes.
- Check for blockages in the dust cup, filter, or floor head.
- Clean the filter and empty the dust cup before restarting.

Hair wrapped around brush roll

- Turn off and unplug the vacuum.
- Use scissors or a seam ripper to carefully cut and remove hair from the brush roll.
- The brush is designed to minimize tangling, but periodic cleaning may be needed.

Warranty and Support

This vacuum cleaner is covered by a 12-month service assurance from the date of purchase. If you have any questions or issues, contact Vazone customer support via email. The manufacturer states that 24/7 online service is available.

Contact: Refer to the email address provided in the product packaging or your order confirmation. No phone number or physical address is listed in the product materials.

Note: This warranty does not cover damage from misuse, failure to perform routine maintenance, or unauthorized repairs.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.