

## 1. Overview

The NEWBULIG Cordless Vacuum Cleaner is a lightweight, rechargeable stick vacuum designed for cleaning various surfaces in the home, including hardwood floors, carpets, and pet hair. It features a flexible brush head with LED lighting, an anti-tangle system, and a multi-stage filtration system.



### Key Characteristics:

- **Form Factor:** Stick vacuum, converts to handheld.

- **Weight:** 5.7 lbs (2.6 kg).
- **Power Source:** Rechargeable lithium-ion battery (22.2V).
- **Dust Cup Capacity:** 0.8 Liters.
- **Filtration:** 8-layer cyclone system with a washable HEPA filter.

## 2. Package Contents

- Main vacuum body
- Motorized floor brush head (with LED lights)
- Crevice tool
- Flat/upholstery nozzle
- Wall mounting bracket
- Power adapter
- User manual (this guide)

## 3. Product Features & Parts

### 3.1 Main Body and Controls

- **Power Button:** Located on the handle. Press to turn the vacuum on or off.
- **Suction Power Button:** Toggles between two suction power levels.
- **Battery Indicator:** LEDs show the remaining battery charge.
- **Dust Cup Release Button:** Press to detach the dust cup for emptying.
- **Handle Trigger:** Used to recline the vacuum for under-furniture cleaning.

### 3.2 Brush Heads and Attachments

The vacuum includes three interchangeable brushes:

- **Motorized Floor Brush:** Primary brush for carpets and hard floors. Features:
  - LED headlights to illuminate dark areas.
  - 180° side-to-side and 90° up-and-down rotation for maneuvering under furniture.
  - Anti-tangle technology to reduce hair wrap.
- **Crevice Tool:** A narrow attachment for cleaning tight spaces like between cushions, along edges, and in car interiors.
- **Flat Nozzle/Upholstery Tool:** A wide brush for cleaning furniture, stairs, and car seats.

## Different Brush Heads



### 3.3 Filtration System

The vacuum uses an 8-layer cyclone filtration system with a high-density HEPA filter.

- **Function:** Captures fine dust and particles (100% of particles above 0.1  $\mu\text{m}$ , 95% below 0.1  $\mu\text{m}$ ).
- **Maintenance:** The HEPA filter is washable and reusable. Allow it to dry completely before reinserting.

### 3.4 Battery and Charging

- **Battery Type:** Lithium-Ion, 2200mAh x 6 configuration.
- **Run Time:** Up to 30 minutes per full charge (depending on suction power level).
- **Charge Time:** Approximately 4 hours to full capacity.
- **Charging:** Connect the power adapter to the charging port on the vacuum body. The battery indicator will show charging status.

## 4. Use Guide

### 4.1 Assembly

1. Insert the desired brush head or attachment into the socket at the bottom of the main vacuum body until it clicks into place.
2. To convert to a handheld vacuum, press the release button where the stick connects to the main body and detach the long tube.
3. Attach a tool (crevice or flat nozzle) directly to the handheld unit.

### 4.2 Basic Operation

1. **Charging:** Fully charge the vacuum before first use.
2. **Power On:** Press the power button on the handle. The battery indicator will light up.
3. **Select Suction Power:** Press the suction power button to switch between standard and high power.
4. **Cleaning:** Push the vacuum forward and back over the surface. Use the handle trigger to recline the head for cleaning under furniture.
5. The LED lights on the floor brush will activate automatically when the vacuum is powered on.



### 4.3 Emptying the Dust Cup

1. Press the dust cup release button to detach the cup from the main body.
2. Hold the dust cup over a trash bin. Open the bottom lid to empty the contents.
3. Close the lid securely and reattach the dust cup to the main body until it clicks.
4. For thorough cleaning, the dust cup can be rinsed with water. Ensure it is completely dry before reuse.


### 4.4 Cleaning the Filter

1. Remove the dust cup.
2. Take out the HEPA filter from the top of the dust cup assembly.
3. Rinse the filter under lukewarm water until the water runs clear. Do not use detergents.
4. Allow the filter to air dry for at least 24 hours in a well-ventilated area before reinstalling.

### 4.5 Storage

- The vacuum can stand upright on its own on flat surfaces.

- For wall storage, mount the included bracket on a wall using appropriate screws (not included). Hang the vacuum by its main body on the bracket.
- Store the vacuum and attachments in a dry place.



## 5. Specifications

- **Brand:** NEWBULIG
- **Model Number:** HJ-6309C
- **Voltage:** 22.2 Volts
- **Wattage:** 150 Watts
- **Battery Runtime:** Up to 30 minutes
- **Battery Charge Time:** ~4 hours
- **Weight:** 5.7 lbs (2.6 kg)
- **Dimensions (L x W x H):** 9.85" x 8.27" x 41.34" (25 x 21 x 105 cm)
- **Dust Cup Capacity:** 0.8 Liters
- **Filter Type:** Washable HEPA Filter

- **Special Features:** Anti-Tangle Brush, LED Headlight, Cyclone Filtration, Self-Standing

## 6. Troubleshooting

- **Vacuum won't turn on:** Ensure the battery is charged. Check that the dust cup and filter are correctly installed.
- **Weak suction:** Empty the dust cup. Check and clean the filter and the brush head for blockages (hair, debris). Ensure the filter is completely dry if recently washed.
- **Brush roll not spinning:** Turn off the vacuum and remove any tangled hair or string from the brush roll.
- **Battery not charging:** Verify the power adapter is properly connected to both the outlet and the vacuum. Ensure the charging contacts on the vacuum and adapter are clean.
- **Vacuum shuts off unexpectedly:** The battery may be depleted. Recharge the vacuum. The motor may also overheat; turn off the vacuum and let it cool for 30-40 minutes.

## 7. Safety Instructions

- Read all instructions before using the appliance.
- Do not use to pick up liquids, burning materials, or sharp, hard objects.
- Do not use outdoors or on wet surfaces.
- Unplug the charger from the outlet when not in use and before cleaning or maintenance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only the charger supplied by the manufacturer.
- Do not use the vacuum if it is damaged in any way.
- Store the vacuum indoors in a dry place. Do not expose the battery to extreme temperatures.

## 8. Warranty and Support

This product is covered by a **1-year manufacturer's warranty** from the date of purchase.

For warranty service or product support, contact the seller through your Amazon purchase history or visit the NEWBULIG store on Amazon.

**Manufacturer:** NEWBULIG

---

*Manual version based on product information available as of March 2025. Specifications are subject to change. Please refer to the official NEWBULIG website or your product documentation for the most current information.*

**Warning**

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

---

Document generated by [ManualsFile](#)