

Table of Contents

- [1. Overview](#)
 - [1.1 Introduction](#)
 - [1.2 What's in the Box](#)
 - [1.3 Product Diagram](#)
- [2. Specifications](#)
- [3. Features](#)
 - [3.1 2-in-1 Dual Brewing System](#)
 - [3.2 5 Adjustable Cup Sizes \(6–14 Oz\)](#)
 - [3.3 Anti-Overflow & User-Friendly Design](#)
 - [3.4 Compact & Space-Saving Build](#)
 - [3.5 Smart Safety & Easy Maintenance](#)
- [4. Setup & First Use](#)
 - [4.1 Unpacking](#)
 - [4.2 Cleaning Before First Use](#)
 - [4.3 Placing the Machine](#)
- [5. Use Guide](#)
 - [5.1 Brewing with K-Cup Pods](#)
 - [5.2 Brewing with Ground Coffee](#)
 - [5.3 Adjusting Brew Size](#)
 - [5.4 Using Travel Mugs](#)
- [6. Cleaning & Maintenance](#)
 - [6.1 Daily Cleaning](#)
 - [6.2 Self-Cleaning Process](#)
 - [6.3 Descaling](#)
- [7. Safety & Indicators](#)
 - [7.1 Auto Shut-Off Feature](#)
 - [7.2 Indicator Lights](#)
- [8. Troubleshooting](#)
- [9. Warranty & Support](#)

1. Overview

1.1 Introduction

The COWSAR Single Serve Coffee Maker (Model CM9440-UL) is a compact, 2-in-1 coffee brewing machine designed for use with both K-Cup pods and ground coffee. It features a 14 oz water reservoir with five adjustable brew sizes (6, 8, 10, 12, and 14 oz), an adjustable-height funnel to accommodate various cup sizes, and a built-in auto shut-off safety mechanism. The machine is intended for home, office, dorm, and travel use.

This manual provides complete instructions for setup, operation, cleaning, and maintenance. Please read it thoroughly before using the appliance.

1.2 What's in the Box

- COWSAR Single Serve Coffee Maker (1 unit)
- User Manual

Note: The included components are limited to the coffee maker itself. No additional filters or pods are included.

1.3 Product Diagram



COWSAR Single Serve Coffee Maker – Front View

The main components of the coffee maker are:

- **Water Reservoir:** 14 oz capacity with volume markers (6, 8, 10, 12, 14 oz).
- **Brew Head:** Located under the lid; accepts K-Cup pods or a ground coffee basket.
- **Control Button:** One-touch button to start/stop the brewing cycle.
- **Adjustable Funnel:** Height-adjustable drip tray area to fit various cup sizes.
- **Lid:** Opens for access to the brew head; must be properly closed for operation.
- **Indicator Light:** Flashes to indicate safety shut-off or operational status.

2. Specifications

Brand	COWSAR
Model Number	CM9440-UL
Part Number	CM9440-UL
Color	Black
Capacity	14 ounces (water reservoir)
Product Dimensions	10.87"D x 4.61"W x 10.94"H
Item Weight	4.4 pounds
Wattage	1050 watts
Voltage	120 volts (AC adapter)
Coffee Input Type	Ground, Pod (K-Cup compatible)
Coffee Maker Type	Drip Coffee Machine
Operation Mode	Fully Automatic
Special Features	Auto Shut-Off, Lightweight, Portable, Self-Cleaning, Single Cup Brew
Included Components	Coffee maker

Voltage Compatibility: This product is compatible with outlets that support 120 volts. It may require a converter when used outside of the United States.

3. Features

3.1 2-in-1 Dual Brewing System

The coffee maker supports two brewing methods: K-Cup pods and ground coffee. Switching between the two is straightforward—use the appropriate basket or holder for your chosen coffee type.



Dual brewing system with K-Cup holder and ground coffee basket

3.2 5 Adjustable Cup Sizes (6–14 Oz)

The 14 oz water reservoir features five precise volume markers: 6 oz, 8 oz, 10 oz, 12 oz, and 14 oz. You can select your desired brew size by filling the reservoir to the corresponding marker. This allows you to brew a small cup or a larger mug according to your preference.

3.3 Anti-Overflow & User-Friendly Design

The machine is equipped with an adjustable-height funnel that fits most cups and travel mugs. This design helps prevent splashing and overflow, keeping your countertop clean. Operation is controlled by a single one-touch button.

3.4 Compact & Space-Saving Build

With a slim body only 4.6 inches wide, the coffee maker is designed to fit in small kitchens, home offices, dorm rooms, or office breakrooms. It is lightweight (4.4 lbs) and portable, making it suitable for travel.

3.5 Smart Safety & Easy Maintenance

The built-in auto shut-off safety feature activates if the lid is open or improperly closed. A flashing indicator light alerts the user to this condition. The cleaning process is designed to be simple and time-efficient.

4. Setup & First Use

4.1 Unpacking

1. Remove the coffee maker and any included accessories from the box.
2. Remove all packaging materials, including plastic films and stickers.
3. Inspect the machine for any visible damage. If damage is found, contact the seller or manufacturer.

4.2 Cleaning Before First Use

1. Wipe the exterior of the machine with a damp cloth.
2. Wash the K-Cup holder, ground coffee basket, and funnel in warm, soapy water. Rinse thoroughly and dry.
3. Do not immerse the main unit in water.

4.3 Placing the Machine

1. Place the coffee maker on a flat, stable, and heat-resistant surface.
2. Ensure there is adequate clearance above the machine to open the lid fully.
3. Plug the power cord into a 120V AC outlet.

5. Use Guide

5.1 Brewing with K-Cup Pods

1. Open the lid of the coffee maker.
2. Place a K-Cup pod into the designated pod holder.
3. Fill the water reservoir with fresh, cold water up to the desired volume marker (6, 8, 10, 12, or 14 oz).

4. Close the lid firmly until it clicks into place.
5. Place a cup or mug on the drip tray, adjusting the funnel height if necessary.
6. Press the one-touch button to start brewing.
7. The machine will automatically stop when the brewing cycle is complete.

5.2 Brewing with Ground Coffee

1. Open the lid of the coffee maker.
2. Insert the ground coffee basket into the brew head.
3. Add the desired amount of ground coffee to the basket.
4. Fill the water reservoir with fresh, cold water up to the desired volume marker.
5. Close the lid firmly until it clicks into place.
6. Place a cup or mug on the drip tray, adjusting the funnel height if necessary.
7. Press the one-touch button to start brewing.
8. The machine will automatically stop when the brewing cycle is complete.

5.3 Adjusting Brew Size

The brew size is determined by the amount of water you add to the reservoir. The reservoir has five volume markers: 6 oz, 8 oz, 10 oz, 12 oz, and 14 oz. Simply fill the water to the marker that corresponds to your desired cup size.



Water reservoir volume markers

5.4 Using Travel Mugs

The adjustable-height funnel allows you to use taller cups and travel mugs. Adjust the funnel height to fit your mug snugly, which helps prevent splashing.

6. Cleaning & Maintenance

6.1 Daily Cleaning

1. After each use, remove and empty the K-Cup holder or ground coffee basket.
2. Rinse the holder/basket under warm running water.
3. Wipe the exterior of the machine with a soft, damp cloth.
4. Ensure the drip tray is emptied and cleaned regularly.

6.2 Self-Cleaning Process

The machine features a self-cleaning function. To use it:

1. Fill the water reservoir with clean water to the maximum (14 oz) level.
2. Place an empty cup or container on the drip tray.
3. Press and hold the one-touch button for 3 seconds to activate the self-cleaning cycle.
4. The machine will run a cleaning cycle, flushing hot water through the system.
5. Discard the water after the cycle is complete.

6.3 Descaling

Over time, mineral deposits may build up inside the machine. To descale:

1. Fill the reservoir with a descaling solution (or a mixture of equal parts water and white vinegar).
2. Run a self-cleaning cycle (see Section 6.2).
3. Repeat the cycle with fresh water only, to rinse the system thoroughly.
4. Repeat the rinsing cycle 2–3 times to ensure no residual solution remains.

7. Safety & Indicators

7.1 Auto Shut-Off Feature

The coffee maker is equipped with an auto shut-off safety feature. If the lid is open or not properly closed during operation, the machine will automatically shut off to prevent accidents. This is indicated by a flashing indicator light.

7.2 Indicator Lights

Indicator State	Meaning
Steady light (during operation)	Machine is brewing normally.
Flashing light	Lid is open or improperly closed. The machine has shut off for safety.
No light	Machine is off or unplugged.

8. Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in, or power outlet issue.	Check the power cord and outlet. Ensure the outlet is functioning.
Indicator light is flashing	Lid is open or not closed properly.	Open the lid and close it firmly until it clicks.
Brewing is slow or stops	Mineral buildup or clogged basket.	Descalc the machine (see Section 6.3) and clean the basket thoroughly.
Coffee is too weak or too strong	Incorrect water level or coffee amount.	Adjust the water level (brew size) and/or the amount of ground coffee.
Water leaks or splashes	Funnel height not adjusted for the cup.	Adjust the funnel height to fit the cup or mug snugly.

9. Warranty & Support

For warranty information, support, or product inquiries, please contact the manufacturer or seller through the original point of purchase. No specific warranty terms or contact details are provided in this manual.

Manufacturer: COWSAR

Model: CM9440-UL

ASIN: B0GMQL2LJN

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.