

Overview

The BassBloom Roar 3 is a portable Bluetooth speaker designed for indoor and outdoor use. It features a compact, lightweight body with a carry strap for easy transport. The speaker delivers audio through a 20W driver and dual passive radiators, and includes a front-facing LED power display, RGB lighting, and tactile control buttons.



The speaker is available in multiple colors: Black, Blue, Pink, Purple, and White.












Features


Audio and Sound

- **20W Driver & Dual Passive Radiators:** The speaker uses a 20W driver with passive radiators on the top and bottom to enhance low-frequency performance.
- **JIKE Bass Enhancement Algorithm:** A proprietary algorithm that processes audio to deliver deeper bass, particularly at lower volumes.
- **Dual EQ Modes:** Two equalizer presets are available: one for clear vocals and one for enhanced bass.
- **Maximum Output Power:** 30 watts peak.
- **Audio Output Mode:** Stereo.




Connectivity

- **Bluetooth 5.4:** Provides a stable wireless connection with low power consumption. The effective range is up to 10 meters (33 feet).
- **True Wireless Stereo (TWS) Pairing:** Allows two Roar 3 speakers to be paired wirelessly for a left-right stereo soundstage.



Power and Battery

- **Battery Capacity:** 2400mAh rechargeable battery.
- **Playtime:** Up to 24 hours of playback at 50% volume with the RGB lights turned off.
- **LED Power Display:** A clear percentage display on the front of the speaker shows the remaining battery level.




Precision LED Display

Always know exactly what's left.
No more battery guesswork.

Durability and Portability

- **IPX6 Waterproof Rating:** The speaker is protected against powerful water jets, making it resistant to rain, splashes, and faucet rinsing. It is not designed for submersion.
- **Portable Design:** Weighs 480g and includes a built-in carry strap for easy attachment to bags or gear.




IPX6 Weather Resistance

Defies rain and splashes, giving you
peace of mind against accidental water exposure.

Lighting

- **RGB Lights:** Built-in RGB lighting that can create a visual light show synchronized with the music.



What's in the Box

- BassBloom Roar 3 Speaker (1 unit)
- Power Cable (USB-C, for charging)




Packing List

Bluetooth speaker * 1
50cm Charging cable *1
50cm AUX line * 1
User manual * 1

Use Guide

Powering On/Off

Press and hold the power button located on the top panel of the speaker to turn it on or off.



Button control instructions

Power On/Off	2s	Restart	10s	Mode Switch	2x	Restore Factory Settings	3x
Next Track	2s	Volume Up Button	1x	Previous Track	2s	Volume Down Button	1x
Forcefully disconnect Bluetooth	3s	Play/pause/answer/hang up	1x	Light Show Button	2x	Turn off the Lights	3x
EQ switch	1x	TWS disconnection/connection	2x				

Bluetooth Pairing

1. Turn on the speaker. It will automatically enter pairing mode.
2. On your device (smartphone, tablet, or laptop), enable Bluetooth and search for available devices.
3. Select "BassBloom Roar 3" from the list of discovered devices.
4. Once connected, the speaker will play a confirmation tone.

Selecting EQ Modes

Press the EQ button on the speaker to toggle between the two sound modes:

- **Vocal Mode:** For clear, crisp vocals.
- **Bass Mode:** For enhanced, punchy bass.

Using TWS Pairing (Stereo Mode)

1. Ensure both speakers are powered on and not connected to any device.
2. Press the TWS button on one speaker. The speakers will automatically pair with each other.
3. Once paired, connect to your audio source via Bluetooth. The speakers will output left and right stereo channels.

Charging the Speaker

1. Connect the included power cable to the USB-C charging port on the speaker.
2. Connect the other end to a USB power source (e.g., a wall charger or computer).
3. The LED display will show the current battery percentage while charging.

Waterproofing Precautions

- The IPX6 rating allows the speaker to withstand powerful water jets. It is suitable for use in rain, near pools, or for rinsing under a faucet.
- **Do not submerge** the speaker in water or other liquids.
- Ensure the charging port cover is securely closed before exposing the speaker to water.



Specifications

Brand	BassBloom
Model	Roar 3
Speaker Maximum Output Power	30 Watts
Audio Driver	Dynamic Driver (5.2 cm)
Connectivity Technology	Bluetooth 5.4
Bluetooth Range	10 Meters (33 Feet)
Audio Output Mode	Stereo
Battery Capacity	2400 mAh
Battery Life	Up to 24 Hours (at 50% volume, lights off)
Water Resistance Level	IPX6 (Waterproof against powerful jets)
Weight	480 g (1.06 lbs)
Dimensions (D x W x H)	7 x 3 x 3 Inches
Mounting Type	Tabletop Mount
Compatible Devices	Laptop, Smartphone, Tablet
Signal-to-Noise Ratio	80 dB
Color Options	Black, Blue, Pink, Purple, White

Troubleshooting

Speaker will not turn on

- Ensure the speaker is charged. Connect it to a power source and wait a few minutes before trying again.

Cannot connect via Bluetooth

- Make sure the speaker is in pairing mode (indicated by a blinking light or tone).
- Move the speaker and your device closer together (within 10 meters).

- Turn off Bluetooth on your device, then turn it back on and search again.
- If the speaker was previously connected to another device, disconnect it from that device first.

No sound or low volume

- Increase the volume on both your connected device and the speaker.
- Check that the audio source is playing music.
- Try switching the EQ mode.

Distorted sound

- Reduce the volume on your connected device or the speaker.
- Ensure the speaker is not placed on a surface that vibrates excessively.

Safety and Care

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Do not attempt to disassemble the speaker. There are no user-serviceable parts inside.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- When not in use for an extended period, store the speaker in a cool, dry place.
- Use only the provided charging cable or a compatible USB-C cable to charge the speaker.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.