

E-333 Mini Dehumidifier

You bought the E-333 Mini Dehumidifier to protect what you care about from moisture. Now protect it by registering your warranty today.



Safety Precautions & Important Information

Recommended method of renewal (use wall outlet)

E-333



Caution: The unit must avoid direct contact with water. Do not drop. Do not open the unit. Do not plug the unit in when the indicator window is ORANGE. Do not leave unit plugged in for more than 18 hours.

FCC Compliance

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This equipment has been verified to comply with the limits for a class B computing device, pursuant to FCC Rules. In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Usage Instructions

1. View beads in the indicator window of the unit. If the indicator beads are orange, the unit is ready to use. If the indicator beads are green, the unit needs to be renewed. (See step 5)
2. Place the unit in the desired location to begin absorbing moisture.
3. Monitor indicator beads roughly once a month (4-6 weeks) for color transition from orange to green.
4. Once indicator beads turn green, it is time to renew the unit.
5. To renew, simply fold down the hidden plug and plug the unit into an outlet (avoid the use of extension cords) for 10 to 12 hours (approximately). Be sure to maintain a minimum of 24-36 inches of open space around the unit as the unit will release heat and moisture vapor while plugged in.

6. DO NOT hang the unit from hooks while plugged in for renewal. Make sure there are no obstructions or contact with any other objects during the renewal process. DO NOT cover the unit. DO NOT leave the unit plugged in for more than 18 hours.
7. Once renewed, indicator beads will return to orange and the unit will be ready to absorb moisture again.

Please visit eva-dry.com for more information on the E-333 dehumidifier and other quality products from Eva-Dry. Thank you for choosing and supporting the Eva-Dry brand.

Production Information

BEFORE YOU RETURN TO STORE — Please review below and call toll-free: 877.382.3790

Frequently Asked Questions

Where are the lights?

There are no lights on the unit. The indicator window contains color-changing beads that indicate when the unit needs to be renewed.

Does the unit need batteries or need to be plugged in to absorb moisture?

No, the unit absorbs moisture without power, plugs, or batteries. Once you remove the unit from its packaging it will start absorbing moisture. There is no ON/OFF switch on the unit. The only time the unit needs to be plugged in is when it needs to be renewed by drying it out.

When renewing the unit, is it normal for it to warm up?

Yes, when you plug the unit in to dry it out, it will warm up. This is how the unit is renewed. The heat allows the clear silica gel inside the unit to expel the moisture it has absorbed. Make sure the unit is in a well-ventilated area during renewal and DO NOT cover the unit.

I see water droplets in the indicator window. Is that normal?

Yes. The unit absorbs moisture. That moisture is released during the drying process. It is normal for released moisture to appear as small water droplets in the indicator window.

How long does it need to be plugged in to completely dry out?

The time will vary based on atmospheric conditions. We recommend you leave the unit plugged in overnight. The unit should not be plugged in for more than 18 hours.

Warranty Information

E-333 WARRANTY CARD

This is a limited warranty against any manufacturer defects. Normal wear, abuse or improper use of this product is not covered under this limited warranty. This warranty will no longer be valid if the product has been tampered with, taken apart or repaired by anyone other than Eva-Dry. This limited warranty is the only one to apply to this product, and sets forth all responsibilities of Eva-

Dry, regarding this product. There is no other warranty, other than described herein. All Eva-Dry products must be registered within 30 days of purchase to activate this warranty. WARRANTY IS NON-TRANSFERABLE.

Mail warranty card to the address listed below, scan QR code, or register online at eva-dry.com.

Eva-Dry

12191 W. Linebaugh Ave., #152

Tampa, FL 33626

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)

