

GRIDDLE BURNER INSTALLATION

36" RANGE

Upon installation it is necessary to install the griddle burner.

Once installed it does not need to be removed unless there is a desire to wash the burner. It is designed to be removed for cleaning purposes.

The burner is packed in a paper bag and located in the oven cavity.

Although it is not necessary, removing the range top allows for easier installation.

To install, feed the air shutter end of the burner onto the griddle valve brass hood.

Once the burner tube is located on the orifice hood lower the burner onto the burner support locating the pin on the underside of the burner into the burner support.

Test burner for lighting prior to replacing the range main top.

WARNING: DO NOT TURN THE GRIDDLE KNOB UNLESS THE BURNER IS IN PLACE.

ORIFICE HOOD AIR SHUTTER END

BURNER PIN

BURNER INSTALLED

BURNER SUPORT

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.