

OZC19S01 Dehumidifier User Manual



Product Description

This sleek dehumidifier is designed for compact and portable use. Apart from having the advantage of energy-saving and environment-friendly, this product is equipped with 7-colors LED lights, most of all, also performs well on dehumidification.

By quickly inhaling the moist air through the fan, the machine removes the water vapor from the air and discharges the dry and fresh air out of the machine that aims to get rid of the mold from the humid environments, which greatly creates a comfortable and healthy living conditions for you. Ideal for home, office and any small space.

Structure

- 1 ON/OFF Button 4 LED Lights 7 DC port 10 Floater
- 2 Air Outlet 5 Handle 8 Adaptor 11 Tank Cover
- 3 Front cover 6 Air Inlet 9 Cable 12 Water Tank






Specification



Name: Dehumidifier
 Model: OZC19S01
 Rated voltage: 12V
 Rated power: 40W

Instructions

please ensure all the parts are completed and undamaged prior to use.

1. When the dehumidifier is plugged in, a long "beep" can be heard. It's in the standby standards. (see Pic.1)

Press "  " on the top with 1 short "beep", "  " and  light up, the machine starts working; Press again to stop. (see Pic.2)

2. When it's working, the 7-colors LED lights will turn on automatically. Press  to lock your desired color; 2nd Press to turn off the light,  button lights off too; 3rd Press to turn on again. (see Pic.3)



(Pic.1)



(Pic.2)



(Pic.3)

3. When the water tank is 700-800ml full, the red warning light at the bottom will flicker with 3 "beeps", the machine stops working automatically. (see Pic.4)

* Stopping-at-almost-full is a protection to prevent water overflow when moving the tank.

4. How to empty the water tank

When the machine is powered off, take the tank by holding the sides of the tank and pressing the front cover with your fingers (see Pic.5). Take off the cover and pour out the water (see Pic.6).

5. Press  to restart, after fitting the water tank back.



(Pic.4)



(Pic.5)



(Pic.6)

Maintenance

1. Wipe the machine body with neutral detergent and wash the tank directly with water to ensure the service life of the machine.
2. When the machine has been cleaned, wipe to dry with a soft and dry cloth.
3. After being cleaned and wiped, put it back to the box for storage.

WHY IS IT UNDERPERFORMING? (less water in the tank)

- Is the door or window open? (Please close the doors and windows.)
- Is there any obstacle blocking the air inlet/outlet?
- Is there any other equipment releasing steam indoors?
- Is the indoor temperature too low? (the dehumidification capacity will be affected in a low temperature and low humidity environment. If the indoor temperature is lower than $(8^{\circ}\text{C} / 46.4^{\circ}\text{F})$ the effect of dehumidification is not obvious).

SAFETY INSTRUCTIONS

This dehumidifier was made with safe and environmental protection materials, it has been certified and complied with the requirement of sale region's related regulations or laws. Important: Please

read the Cautions Notice before using the device. Basic precautions should always be followed to reduce the risk of fire, electrical shock, and injury to persons or damage to the product.

1. Before use, please check the applied voltage matches with the adapter label.
2. DO NOT turn on the machine when the wire is damaged, ask customer service for help.
3. Keep it away from the obstacles to avoid any block-up of the air inlet or outlet.
4. DO NOT use in inflammable and explosive environment or which is above $(40^{\circ}\text{C} / 104^{\circ}\text{F})$. Ideal operation environment: Temp: $(8^{\circ}\text{C} - 40^{\circ}\text{C}(46.4^{\circ}\text{F} - 104^{\circ}\text{F}))$
5. Please switch off and plug out the machine if you're not using it.
6. DO NOT twist or pull the wire.
7. DO NOT use the dehumidifier in a lean place of angle more than 10 degrees.
8. DO NOT cover the machine to avoid overheating.
9. DO NOT use the dehumidifier in condition of low temperature, dusty or volatile place of acid, alkali and oil.
10. DO NOT touch the plug with a wet hand in case of electric shock.
11. DO NOT put any object into the dehumidifier while it's working.
12. This appliance can be used by children aged from 8 years old and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
13. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
14. Machine surface can be cleaned by soft cloth neutral detergent instead of petroleum, alcohol and other organic agents.
15. DO NOT use unmatched adaptor.
16. DO NOT disassemble the product or component by yourself.
17. It is normal that the adapter will get hot (no more than (80°C) or (176°F) during running).

Warranty

We appreciate your feedback and will do our best guarantee your satisfaction.

Within 1 year after your purchase, shall the product has defects, we will provide a refund or resend you a new one. Please email us with your concern and order number. Your inquiries will be taken care of as soon as possible.

This warranty only cover orders from authorized brand online stores and our official website. We are not responsible for any purchases from other distribution channels.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)

