

## Product introduction

Colorful youth color matching delicate and easy to hold. Clean the dust at a time never suffer from a messy surface. Enjoy your clean and new life

### Parameter

- Name: Baseus A2 Car Vacuum Cleaner
- Color: Black, Green, White
- Suction: 5.00
- Charging time: 3-3.5h
- Battery capacity: 21.6Wh
- Input: 524A ad)
- Rated power 70W
- Battery duration: 18min
- Noise: <75dB
- Charging port: Type interface
- Size: 253\*60\*60mm

### Included Accessories



Two-in-one suction nozzle \*1



Blowing hose \*1



Charging cable \*1



Storage bag \*1

### Charging and Use

Before using for the first time, the lithium ion battery must be fully charged, even if the battery itself still has some power left

#### Charging

1. Make sure the product power is off
2. Plug the power adapter into a power outlet

3. Insert the charging cable into the charging port of the vacuum cleaner. The charging indicator flashes blue, indicating that the vacuum cleaner is charging. The charging indicator lights up steadily indicating that the vacuum cleaner is fully charged.

### Tip

If you do not intend to use this product for a long period of time, please unplug the adapter from the socket to conserve energy.

## Usage



① Open the lid.



② Push the power button.



③ Align the suction port of the running machine with the surface of the object to be cleaned.



④ Hold the vacuum cleaner to suck dust and debris.



⑤ Special nozzles and hoses can be used in special areas.



⑥ Turn the dust cup to take out the dust bin and pour out the debris.

## Maintenance

Make sure to empty and clean the dust bin regularly and do not leave debris in the dust bin or an extended period of time.

1. With the power off turn the dust cup to remove the dustbin and pour out the dust and debris.

2. Gently tap the filter to remove the dust attached.
3. Gently wipe the dust cup with a dry cloth to clean.
4. Clean the dust compartment filter with clean water, dry all parts completely, and then reassemble.

## Replacement

After prolonged use or when it can no longer be cleaned. we recommend that you replace the filter

Part Name	China RoHS controlled substances or elements					
	Pb	Hg	Cd	Cr(VI)	PBBs	PBDEs
Circuit	×	○	○	○	○	○
Switch	○	○	○	○	○	○
Power Cable	×	○	○	○	○	○
Motor Components	○	○	○	○	○	○
Rubber Components	○	○	○	○	○	○
Accessories	○	○	○	○	○	○
Filter components	○	○	○	○	○	○
Dust Bin Components	○	○	○	○	○	○
Body & Frame Components	○	○	○	○	○	○

## Danger

- 1 Never breathe water or other liquids; never breathe flammable substances; or breathe uncoated ash
2. Never immerse the vacuum cleaner or charger in water or any other liquid.

## Warning

1. Before connecting the product to the power supply. please check whether the voltage marked by the product is consistent with the local power supply voltage
2. If the vacuum cleaner is damaged. please do not use
3. This product is not suitable for people (including children) who are not physically sound, are mentally handicapped, or lack relevant experience and operating knowledge. unless someone responsible for their safety supervises or directs their use of his product
- 4 Please do not let children play with this product.

## Note

- 1, Before cleaning the vacuum cleaner, be sure to unplug the adapter from the wall outlet.
- 2 Only use the charging cable provided with this product to charge the vacuum cleaner. During charging, the adapter will be slightly hot, which is normal.
3. When using be sure to cut off the power of the vacuum cleaner
- 4 Do not block the exhaust when vacuuming.
5. Please turn off the product power when charging.
- 6 Please install the filter before use.
7. The temperature range for product charging, storage and use is between 5°C - 35°C
8. Do not disassemble the battery, and prevent it from contacting fire, heat or direct sunlight

This chapter summarizes the most likely problems encountered when using this product. You cannot solve the problem based on the information below. Please contact the customer service center in your country (region).

## Troubleshooting

### 1. The product does not work

The battery may be low; please charge the battery.

1. You may not have connected the vacuum cleaner to the charger correctly. Please connect the vacuum cleaner to the charger with the charging cable. The charging indicator should light up, indicating that the vacuum cleaner is charging.
2. You may not have plugged the adapter into the power outlet correctly; please plug the adapter into the power outlet.
3. Blocking the filter will cause the temperature of the vacuum to rise and a red light will flash indicating temperature protection has engaged. After cleaning the filter and the vacuum cools down, it will continue to operate normally.
4. If the product still does not work properly, please send the product to local distributor or an authorized customer service center and ask them to check.

### 2. The charging indicator does not light

Make sure the adapter is properly plugged into the power outlet and the vacuum cleaner is turned off

### 3. The vacuum cleaner does not vacuum properly

The dustbin may not be installed correctly on the product. Please install the dust bin correctly on the vacuum cleaner.

The dust container may be full. Please empty the dust container.

The filter may be clogged. Clean the inner filter and the outer filter

#### **4. Dust spilled from the vacuum cleaner**

The dust container may be full. Please empty the dust container.

The dust bin may not be installed correctly on the product. Please install the dust bin correctly on the vacuum cleaner

The filter may not be placed correctly in the dust bin. Install the filter properly in the dustbin.

#### **5. The vacuum cleaner does not work properly when installing an accessory to the suction nozzle**

The dust container may be full. Please empty the dust container.

The accessory may be blocked. Remove the obstruction from the accessory and try again

The filter may be clogged. Clean the inner filter and the outer filter.

#### **Warning**

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.