



User Manual for SOUNDPEATS Q30 HD Wireless Headphones




Introduction

Thank you for choosing SOUNDPEATS Q30 HD Wireless headphones. Please read the manual carefully, and keep it for further reference. If you need any assistance, please contact our customer support team by emailing support@soundpeatsaudio.com

Package Content



Product Diagram



1. USB Charging Port
2. Volume+/Next Track
3. Multifunctional Button
4. LED Indicator/Microphone
5. Volume-/Previous Track

Specifications

Bluetooth Profile	BT5.0, HSP, HFP, A2DP, AVRCP
Bluetooth Chipset	QCC 3034
Audio Codec	SBC, APTX HD
Play Time	Up to 13 hours (Varies by volume level and audio)
Charging Time	About 1.5 hours
Maximum Working Range	10m
Earbud Dimension (L * W * H)	626 x 21.5 x 29.5 mm
Earbud Weight	16.1g

Button Control

Function	Operation
Power On	Press and hold the Multifunctional Button for 3s until the led light flashes blue
Power Off	Press and hold the Multifunctional Button for 3s until the led light flashes red
Play / Pause	Short press the Multifunctional button
Volume +/-	Short press the +/- button
Play Next/Previous	Long press the +/- button for 2 seconds
Answer Phone Call	Short press the multifunctional Button
Hang Up	Short press the Multifunctional Button in an active call
Reject Phone Call	Press the Multifunctional button for 1.5s
Mute / Resume A Call	Double tap the MFB during a call
Transfer Between Headset and Phone	Press the Multifunction button for 1.5s during a call
Activate Voice Assistant	Double press the Multifunctional button while in playing or pausing mode
Factory Reset	Press the Multifunction button for 3s when the headset is charging

LED Indicators

Status	Earbuds LED Indicator
Charging	LED indicator is solid red
Fully charged	LED indicator is solid blue
Low battery	LED indicator flashes red once every 6 seconds
Reset	LED indicator flashes blue twice quickly

How to Wear

1. Identify the right and left earpieces.
2. Insert the earbuds into your ears. Adjust the ear fins direction and put them into your ears.
3. Adjust each earpiece until it fits flush in your ear and the ear tip seals in the ear canal.



Get Started

Pairing

1. Power on the headset, press and hold the Multifunctional button for approximately 3 seconds until the LED indicator flashes blue quickly (you will hear the voice prompt "power on" first, just keep holding the multifunctional button). Now the headset is in pairing mode.
2. Activate the Bluetooth on your device and search for the nearby Bluetooth connection:
For iPhone/iPad/iPod®: Settings -> Bluetooth -> On
For Android™: Setting -> Wireless & Networks -> Bluetooth -> On -> Scan for devices
For Windows® Phone devices: Settings -> Bluetooth -> On
3. "SOUNDPEATS Q30 HD" should be listed in the search result. Select the name to connect. Once connected, the indicator will be solid blue. You will hear a voice prompt "Your headset is connected".

Notes:

1. When you want to unpair the headset with the device, just press the volume buttons + and - simultaneously for about 3s.
2. The Q30 HD headset will stay in pairing mode for 3 minutes at most if no pairing device is found. Afterwards, it will power off automatically.

Charging

1. Connect the charging port with any USB charging adapter or charging port available.
Charging starts automatically with LED indicator turning red and the headset turns off.
2. The headset is fully charged when the LED indicator turns blue.

Notes: When charging with a USB adapter, the charging current should not be greater than 1A.
Please do not use quick charger to charge the headphones.

Care and Maintenance

- Keep the headset away from heat and humidity.
- Do not put the product under direct sunlight or hot areas. High temperatures will shorten lifespan of the headset, battery and / or the internal circuit board.
- Power off the headset when not in use and before storing.
- Do not try to take the product apart.
- Do not drop or knock your headset on hard surfaces.
- Do not use chemicals or detergents to clean the product.
- Do not scrape the surface with sharp objects.

Warranty

We warranty this device 12 MONTHS from date of the original purchase for manufacturer defects.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)