

QUICK SETUP GUIDE Bluetooth Mouse


PACKAGE CONTENTS


- Wireless mouse
- AA battery
- Quick Setup Guide

SYSTEM REQUIREMENTS

- Windows® 10, Windows® 8.1, Windows® 8, Windows® 7, or
- Mac OS X 10.4 or higher
- Built-in Bluetooth function or Bluetooth receiver


FEATURES



FUNCTION	DESCRIPTION
LED indicator	<ul style="list-style-type: none">• Lights for ten seconds when you turn on your mouse.• When the connect button is pressed, the red LED keeps blinking until paired successfully or pairing time-out (ten minutes).• Low battery warning: Blinks for six seconds when mouse stops moving.
 Connect button	Press to put your mouse in pairing mode.

INSTALLING A BATTERY



1. Remove the battery cover, then insert a AA battery. Make sure that the + and – match the symbols inside the battery compartment.




2. Replace the battery cover.

CONNECTING YOUR MOUSE

Windows OS:

1. Slide the power switch to **ON**, then press the  connect button on the bottom of your mouse. The LED indicator blinks.
2. Click the  Bluetooth icon in your computer's taskbar.
Note: If your adapter is turned off, right-click the icon, then select **Turn adapter on**.
3. Click **Add a device**. Your computer searches for your mouse.
4. Double-click **Insignia Bluetooth Mouse**. When pairing is complete, the LED indicator turns off.


Mac OS:

1. Slide the power switch to **ON**, then press the  connect button on the bottom of your mouse. The LED indicator blinks.
2. Open **System Preferences**, then click **Bluetooth**.
3. Click **+** in the lower-left corner. Your computer searches for your mouse.
4. Double-click **Insignia Bluetooth Mouse**. When pairing is complete, the LED indicator turns off.

Note: If your computer has never connected to a Bluetooth device, click **Set Up New Device** to pair your mouse to your computer.

UN-PAIRING YOUR MOUSE

Windows:

1. Click the  Bluetooth icon on your task bar.
2. Click Show Bluetooth Devices.
3. Right-click Insignia Bluetooth Mouse.
4. Click Remove Device to un-pair the mouse.

Mac:

1. Open **System Preferences**, then click **Bluetooth**.
2. Click the – in the lower-left corner.
3. When it asks Are you sure you want to remove this device?, click **Remove**

USING YOUR MOUSE

Turning your mouse on or off

- Slide the OFF/ON switch to turn your mouse off or on.
- Your mouse sleeps after 10 minutes of inactivity to save battery life.
Move your mouse or press a button to wake it up.

Adjusting mouse sensitivity (DPI):

Note: The default setting is 1200 DPI.

- Press the DPI button to toggle between 800, 1200, or 1600 DPI. The LED blinks when you switch the sensitivity:

LED blinks once	LED blinks 2 times	LED blinks 3 times
800 DPI	1200 DPI	1600 DPI

- You may also be able to adjust your mouse sensitivity with your computer's settings. See your operating system's instructions for more information.

CLEANING YOUR MOUSE


- Wipe the mouse with a damp, lint-free cloth.

SPECIFICATIONS

- **Dimensions (L × W × H):** 2.78 x 1.56 x 3.73 in. (7.05 x 3.94 x 9.48 cm)
- **Weight:** 3.07 ± 0.18 oz. (87 ± 5 g)
- **Battery:** 1 AA alkaline battery
- **Battery life:** 6 months (based on average usage)
- **Operating distance:** 33 ft (10 m)
- **Radio frequency:** Bluetooth 3.0
- **Compatibility:** Bluetooth 2.1, 3.0, 4.0, 4.1
- **Rating:** 1.5V C.C – 10mA

TROUBLESHOOTING



PROBLEM:	SOLUTION:
<p>My mouse is not working.</p>	<ul style="list-style-type: none"> • Make sure that the battery is installed correctly and that the switch is turned ON. Replace the battery if it still does not work. • Move your mouse closer to your computer. • Make sure that your computer meets the system requirements. • Make sure that your mouse is paired by pressing the  connect button on the bottom of your mouse, then pair it with your computer. • Make sure that the Bluetooth function on your computer or Bluetooth receiver is working. • Un-pair your mouse from your computer, then re-pair it.
<p>The screen cursor does not move properly</p>	<p>If your screen cursor lags behind the movement, then your Bluetooth connection may not be able to transmit all of the data from the mouse with the necessary speed. This may be caused by interference from other radio sources, obstructions in the radio wave path, excessive distance from the computer, or a combination of the above.</p> <ul style="list-style-type: none"> • Remove any metallic objects from the line of sight between your computer and the Bluetooth mouse. • If you are using a computer with a built-in Bluetooth antenna, try reorienting the computer until you get a better data rate. • If you are using a Bluetooth dongle, use a USB extension cable and place the Bluetooth dongle onto your desktop or somewhere in sight of your Bluetooth mouse. • Move the mouse closer to your Bluetooth dongle. • Turn off the mouse, and then turn it on again for a better connection. • Disconnect any Bluetooth audio devices, such as headsets, that may be connected to your computer. • Switch off any other devices operating in the 2.4 GHz radio spectrum, such as a Wi-Fi network or mobile

telephone, or move their antennas further away from your computer.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

