


WHAT'S IN THE BOX




BLUETOOTH PAIRING



PLAY



CHARGING



CARABINER



WATERPROOF DUSTPROOF IP67



Warning:

- To protect battery lifespan, fully charge at least once every 3 months. Battery life will vary due to usage patterns and environmental conditions.
- Do not expose the JBL Clip 4 to liquids without removing cable connection. Do not expose JBL Clip 4 to water while charging. It may result in permanent damage to the speaker or power source. After a liquid spill, do not charge your speaker until it's

completely dry and clean. Charging when wet might damage your speaker. When using an external adapter, the output voltage/ current of the external adapter should not exceed 5V/3A.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)