D918

EN DE FR IT ES

RC Dinosaur User Manual

V1.0



Assembly instructions



Remote control and dinosaur charging





The dinosaur and remote control is equipped with a built-in battery. It is recommended to use a 5V·2A charging adapter(not included in package) and the charging cable included in the package for charging.

When charging, indicator of the dinosaur and remote control lights up red, and it turns off when fully charged.

Charging Safety Instructions
1. Do not use incompatible chargers.
2. Charge under adult supervision. Do not charge on bed, sofa or flammable surfaces.
3. Unplug the power in time after fully charged.
4. Do not charge in high temperature, humid or closed environment. Stop charging if overheating, swelling or odor occurs.
5. Turn off the dinosaur and controller before charging.
6. Keep away from children during charging.
7. Do not disassemble or dispose of dinosaur at will.

Operation Guide



Step 1. Turn on dinosaur



Step 2. Turn on remote control

Note: The remote control will automatically pair with the dinosaur once powered on.



Step 3. Install the SD card

Please install an SD card into the SD card slot of the remote control before using it to take photo or video.

Supports up to 32GB SD card (not included).

Remote Control Functions

Component names

1. Camera
2. Spray nozzle
3. Water filling port
4. Rear claw
5. Front claw with wheel



Note: Please add water into the water filling port first for the spray function.

Package content

		
Remote control	Dinosaur	Water filler
		
Screwdriver	USB cable	Instruction manual

Disclaimer and Safety Warnings

1. This package and instruction manual contain important information. Please keep it for future reference.
2. You are responsible for ensuring that this rc car will not cause personal injury or property damage to others.
3. Please strictly follow the instructions shown in the manual during operation to avoid possible injuries caused by the car colliding with your head, face, or body.
4. The company and distributors are not responsible for physical loss, damage, or injury caused by improper operation.
5. Users aged 8 years and older should use this product under the guidance of an adult. Children under 8 years of age are prohibited from using this product.
6. This product contains small parts. Please keep it out of the reach of children to avoid the risk of suffocation caused by accidental swallowing of parts.
7. It is strictly forbidden to use this product near roads or areas with heavy traffic to avoid accidents.
8. Do not disassemble or reassemble the remote-controlled car, otherwise it may cause malfunctions during operation.
9. Please connect to the designated power source that matches the product' s specifications when charging.
10. When charging, please do so under the supervision of an adult. Keep away from any combustible materials during charging and keep it within your sight at all times while charging.
11. Keep the remote-controlled car as far away as possible from other electrical or electronic equipment, or areas with magnetic objects, to prevent mutual interference.
12. Keep your remote-controlled car within sight at all times during operation.
13. Never operate the remote-controlled car above the heads of a crowd.
14. Understand and comply with local operation restrictions and requirements.
15. Please ensure that the environment and equipment are in good condition before and after operation.
16. If the remote-controlled car is damaged or malfunctions, do not attempt to repair it yourself. Please contact our after-sales team to resolve the issue.
17. This product is equipped with a camera. You must respect the privacy of others when taking photos or recording videos. Recording or transmitting images of individuals without their consent may violate local, state, and federal privacy laws.
18. This remote-controlled car may be dangerous during use. Please ensure that it is far away from any people or spectators during operation.
19. Improper installation, poor use conditions, or unfamiliar operation may cause damage to the remote-controlled car or personal injury, and may also lead to accidents. Please pay special attention to operation safety and learn to identify more dangerous situations that may be caused by your own negligence.
20. Stay away from obstacles and people. During operation, this remote-controlled car may have slight changes in speed or sensitivity, which may cause potential hazards. Therefore, please stay away from crowds, buildings, trees, high-voltage lines and other objects. At the same time, please avoid using it under severe weather conditions such as heavy rain, thunderstorms, and strong winds to ensure the safety of users, spectators and surrounding property.
21. Keep away from humid environments. The interior of the remote-controlled car is composed of many precision electronic and mechanical parts. Therefore, please try to avoid any moisture or water entering the car body, otherwise it may cause malfunctions of mechanical and electronic parts and lead to accidents.
22. Only use the included parts for their intended purpose. Please use original parts for modification or maintenance to ensure operation safety. Please operate and use within the range allowed by the product function. The use of unapproved parts will invalidate the warranty. Do not use the remote-controlled car for any illegal purpose or beyond the scope specified by local laws and regulations.
23. The remote-controlled car owner shall not operate the remote control while under the influence of drugs or alcohol. Please operate this remote-controlled car according to your own physical condition and operation skills. Any fatigue, poor mental state, or incorrect operation may increase the risk of accidents.
24. Emergency Response: In the event of a remote-controlled car crash, fire, or battery leakage, immediately stop using the product, disconnect the power supply, and move to a safe distance. For battery leakage, avoid contact with the leaked liquid; if contact occurs, rinse the affected area with plenty of water and seek medical attention if necessary.
25. Compliance Disclaimer: This product complies with FCC Part 15 Class B requirements for export to North American markets. The manufacturer and distributors shall not be liable for any non-compliance risks, losses, or penalties caused by the buyer's failure to comply with the import regulations of the destination country/region, improper use beyond the scope of compliance, or unauthorized modification of the product. The buyer shall be solely responsible for ensuring that the product complies with the relevant laws, regulations, and compliance requirements of the destination country/region during import and use.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

APP 操作指南

1、安装手机客户端　请扫描对应二维码到相应网站下载 APP。

IOS　　Android

2、添加设备　给设备通电，手动连接WIFI热点至“KY/HD/Du/******”，无密码。

图 1

图 2

图 3

3、欢迎界面　操作说明（FAQ）、系统设置（SETTING）、启动(START)、如图1所示。

4、操作方式　播放界面及各按键的功能，如图 2 所示。

5、手势识别　打开播放界面右侧设置菜单，点击 图标 ，开启手势识别功能 如图 3.

手势拍照　在 恐龙 镜头正前方 2m 左右，单手手掌（掌心向前）在身侧平举；飞行器识别手势后，开始 3 秒倒计时后拍照（此时可放下手臂）. 图 4 ， 图 5。

（*连续两次识别的时间差应大于 3 秒）

（*部分机型不支持此功能，开启功能会导致画面延时）

手势录像　在恐龙 镜头正前方 2m 左右，单手握拳（掌心向前）在身侧平举；飞行器识别手势后，开始 3 秒倒计时后开始录像（此时可放下手臂）；进行录像中识别拳头手势时，结束录像。图 6 ，图 7 。

（*录像进行中不检测手掌）

图 4 （正确手势）

图 5 （错误手势）

图 6 （正确手势）

图 7 （错误手势）

6、音乐录像　点按 图标进入音乐库选择背景音乐，并点按**使用**，返回控制界面，录制视频中即有背景音乐。

7、手动调焦　按住控制界面最左侧的**轨迹球**，滑动可调整图像焦距（1X～50X 倍率数码放大）。

1X ： 关闭焦距调整，此时图像是默认大小。　**50X** ： 50 倍最大焦距。

：录像过程中，可以上下滑动此按键手动调整焦距。

8、 特效功能　在控制界面上点按 进入特效控制界面，再次点按 会出现各种特效选项，选择好特效后，点按 退出特效选项。点按 ✕ 可以退出特效，返回主控制界面。

旋转特效：在滤镜控制界面上点按 ，使用一次旋转特效。

注意：1只恐龙，同一时间，仅允许一个手机 App 连接！（详细操作参照app内使用说明）

APP Operating instructions

1. Install mobile client　Please scan the two-dimensional code to downloadAPP.

IOS　　Android

2.Add device　Power the device, manually connect WIFI hotspot to “KY/HD/Du/******”, no password.

Figure 1

Figure 2

Figure 3

3.Head interface　SETTING, FAQ, START , Figure 1.

4.Operation mode　Play the interface and the functions of each button, as shown in Figure 2.

5.Gesture recognition　Open icon of playback interface and gesture recognition function.

Gesture photo　About 2 meters in front of the dinosaur lens, the palm of one hand (palm forward) is raised flat on the side of the body; after the dinosaur recognizes the gesture, it starts countdown for3 seconds and takes pictures (at this time, the arm can be lowered). Fig. 4,Fig. 5.

（* The time difference between two consecutive identifications should be greater than 3 seconds.）

（* Some models do not support this function. Opening the function will cause picture delay. ）

Gesture video　About 2 meters in front of the camera, one hand clenches the fist (palm forward) and holds it flat on the side of the body; after the aircraft recognizes the gesture, it starts recording after countdown of 3 seconds (arm can be lowered at this time); when recognizing the fist gesture in the video, it ends the video. Figures 6and 7.

（*No palm detection during video recording）

Fig. 4（correct）


Fig. 5（Not correct）


Fig. 6（correct）

Fig. 7（Not correct）

6. Music recording: click the icon to enter the music library and select background music, and then click use to return to the control interface, where there is background music.

7. Manual focusing: press and hold the track ball on the left most side of the control interface, and slide to adjust the image focal length (1x-50x digital magnification).

1X: turn off focus adjustment, and the image is the default size.　**50x:** 50 times the maximum focal length.

: in the process of recording, you can manually adjust the focal length by sliding this key up and down.

8. Special effects　**Filterspecial effects:** on the control interface, click to enter the filter control interface.

Click again to display various filter options. After selecting the filter, click to exit the filter option.

Click to exit the filter and return to the main control interface.

Note: only one mobile app is allowed to connect to an dinosaur at the same time!

(For detailed operation, please refer to the instructions in app)

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.