60x90mm

VOULAO

无线耳机 VL02

快速入门指南
VL02

产品规格

型号: VL02

蓝牙

距离:≈10 m
版本: 6.0

扬声器

直径: 6 mm
阻抗:16Ω

耳机功率

输入:5V⎓25mA
电池容量: 25mAh
使用时间:≈4 hrs
充电时间:≈1.5 hrs

充电仓功率

输入:5 V⎓ 220 mA
输出:5V⎓50 mA
电池容量: 220 mAh
充电时间:≈1.5 hrs
充电仓充满电时,能给耳机充电约3次

物品清单



充电仓

2 耳机

快速入门指南

USB-C充电线

部件



取出耳机并配对



如果您是第一次使用耳机,请将两个耳机从充电仓中取出,其中一个耳机的LED灯将会交替闪烁白灯和蓝灯,表示它们处于配对模式。
注:
·如果耳机未与任何设备配对,打开后会自动进入配对模式。配对成功后,您会听到提示音。
·如果耳机之前已配对,打开后会自动重新连接。连接时您会听到提示音。

如何佩戴耳机





开机和关机

开机
自动开机:将耳机从充电仓中取出,耳机开机。
手动开机:长按3秒,耳机开机。

关机
自动关机:耳机放入充电仓中,耳机关机。
手动关机:长按5秒,耳机关机。

注:当耳机开机后,3分钟未与蓝牙设备配对,便会自动关机;当配对的蓝牙设备超出信号有效连接距离,且未重新连接时,3分钟后,耳机自动关机。

连接到蓝牙设备

在您的设备上,打开蓝牙并选择连接到"VL02"。

如何重置耳机

如果耳机无法相互配对或重新连接,请同时轻触两只耳机五次以进行重置。注意:重置耳机将清除蓝牙配对历史记录

基本操作

功能操作

· 暂停/播放:轻触任一耳机一次
· 音量加:轻触右耳机四次
· 音量减:轻触左耳机四次
· 上一曲:轻触左耳机三次
· 下一曲:轻触右耳机三次
· 接听/挂断电话:轻触任一耳机一次
· 通话拒接:按住任一耳机2秒
· 启动语音助手:按住左耳机2秒
注:单耳使用时,按住已开机的耳机2秒,均可激活语音助手
· 游戏模式与音乐模式切换:按住右耳机2秒切换
注:单耳使用时,无法切换游戏模式和音乐模式
注:出厂设置默认为音乐模式
注:通知声音较大的是游戏模式
· 降噪模式:轻触任一耳机五次
· 睡眠模式:轻触任一耳机六次

指示灯显示

耳机指示灯	状态
白色和蓝色交替闪烁	两个耳机:开机 单耳机:未配对
白色常亮	耳机充电中
灭灯	配对成功或充满电
充电仓指示灯	**状态**
冰蓝色常亮	耳机充电中
红色闪烁	充电仓充电中
红色常亮	充电仓充满电

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。
表单标记"×"的部件,皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件:包括印刷电路板及其零部件,
电子元器件等,根据产品型号不同,
您所购买的产品可能不会含有以上所有部件。

重要安全说明

在使用本产品之前,请仔细阅读本说明书中的所有安全说明。

常规安全说明

· 小心使用本产品,并将其存放在没有极端温度、高温高压和潮湿的清洁环境中,确保产品存放在不易弯曲或挤压的地方。
· 维修和更换只能由授权的售后服务人员进行。
请勿自行拆卸或更换产品的任何部件,以防受伤或损坏设备。
对产品的任何未经授权的修改都将使保修无效。
· 仅在允许蓝牙传输的环境中使用本产品。

个人安全说明

· 如果产品有明显缺陷或出现膨胀或温度过高等异常,请勿使用。
· 执行需要全神贯注的高风险任务时,请勿使用本产品。
· 为了保护您的听力,请勿长时间高音量收听。
· 请将产品及其包装放在儿童和宠物接触不到的地方,
以防发生吞咽和窒息等事故。

电池安全说明

该产品内置可充电电池,请阅读以下说明,确保安全使用和处置。
· 请勿将产品长时间暴露在热源中,如明火或阳光直射。
· 仅将产品存放在环境温度为 0°C 至 35°C (32°F 至 95°F) 的环境中。
· 请勿在易产生灰尘、烟雾、高温、高压或高湿度的环境中使用
或存放本产品。
· 保持产品干燥,远离液体或湿气。
· 只能使用经 FCC 或 CCC 认证、输出电压为DC 5V/1A的充电器。
· 充电时不要使用产品。
· 产品充电时间不要超过8小时。
· 按照当地的废物管理规定负责任地处理产品。

VOULAO

VOULAO

Wireless Earbud VL02

Quick Start Guide
VL02

Product Specifications

Model: VL02

Bluetooth

Range:≈10 m
Version: 6.0

Speaker

Diameter: 6 mm
Impedance:16Ω

Earphone power

Input:5V⎓25mA
Battery capacity: 25mAh
Battery life:≈4 hrs
Charging time:≈1.5 hrs

Charging case power

Input:5 V⎓ 220 mA
Output:5V⎓50 mA
Battery capacity: 220 mAh
Charging time:≈1.5 hrs
Earphone recharges: 3 charges
(when case is fully charged)

What's in the box



Charging case

2 Earphones

Quick Start Guide

USB-C cable

Components



How to put on the earphones



Power on and off



Power on
If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and blue alternately, indicating that they are in pairing mode. They will automatically power on and await connection.

Power off
Placing the earphones in the charging case and closing the case will automatically turn them off. unconnected state To manually turn off each earphone, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power of after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.

Connect to Bluetooth device

On your device, turn on Bluetooth and choose to connect to " VL02 ".

How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.

Basic operations



Key functions

·Play/Pause: Tap either earbud twice.
·Volume up: Tap the right earphone 4 times.
·Volume down: Tap the left earphone 4 times.
·Play previous track: Tap the left earphone three times.
·Play next track: Tap the right earphone three times.
·Answer/End call: Tap either earbud once.
·Reject call: Press and hold either earphone for two seconds.
·Activate voice assistant: Press and hold either earphone for two seconds.
Note: When using a single earphone only, press and hold the active earphone for two seconds.
·Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)
Note: Mode switching is disabled when you're using a single earphone only.
·Noise cancellation:Tap either earbud 5 times.
·Sleep mode: Tap either earbud 6 times.

Indicator LEDs

Earphone LED	Status
Blinking blue and white	Both earphones: Powered on Single earphone: Unpaired
Solid white	Earphone charging
off	Paired or fully charged
Charging case LED	**Status**
Solid ice blue	Earphone charging
Blinking red	Case charging
Solid red	Case fully charged

Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

General safety instructions

· Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.
· Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
· Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions

· Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
· Do not use the product when performing high-risk tasks that require your full attention.
· For your hearing protection, do not listen at high volume for long periods.
· Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions

The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.

· Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
· Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
· Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
· Keep the product dry and away from liquids or moisture.
· Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
· Do not use the product while charging.
· Do not leave the product charging for longer than eight hours.
· Dispose of the product responsibly according to your local waste management guidelines.

FCC ID:2BTLR-VL02

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

VOULAO